


SLM30-E Swirl Flow Meter

Quick Start Guide – Steam and Liquid Applications



Device firmware version:

- 03.00.01 (HART)
- 02.01.00 (Modbus)

Contents

1. Safety information	3
2. Transport and storage	4
3. Installation	6
4. Electrical connections	14
5. Commissioning	21
6. Approvals	32

1. Safety information

Safe operation of these products can only be guaranteed if they are properly installed, commissioned, used and maintained by qualified personnel (see SLM30-E Installation manual IM- P799- 02) in compliance with the operating instructions. General installation and safety instructions for pipeline and plant construction, as well as the proper use of tools and safety equipment must also be complied with.

This device has been designed for use exclusively within the technical limit values indicated on the identification plate and in the data sheets.

When using measuring media, the following points must be observed:

- Measuring media may only be used if it can be assured that the chemical and physical properties necessary for operational security of the materials of the wetted parts of the flowmeter sensor will not be adversely affected during the operating time.
- Media containing chloride can cause corrosion damage to stainless steels which, although not visible externally, can damage wetted parts beyond repair and lead to the measuring medium escaping. It is the operator's responsibility to check the suitability of these materials for the respective application.
- Measuring media with unknown properties or abrasive measuring media may only be used if the operator is able to perform regular and suitable tests to ensure the safe condition of the device.

Improper use

The following are instances of especially improper use of the device:

- Operation as a flexible compensating adapter in piping, for example for compensating pipe offsets, pipe vibrations, pipe expansions, etc.
- For use as a climbing aid, for example for mounting purposes.
- For use as a bracket for external loads, for example as a support for piping, etc.
- Material application, for example by painting over the housing, name plate or welding/soldering on parts.
- Material removal, for example by spot drilling the housing.

2. Transport and Storage

2.1 Inspection

Check devices after unpacking to ensure they are undamaged. Any damage found must be submitted to the shipper immediately and before any installation.



Danger!

Do not stand under suspended loads

Risk of Injury!

Support the devices laterally during transport

Ensure devices do not slip or turn during transport!




Fig. 1

2.2 Flange devices ≤ DN 300

- Use carrying straps to transport devices.
- Wrap the carrying straps around both process connections. Do not use chains should not be used to prevent damage to the housing.

2.3 Flange devices > DN 300

- Take care using a forklift to transport flange devices to avoid housing damage.
- Flange devices must not be lifted by the centre of the housing.
- Flange devices must not be lifted by the terminal box.
- Only the transport lugs fitted to the device can be used to lift the device for insertion into a pipeline.

2.4 Storing the device

Store the device in its original packaging in a dry and dust-free location.

- Observe the permitted ambient conditions for transport and storage.
- Avoid storing the device in direct sunlight.
- In principle, the devices may be stored for an unlimited period. However, the warranty conditions stipulated in the order confirmation of the supplier apply.

2.5 Ambient conditions

The ambient conditions for the transport and storage of the device correspond to the ambient conditions for operation of the device (below)

2.6 Ambient temperature range

Standard	High Temp
-20 to 85 °C (-4 to 185 °F)	-40 to 85 °C (-40 to 185 °F)

2.7 Relative humidity

Standard	Maximum 85 %, annual average ≤ 65 %
----------	-------------------------------------

3. Installation

A SLM30-E may be installed at any point in the pipeline system.

The following installation/ operating conditions must be considered:

- Compliance to the device min/max ambient and min/max medium temperatures.
- Compliance with the recommended inlet and outlet sections.
- The flow direction must correspond to that indicated by the arrow on the sensor.
- Minimise mechanical vibrations of the piping (by fitting supports if necessary).
- The inside diameter of the sensor and the piping must be identical.
- Avoid pressure oscillations in long piping systems at zero flow by fitting gates at intervals.
- Avoid pulsating flow caused by piston or irregular pump units.
- Ensure the frequency of the conveying equipment must not be within the range of the measuring frequency of the flowmeter.
- Valves and gates should be arranged in the flow direction downstream of the flowmeter (typically: $3 \times \text{DN}$).
- If the medium is conveyed through piston / plunger pumps or compressors (pressures for fluids $> 10 \text{ bar}$ / 145 psi), it may be subject to hydraulic vibration in the pipeline when the valve is closed. If this does occur, the valve absolutely must be installed upstream of the flowmeter. Suitable damping devices (e.g. air vessels) might need to be fitted.
- When fluids are measured, the flow meter must always be filled with measuring medium. The sensor must not be empty.
- There must be no cavitation.
- The relationship between the measuring medium and the ambient temperature must be taken into consideration (see TI-P799-01).
- At high measuring medium temperatures $> 150 \text{ }^{\circ}\text{C}$ ($> 302 \text{ }^{\circ}\text{F}$), the sensor must be installed so that the transmitter or terminal box is pointing to the side or downwards.

8 Critical Steps for correct SLM30-E performance

1) Avoid flow distortion

To maximize operational reliability, the fluid flow profile at the front of the meter must not be distorted. Ensure installation meets the recommendations listed in section 3.1.

2) Avoid Cavitation

Static overpressure is necessary downstream of the flowmeter (downstream pressure).

$$p_1 \geq 1,3 \times p_2 + 2,6 \times \Delta p$$

p_1 = Static gauge pressure downstream of the device (mbar)

p_2 = Steam pressure of fluid at operating temperature (mbar)

Δp = Pressure drop, measuring medium (mbar)



3) High Medium Temperatures

At high measuring medium temperatures $> 150\text{ }^{\circ}\text{C}$ ($> 302\text{ }^{\circ}\text{F}$), the sensor must be installed so that the transmitter is pointing to the side or downward, see section 3.3

4) Installation of external pressure and temperature sensors

SLM30-E meters can accept external pressure or temperature sensors via the 4-20mA input. Install external sensors as shown in section 3.4.

5) Insulation

With reference to section 3.6. A small vent hole is present in the sensor tower. Do not apply insulation above this hole.

Critical Steps continued on next page

8 Critical Steps for correct SLM30-E performance (continued)

6) Auto Zero

The automatic zero function determines the mechanical noise values at the sensor.

If the signal level is above the noise threshold, a valid flow signal will be recognised.

The Auto Zero function is located via the Easy Setup or Device Setup menu :-

Device Setup → Plant/Customized → Field optimization → Auto Zero

Before starting the zero-point adjustment, ensure: -

- a. There is no flow through the sensor (close all valves, shut-off devices etc.)
- b. The sensor must be filled completely with measuring medium for measurement.

7) Manual Zero Point

If the Auto Zero is not possible, the noise threshold must be determined manually.

To do this: -

- a. Read & note the maximum Sig. Amplitude value:

Service → Sensor → Sig. Amplitude

- b. Multiply the maximum Sig. Amplitude value by 1.2 to 2.0.
We recommend 1.7 as the best value to use.

Enter the calculated number as the new 'Low Flow Thld' value: -

Device Setup → Field optimization → Low Flow Thld

Note:

Zero-point settings > 200 indicate an elevated potential for interference (vibrations, pulsations or EMC interference).

In such cases the installation location and installation of the device should therefore be checked and appropriate measures taken, if necessary, to eliminate interference.

8) Advanced Filters

- i. **Stalling Filter**

If the meter is operating at < 30% of the meter maximum range, the stalling filter should be enabled. By ignoring signal losses this meter can enable improved low flow performance.

- ii. **Noise Filter**

Where the signal output is affected by the application (pulses, cavitation, vibration or even EMC interference, activate this filter.



3.1 Inlet and outlet sections

To maximize operational stability, distortion to the flow profile on entry to the flowmeter should be minimised. We recommended the following guideline inlet and outlet sections for various installations: -

3.1.1 Straight Pipe Sections




Fig. 2

Installation	Inlet Section	Outlet Section
A Straight pipe section	min. $3 \times \text{DN}$	min. $1 \times \text{DN}$
B Valve upstream of meter	min. $5 \times \text{DN}$	min. $1 \times \text{DN}$
C Pipe reduction	min. $3 \times \text{DN}$	min. $1 \times \text{DN}$
D Pipe extension	min. $3 \times \text{DN}$	min. $3 \times \text{DN}$

3.1.2 Pipe section with elbows




Fig. 3

Installation	Inlet Section	Outlet Section
Single pipe elbow upstream or downstream of the meter tube	min. 3 x DN	min. 1 x DN

3.2 Avoiding cavitation

To avoid cavitation, a static overpressure is necessary downstream of the flowmeter. The required pressure can be estimated using the following formula:

$$p_1 \geq 1.3 \times p_2 = 2.6 \times \Delta p^d$$

- p_1 = static gauge pressure
- p_2 = pressure of fluid at operating temperature
- Δp^d = pressure drop across the flow meter

3.3 Installation at high medium temperatures




Fig. 4

At medium temperatures $> 150\text{ }^{\circ}\text{C}$ ($302\text{ }^{\circ}\text{F}$), the sensor must be installed so that the transmitter is pointing to the side or downward.

3.4 Installation of external pressure and temperature measurement

The flowmeter may be configured with an optional temperature measurement for applications such a steam mass measurement. However, if pressure and temperature are to be compensated externally (e.g. using a flow computer unit), the measuring points must be installed as below:




Fig. 5

3.5 Control and setting devices

Control elements should normally be installed at least $5 \times \text{DN}$ downstream of the flowmeter. However, if the measured fluid is conveyed via piston pumps / peristaltic pumps or compressors, hydraulic vibrations may occur within the piping when valves are closed. In such cases it is acceptable to position the valve upstream of the flow meter, taking care to ensure there are sufficient pipe diameters before the flow meter to ensure a correct flow profile.




Fig. 6

3.6 Sensor Insulation

The SLM30-E and piping may be insulated.




Fig. 7

Insulation must not under any circumstances be past the small hole in the sensor tower (1).



Take care to ensure that the SLM30-E transmitter does not overheat.

Even with correct insulation, extreme conditions may occur if the transmitter is exposed to high ambient and high medium temperatures.

3.7 Use of trace heating.

Trace heating will not impair EMC protection or generate additional vibrations and is permitted under the following conditions:

- The trace heating is installed directly on or around the flow sensor.
- If installed inside insulation, the maximum insulation thickness must not exceed the maximum insulation depth (see previous image).
- Ambient conditions are observed to ensure the transmitter does not overheat.
- The flow meter is installed in accordance with EN 60079-14.

4. Electrical Connections



Warning!

Risk of injury due to live electrical connections

- Electrical connections should only be carried out by authorised and electrically trained personnel in accordance with the electrical diagrams.
- Only connect the device with the power supply switched off.
- Observe applicable electrical standards and site regulations.

4.1 Signal cables

For remote design, the transmitter and sensor must be connected by a signal cable according to the following specification:

Cable specification

Impedance	70 to 120 Ω
Withstand voltage	500 V
Outer diameter (OD)	6 to 12 mm (0.24 to 0.47 in)
Cable design	3 x 2 x 0.75 mm ² , twisted pair
Conductor cross section	0.75 mm ²
Shield	Copper braid (85% coverage)
Temperature range	80 °C (176 °F) minimum
Maximum length	30 m (98 ft)

4.2 Installing the connection cables

Ensure that a drip loop is used when connecting cables to the sensor. If mounting the sensor vertically, position the cable entries on the downward side of the transmitter. If necessary, rotate the transmitter housing accordingly.




Fig. 8

4.3 Cable glands

All SLM30-E flow meters are supplied with transport sealing plugs. The supplied sealing plugs do not have IP rating 4X / IP 67 and must be replaced with suitable cable glands or sealing plugs during device installation. When selecting the cable glands or sealing plugs, make sure they have the required IP rating.

To guarantee IP rating 4X / IP67, the cable glands / sealing plugs must be screwed in using a suited sealing compound.

4.4 Grounding



Impact on measurement

The measurement may be impacted by external electric disruptions (EMC disruptions).

- Ground the device as shown to avoid impact on the measurement by external electric disruptions (EMC disruptions)




Fig. 9

To avoid potential differences, 3-point grounding (sensor, transmitter and earth) as shown above is recommended.

1. Loosen the screw terminal on the transmitter housing or on the housing of the SLM30-E
2. Insert the forked cable lug for functional grounding between the two metal tabs and into the loosened terminal.
3. Tighten the screw terminal.

Power Supply / Signal Connections (4-20mA / HART)




Fig. 10

The standard SLM30-E is a 2-wire, 4-20mA, loop powered device

Terminal	Function
PWR/COMM +	Power supply, current output / HART output
PWR/COMM -	Power supply, current output / HART output
EXT. METER	Not assigned

Additional options (analog outputs and digital inputs) may be available if selected




Fig. 11


Terminal	Function
PWR/COMM +	Power supply, current output / HART output
PWR/COMM -	
EXT. METER	Current output 4 to 20 mA for external display
DIGITAL OUTPUT 1+	Digital output, positive pole
DIGITAL OUTPUT 2	Bridge after terminal 1+, NAMUR output OFF
DIGITAL OUTPUT 3	Bridge after terminal 4-, NAMUR output ON
DIGITAL OUTPUT 4-	Digital output, negative pole
ANALOG INPUT + ANALOG INPUT -	Analog input 4 to 20 mA from external remote transmitter e.g., temperature or pressure

4.5 Connection to remote mount design


Signal cable is available in four standard lengths: 5 m (16.4 ft), 10 m (32.8 ft), 20 m (65.6 ft) and 30 m (98.4 ft). The cable ends are already prepared for installation.

Signal cable may be cut to any desired length. Ensure cables are prepared correctly as per the following detail:-

Sensor



Transmitter



1	Heat-shrink tube Ø 4 mm, 10 mm long
2	Fork cable lug
3	Heat-shrink tube Ø 2.3 mm, 40 mm long (shielding)

Fig. 12

Twist the shield, shorten and insulate with heat-shrink tube (3).

Crimp a matching forked cable lug (2) and insulate the crimping with a heat-shrink tube (1).

- Attach wire-end ferrules (0.75 mm²) to the wires on the sensor side.
- Twist the wires on the transmitter side and solder.



Before opening the transmitter housing or the terminal box, note the following points:

- Ensure sure that there is no explosion hazard.
- Switch off the power supply and wait at least 2 minutes before opening.

The signal cable is colour matched. Connect the cable as per the following directive:-




Fig. 13

Terminal	Colour / Function
VDD	Yellow
/M/R	White
GND	Green
HS	Pink
DX	Grey
RX	Brown
	Ground terminal (functional ground / shield)

5. Commissioning



Risk of burns due to hot measuring media

The device surface temperature may exceed 70 °C (158 °F), depending on the measuring medium temperature!

- Before starting work on the device, make sure that it has cooled sufficiently.

Risk of injury due to live parts

- Improper work on the electrical connections can result in electric shock.

Note:

This QuickStart document provides basic commissioning guidance for the standard 4-20mA SLM30-E unit.

For additional commissioning guidelines (HART & Modbus), please reference IM-P799-02.

5.1 Checks prior to commissioning

- Ensure the power supply to the flowmeter is switched off.
- The power supply used must match the information on the name plate.
- Correct wiring in accordance with Electrical connections in section 4 of IM-P799-02
- Correct grounding in accordance with Grounding in section 4.4 of IM-P799-02
- The ambient conditions must meet the requirements set out in the specification.
- The transmitter must be installed at a location largely free of vibrations.
- The housing cover and cover lock must be sealed before powering-up the power supply.
- For devices remote design devices, ensure that the sensor and transmitter are assigned correctly.

The device can be factory parameterized to customer specifications.

If no customer information is available, the device will be delivered with factory settings:

Parameter	Factory Setting
Operating mode	Liquid Volume
Output value	Flow Rate
DO function	No function
$Q_{V_{Max}}$ or $Q_{m_{Max}}$ *	Set to Q_{max} DN
Unit Q	m ³ /h

Parameter	Factory Setting
HART In value	No function
Low flow cut off	4%
I out @ alarm	Low
Low alarm value	3.55mA
High alarm value	22mA


Notes: For steam, please select 'Steam/ Water Mass' as the operating mode.

Please ensure the flow meter is correctly sized for the application.

* ' $Q_{V_{Max}}$ ' or ' $Q_{m_{Max}}$ ' is determined by the Operating mode.

5.2 Commissioning/Parameterization using the Easy Setup menu


Remove the transmitter / front housing to access the configuration buttons. You can now set the SLM30-E parameters.




The Flowmeter display is equipped with four buttons.
Use these buttons to access the Easy Setup menu.

Fig. 14

1. Power up the unit so the initial display is visible:




Switch to the configuration level using  (right-hand side button).



Use / and Select 'Standard'.


Confirm the selection with .

If a password has been created, enter it.
Otherwise select OK to proceed



A password is not available as a factory default.


2. You will now enter the Easy Setup menu:



Use  /  make a selection.

Confirm the selection using .

Selection of the menu language




Use  to call up the edit mode.

Use  /  to select the desired language.

Confirm the selection with  and continue with 'Next'.

Select the operating mode




Use  to call up the edit mode.

Use  /  to select the desired operating mode.

Confirm the selection with  and continue with 'Next'.

3. Configuration of the current output




Use  to call up the edit mode.

Use / to select the desired process value for the current output.

Confirm the selection with  and continue with 'Next'.

4. Configuration of the digital output



Use  to call up the edit mode.

Use / to select the desired operating mode for the digital output.

- Logic: Digital Output operates as a binary switch.
- Pulse: Digital Output will operate to provide pulse output.
- Freq: Configurable frequency output proportional to 0-100% flow.

Confirm the selection with  and select 'Next'.

5. Depending on the DO selection set pulse or frequency values - A

Easy Setup

Pulses Per Unit

0000001 /l

Next Edit

Use  to call up the edit mode.

Use // to set pulses per unit (Pulse on DO) or upper frequency (Freq on DO).

Confirm the selection with  and select 'Next'.

Easy Setup

Upper Frequency

1.00 Hz

Next Edit

6. Set pulse or frequency – B

Easy Setup

Pulse Width

0000001 ms

Next Edit

Use  to call up the edit mode.

Use // to set pulses per unit (Pulse on DO) or upper frequency (Freq on DO).

Confirm the selection with  and select 'Next'.


Easy Setup

Lower Frequency

1.00 Hz

Next Edit

7. If 'Logic' is selected for the DO function




Use  to call up the edit mode.

Use  /  to select the switching behaviour for the binary output (NO or NC).

Confirm the selection with  and select 'Next'.

8. Selecting units

Units for the following parameters may be selected (depending on SLM30-E type & configuration); Volume, mass, standard volume, power, density, temperature, pressure, volume flowmeter, mass flowmeter, standard volume flowmeter & energy.




Use  to call up the edit mode.

Use  /  to select the desired units.

Confirm the selection with  and select 'Next'.


9. If the device is analog/HART input enabled, the following options are available:



Use  to call up the edit mode.


Use  /  to select the desired analog / HART input function.

Confirm the selection with  and select 'Next'.



Analog / HART Value	Function	
Ext. T*	External temp Tx	
Pressure	External press Tx	
Gas content	External gas analyser	*Ext. T = Temp Tx downstream of meter
Density	External density Tx	
Int. T*	External temp Tx	*Int. T = Temp Tx upstream of meter
Ext. Cutoff	External output zero	

10. Set the measurement range for external Tx



Use  to call up the edit mode.

Use / to select the desired external Tx measuring range.

Confirm the selection with  and select 'Next'.

Upper Range = 20mA input
Lower Range = 4mA input


Parameters dependent on the operating mode

The next parameters are entirely dependent on the specific operating mode selected for the device. Refer to the operating instruction for detailed information.

Select operating mode

For steam, please select 'Steam/Water Mass' as the operating mode. The default density selection is calculated using the internal temperature sensor (steam table). Edit this parameter if external transmitters are to be used for this function.

11. Setting of the flow rate or energy value at which the device must output 20mA (100%)




Use  to call up the edit mode.

Use / to select the desired external Tx measuring range.

Confirm the selection with  and select 'Next'.

12. Adjusting the damping value




Use  to call up the edit mode.

Use / to select the desired damping value.

Confirm the selection with  and select 'Next'.


13. Configuration of the alarm signaling via the current output



Use to call up the edit mode.

Use to select desired state

Confirm the selection with and select 'Next'.




Use to call up the edit mode.


Use to set the desired alarm current

Confirm the selection with and select 'Next'.

Applicable only for 4-20mA units.
Edit the high and low alarm current for your application.
Otherwise the factory default will be used.



14. Zero point adjustment of the flowmeter




Note: Before starting the Auto Zero ensure:

- There is NO flow through the sensor
- The sensor is filled with the medium to be measured

Use to start automatic adjustment of the zero point for the system.

15. Configuration of the low flow cut-off




Use  to call up the edit mode.

Use / to set the desired value for the low flow cut-off

Confirm the selection with  and select 'Next'.

16. Easy setup complete



Once all the parameters have been configured, the main menu appears again. The most important parameters are set.

The SLM30-E device is now ready to use.

For more further details, please reference the full installation manual: IM-P799-02

6. Approvals

The SLM30-E has been approved for operation in accordance with the following standards:

- SLM30-E is registered all throughout Canada under CRN:0F24350.5C
- PED Module B - EU Type Approval Certificate No. 0045/202/1045/Z/00129/22/001(00)
- PED Module D - Quality Assessment Certificate No. 525-PED-DE-50325/1-Mod-D-1

