



Rapid-action intermittent
blowdown valve



PA 46

PA 47

PA 48



MPA 46

MPA 47

MPA 48

Contents

Foreword	4
Availability.....	4
Formatting features in the document	4
Safety.....	5
Use for the intended purpose	5
Basic safety notes	5
Information on property damage or malfunctions	7
Qualification of personnel.....	7
Typographic features of warning notes.....	7
Formatting features for warnings of property damage	7
Description	8
Scope of supply and equipment specification	8
Optional extras	12
Application of European Directives.....	13
Task and function.....	13
Storing and transporting the equipment.....	14
Storing the equipment	14
Transporting the equipment	14
Mounting and connecting the equipment.....	15
Preparing installation	15
Connecting the equipment	15
Mounting the lever.....	16
Positioning the lever	17
Starting up the equipment.....	18
Operating the equipment.....	19
Operating the PA	19
Operating the MPA	21
After operation	22
Removing external dirt deposits.....	22
Required tools for servicing	23
Tightening torques.....	23
Maintaining the equipment.....	24
Servicing the equipment and installing spare parts	26
Retrofitting the equipment.....	33
Troubleshooting	37
Putting the equipment out of operation	38
Removing harmful substances.....	38
Removing the equipment	38
Re-using equipment after storage.....	39
Returning the valve.....	39
Disposing of the equipment.....	40

Technical data	41
Dimensions and weights.....	41
Flow diagram.....	45
Control pressure for MPA	46
Pressure & temperature ratings	47
Manufacturer's declaration	49

Foreword

This installation & operating manual will help you use the following types of equipment safely and efficiently for their intended purpose.

- ▶ Rapid-action intermittent blowdown valve PA 46 (manual actuation)
- ▶ Rapid-action intermittent blowdown valve PA 47 (manual actuation)
- ▶ Rapid-action intermittent blowdown valve PA 48 (manual actuation)
- ▶ Rapid-action intermittent blowdown valve MPA 46 (automatic actuation)
- ▶ Rapid-action intermittent blowdown valve MPA 47 (automatic actuation)
- ▶ Rapid-action intermittent blowdown valve MPA 48 (automatic actuation)

These types will be called equipment in this document.

This installation & operating manual is intended for anyone commissioning, using, operating, servicing, cleaning or disposing of this equipment and, in particular, for professional after-sales service technicians, qualified personnel and authorised and trained staff.

All of these persons must read and understand the content of this installation & operating manual.

Following the instructions given in this installation & operating manual helps avoiding danger and increases the reliability and service life of the equipment. Please note that in addition to the instructions given in this installation & operating manual you must also observe all locally applicable rules and regulations concerning the prevention of accidents as well as approved safety guidelines for good professional practice.

Availability

Keep this installation & operating manual together with the plant documentation for future reference. Make sure that this installation & operating manual is available to the operator.

The installation & operating manual is part of the equipment. Please hand over this installation & operating manual when selling the equipment or passing it on.

You can find further information, instructions and details of equipment accessories in the respective manufacturer documentation.

These documents are regarded as belonging to this installation & operating manual. Keep these documents together with this installation & operating manual. Hand over this installation & operating manual if you sell or pass on the equipment to a third party.

Formatting features in the document

Certain text elements of this installation & operating manual feature a specific typographic design. You can easily distinguish the following text elements:

Standard text

Cross-reference

- ▶ Listing
 - ▶ Sub-items in listings
- Steps for action.



Here you will find additional useful information and tips serving to assist you in using the equipment to its fullest potential.

Safety

Use for the intended purpose

The following rapid-action intermittent blowdown valves are installed in pipes to discharge boiler blowdown water.

- ▶ Rapid-action intermittent blowdown valve PA 46 (manual actuation)
- ▶ Rapid-action intermittent blowdown valve PA 47 (manual actuation)
- ▶ Rapid-action intermittent blowdown valve PA 48 (manual actuation)
- ▶ Rapid-action intermittent blowdown valve MPA 46 (automatic actuation)
- ▶ Rapid-action intermittent blowdown valve MPA 47 (automatic actuation)
- ▶ Rapid-action intermittent blowdown valve MPA 48 (automatic actuation)

The equipment is designed for discharging boiler blowdown water with non-metallic solids from steam boilers.

The equipment must only be used within the allowable pressure and temperature limits and only if the chemical and corrosive influences on the equipment are taken into account.

The pipe between the steam boiler and the equipment must not be longer than 2 metres.

Correct use includes compliance with the instructions given in this installation & operating manual, in particular obedience to all safety instructions.

Usage for the intended purpose also includes reading and adhering to all instructions in the installation and operating manual for the actuator (if present).

Any other use of the equipment is considered to be improper.

Note that the equipment is also used incorrectly if the materials of the equipment are not suitable for the fluid.

The equipment is also considered to be used improperly if:

- ▶ the equipment is not in proper working condition when being used
- ▶ the equipment is operated or serviced by unqualified personnel. The personnel must have the necessary qualification and experience for the required work.

Basic safety notes

Explosion hazard

- ▶ Explosion risk if equipment is used that is not suitable for the environmental conditions. When using the equipment in explosion risk areas make sure that:
 - ▶ The permissible surface temperature of the equipment for the place of installation must not be exceeded.
 - ▶ If electrically insulated equipment is installed appropriate measures must be taken to discharge any static electricity between pipe flanges.
- ▶ The heat generated by friction caused by moving parts that do not run smoothly can cause explosions. Make sure that all moving parts can operate smoothly.
- ▶ When carrying out welding work in order to install or remove the equipment flying sparks may be generated that can cause fire or explosion. Observe any on-site regulations for fire and explosion prevention. Only qualified personnel is allowed to mount or remove the equipment or its components.

Risk of severe injuries

- ▶ The equipment is under pressure during operation and may be hot. Before carrying out any work on the equipment make sure that the following requirements are met:
 - ▶ The pipes must be depressurized (0 bar).
 - ▶ The fluid must be completely removed from the pipes and the equipment.
 - ▶ During work on the equipment the installation must be switched off and protected against unauthorised or unintended activation.
 - ▶ The pipes and the equipment must have cooled down to room temperature (approx. 20 °C).
- ▶ If the equipment is used in contaminated areas there is a risk of severe injuries or death caused by harmful substances in or on the equipment. Before working on the equipment make sure that it is completely decontaminated. Always wear the protective clothing prescribed for contaminated areas when working on the equipment.
- ▶ The equipment must only be used with fluids that do not attack the material and the gaskets and sealings of the equipment. Otherwise leaks may occur and hot or toxic fluid could escape.
- ▶ The equipment and its component parts must only be mounted or removed by qualified personnel. A qualified person must be acquainted with and experienced in the following:
 - ▶ Making pipe connections.
 - ▶ Selecting suitable lifting gear and understanding the rules for its safe use.
 - ▶ Working with dangerous (contaminated, hot or pressurized) fluids.

- ▶ If the admissible temperature and pressure limits are exceeded the equipment may be destroyed and hot or pressurized fluid may escape. Make sure that the equipment is only operated within the admissible service range and limits.
For more information on limits and pressure & temperature ratings see name plate and the section "*Technical Data*".
- ▶ The moving parts of the equipment can cause severe injuries or death. Make sure that nobody is standing close to these moving parts or can touch them while the equipment is operating. Before working on the equipment make sure that the power supply to the actuator is cut off and cannot be switched on accidentally.
- ▶ If the stuffing box is leaking there is a risk of severe injuries caused by escaping hot fluid. Use the equipment only if it is in proper working condition. Replace any leaking stuffing box seal.

Risk of minor injuries

- ▶ Sharp edges on internals present the danger of cuts to hands. Always wear industrial gloves when servicing the equipment.
- ▶ If the support of the equipment during installation is insufficient the equipment might fall down, thereby causing bruises or injuries. Make sure the equipment is safely held in place during installation and cannot fall down. Wear protective safety footwear.

Information on property damage or malfunctions

- ▶ Malfunctions will occur if the equipment is installed in a wrong position or with the flow arrow pointing in the opposite direction of the fluid flow. This may result in damage to the equipment or the installation. Make sure that the flow arrow on the equipment body matches the indicated direction of the fluid flow in the pipe.
- ▶ If the material is unsuitable for the fluid, increased wear may occur and fluid may escape. Make sure that the material is suitable for the fluid used in your installation.

Qualification of personnel

A qualified person must be acquainted with and experienced in the following:

- ▶ the pertinent on-site rules and regulations for preventing fire and explosions as well as industrial safety regulations
- ▶ working on pressure equipment
- ▶ making pipe connections
- ▶ working with dangerous (hot or pressurized) fluids
- ▶ lifting and transporting loads
- ▶ observing all notes and instructions in this installation & operating manual and the applicable documents
- ▶ connecting the power supply of the actuator

Typographic features of warning notes



DANGER

Notes with the heading **DANGER** warn against imminent dangerous situations that can lead to death or serious injuries.



WARNING

Notes with the heading **WARNING** warn against possibly dangerous situations that could lead to death or serious injuries.



CAUTION

Notes with the heading **CAUTION** warn against dangerous situations that could lead to minor or moderate injuries.

Formatting features for warnings of property damage

Attention!

This information warns of a situation leading to property damage.

Description

Scope of supply and equipment specification

Scope of supply

The following parts are included in the scope of delivery for PA valves:

- ▶ An intermittent blowdown valve
- ▶ A lever
- ▶ This Installation & Operating Manual

The following parts are included in the scope of delivery for MPA valves:

- ▶ An intermittent blowdown valve with diaphragm actuator
- ▶ This Installation & Operating Manual

Type PA valves have the lever included in the packaging.


Type MPA valves are supplied ready for installation.

Equipment specification



PA and MPA valves have different types of actuator. Below, the two types of actuator are shown in separate diagrams. The body with inner parts is identical in both valves and is shown separately.


PA actuator



No.	Designation
1	Lever
2	Lock
3	Spacer tube
4	Pressure fitting
5	Control pin

No.	Designation
6	Inspection hole
7	Clevis
8	Guide bushing
9	Pressure plate
10	Hexagon head bolt


MPA actuator



No.	Designation
11	Emergency lever
12	Spacer
13	Diaphragm actuator

No.	Designation
14	Connection for control medium G 3/8
15	Lubricating nipple
16	Connection sleeve

PA/MPA body



No.	Designation
17	Cone
18	Name plate on body ATEX name plate
19	Gasket
20	Sealing plug

No.	Designation
21	Seat bushing
22	Body
23	Stuffing box
24	Union nut
25	Spring

End connections

The equipment is available with the following end connections:

- ▶ Flanges
- ▶ Socket-weld ends
- ▶ Butt-weld ends

Name plate

The following items are indicated on the name plate:

- ▶ Manufacturer
- ▶ Type designation
- ▶ Nominal size
- ▶ Pressure rating
- ▶ Max. service temperature
- ▶ Direction of flow
- ▶ CE marking
- ▶ Date of manufacturing
- ▶ Material number

The following items are indicated on the equipment body:

- ▶ Material
- ▶ Batch code

Optional extras

The following add-on equipment is available:

- ▶ Assembly kit 335130 for retrofitting the drive of an existing MPA 26 or MPA 27 in a PA 46 or PA 47 to upgrade them to an MPA 46 or MPA 47 (guide bushing with washer and spacer disc)
- ▶ Diaphragm actuator 337866 for PA 4x (membrane actuator, spacer washer)
- ▶ TA programme controller for MPA 4x
- ▶ Retrofit kit 337980 proximity switch for MPA 4x (one limit switch):
 - ▶ Proximity switch with angle plug
 - ▶ Isolation amplifier
 - ▶ Bracket
 - ▶ 2 washers
 - ▶ 2 hex nuts
 - ▶ Follower pin
 - ▶ Installation & Operating Manual
- ▶ Retrofit kit 337946 proximity switch for MPA 4x (two limit switches):
 - ▶ 2 proximity switches with angle plug
 - ▶ 2 isolation amplifiers
 - ▶ 2 brackets
 - ▶ 4 washers
 - ▶ 4 hex nuts
 - ▶ Follower pin
 - ▶ Installation & Operating Manual
- ▶ Emergency lever for MPA:
 - ▶ Emergency lever
 - ▶ Clevis G 10 × 20, DIN 71752
 - ▶ Hex bolt

Application of European Directives

Pressure Equipment Directive

The equipment conforms to this Directive (see "Declaration of Incorporation" section) and can be used for the following media:

- ▶ Fluids of group 2

ATEX Directive

Pay attention to the instructions below if using in potentially explosive environments.

The equipment has classification: CE Ex II 2G/D c X.

For use in potentially explosive atmospheres in zones (surrounding atmosphere to Directive 1999/92/EC) 1, 2, 21 and 22, please read and observe the following information:

The sign "X" in the Ex label signifies that operation at an excessive surface temperature caused by the medium must be avoided. The equipment itself does not generate additional surface temperatures.

Once installed, static electricity may arise between the equipment and the connected system. During use in potentially explosive atmospheres, the discharge or prevention of possible electrostatic charging is the responsibility of the manufacturer or owner of the system. If there is a possibility that medium might escape, e.g. via actuating devices or leaks in screwed couplings, the manufacturer or owner of the system must take this into consideration when dividing the area into zones.

If the MPA has a pneumatic drive, if incorrectly discharged the exhaust air (compressed air) required for operation can lead to swirls of potentially explosive dust.

Task and function

Purpose

The equipment is designed for the manual or automatic discharge of boiler blowdown water with non-metallic solids from steam boilers.

Function

Type PA valves are intended for manual operation. For the blowdown process, the valve is opened fully by hand with the lever for around two to three seconds. The cone, which is compressed by a spring, is pushed out of the seat bushing. The sludge is discharged through the open valve. Slowly releasing the lever causes spring force to push the cone into the seat bushing (rapid closing). The valve is closed.

The position of the valve is indicated by the control pin. When the valve is open, the control pin is in its uppermost position; when closed, in its bottom position. Optional limit switches are available, with which the valve position can be transmitted to a control system.

Type MPA valves are equipped with a diaphragm actuator for automatic operation. Compressed air or pressurised water is used as the control medium. For blowdown, the valve is opened by the diaphragm actuator.

The opening signal can be sent by various controllers:

- ▶ The TA programme controller, see data sheet
- ▶ The continuous blowdown controller LRR 1-40, LRR 1-52, LRR 1-53, LRR 1-60, see data sheet
- ▶ The SPECTORcontrol with CAN bus

Storing and transporting the equipment

Attention!

Equipment can be damaged if stored or transported improperly.

- Close all openings with the sealing plugs or covers supplied with the equipment or use similar sealing covers.
- Protect the equipment against moisture and corrosive atmospheres.
- Please contact the manufacturer if the specified transport and/or storage requirements cannot be met.

Storing the equipment

- Please observe the following items when storing the equipment:
 - ▶ Do not store the equipment for more than 12 months.
 - ▶ Use the supplied sealing plugs or other suitable seal caps in order to seal off all openings of the equipment.
 - ▶ Protect the sealing surfaces and contact areas against mechanical damage.
 - ▶ Protect the equipment and all components against hard shocks and impacts.
 - ▶ Store the equipment only in closed rooms that meet the following environmental conditions:
 - ▶ Air humidity below 50 %, not condensing
 - ▶ Indoor air: clean, salt-free and non-corrosive
 - ▶ Temperature 5–40 °C.
- Make sure that all these requirements are always met when storing the equipment.
- Please contact the manufacturer if you cannot comply with the recommended storage conditions.

Transporting the equipment



DANGER

Risk of bruises if the equipment or component parts fall down.

- Use suitable lifting gear when moving or lifting the equipment and/or component parts.
- Make sure that the equipment cannot topple over.
- Make sure that nobody is standing below the lifted equipment.

The lifting gear must be of sufficient strength for the equipment including the actuator.

- Meet the requirements for storage also when transporting the equipment.
- Prior to transport seal off connections with sealing plugs.



If you do not have the sealing plugs supplied with the equipment use appropriate seal caps to seal off the connections.

- For short distances (only a few metres) you can transport the equipment unpacked.
- When transporting the equipment over larger distances use the original packaging.
- If you do not have the original packaging use a box that protects the equipment adequately against corrosion and physical damage.



For a short period of time the equipment may be transported even if the temperature is below 0 °C, provided that the equipment is completely empty and dry.

Mounting and connecting the equipment

Preparing installation

- Take the equipment out of the transport packaging.
- Check the equipment for transport damage.
- Contact the manufacturer if you detect any kind of shipping damage.

When supplied by the factory, the connections may be sealed off with sealing plugs.

- Remove sealing plugs before mounting the equipment.
- Keep the sealing plugs and the packing for further use.



DANGER

Personnel working on pipes are exposed to safety risks and may suffer severe injuries, poisoning or even loss of life.

- Make sure that no hot or hazardous fluid is in the equipment or the pipes.
- Make sure that the pipes upstream and downstream of the equipment are depressurised.
- Make sure that the installation is switched off and protected against unauthorised or unintended activation.
- Make sure that the equipment and the pipes have cooled down to room temperatures.
- Wear protective clothing that is suitable for the fluid and, if necessary, wear protective gear.

For more information on suitable protective clothing and safety gear refer to the safety data sheet of the fluid in question.

- Drain pipes until they are empty.
- Switch the installation off and protect it against unauthorised or unintended re-activation.
- To avoid waterhammer make sure that the pipe downstream of the equipment has a down gradient.
- If this is not possible provide other means to ensure draining.

Connecting the equipment



DANGER

Incorrectly connected equipment can result in accidents with extremely severe injuries or death.

- Make sure that only specialist personnel connect the equipment to the pipe.
- Make sure that the direction of flow in the pipe matches the flow direction arrow on the equipment.
- Make sure that the connected pipe does not subject the body to any stress (forces or torques) during installation and operation.

Specialist personnel must have knowledge and experience of the type of pipe connection used.

Attention!

Equipment will be damaged if the end connections are undersized.

- Make sure that the connections are strong and rigid enough to support the weight of the equipment and to withstand the forces that occur during operation.

- Make sure that the lever or emergency lever can move freely.

It must be possible to move the lever or emergency lever fully without touching other fittings.

Attention!

Risk of equipment damage or malfunction if incorrectly installed.

- Make sure the pipe between the steam generating unit and the equipment has a maximum length of two metres.
- To prevent water hammer, route the pipe after the equipment with a downhill gradient.
- For equipment with diaphragm actuator and pressurised water as the medium, make sure the supply line is made of corrosion-resistant material.

Note the following instructions for different installation positions:

- We recommend installing the equipment horizontally with the lever or diaphragm actuator at the top.
- If installing the equipment with an inclined or horizontal pressure fitting, provide support for the diaphragm actuator.

To allow easy access for routine servicing and exchanging components observe the indicated withdrawal distances and allow for clearances to adjacent installation parts.

- Make sure that the pipe system of the plant is clean.
- Make sure that the equipment is free from foreign matter.
- Install the equipment in the desired, permitted installation position.

For MPA valves, proceed as follows:

- Connect the control medium (compressed air, pressurised water) to the G 3/8 fitting of the diaphragm actuator with a maximum pressure of 8 bar.

i Refer to the control pressure diagram on page 46 to determine the required minimum pressure. Take account of the boiler pressure and nominal size.

- Make sure that the equipment is safely mounted and that all connections are made correctly.


Mounting the lever

The lever for type PA valves is supplied loose. Mount the lever before installing the valve.

i The lever or emergency lever is intended to be mounted on the right of the valve in the direction of flow. If you wish to fit the lever in another position, proceed as described on page 17.

Fit the lever as follows:

- Remove the retainer of the folding spring bolt (26) from the clevis (7).
- Pull the folding spring bolt out of the clevis.
- Push the lever (1) into the clevis through the hole in the spacer tube (3).
- Push the folding spring bolt through the holes in the lever and the clevis.
- Press the retainer of the folding spring bolt onto the clevis.



Positioning the lever



At the factory, the lever of the PA models and the emergency lever of the MPA models is fitted on the right of the equipment in the direction of flow. You may change the position of the lever to adapt your equipment to your on-site conditions. You can alter the position of the lever on the equipment by rotating the upper part 90°, 180° or 270°.

To do this, you need a new steel split pin to ISO 1234 with dimensions 2.5 × 40 mm.

You will find information on the required tools on page 23.

Proceed as follows:

- Remove the diaphragm actuator of type MPA equipment as described on page 28.
- Remove the retainer of the folding spring bolt (26) from the clevis (7).
- Pull the folding spring bolt out of the clevis.
- Pull the lever (1) out of the clevis.
- Remove the four hexagon head bolts (10).
- Remove the lock (2).
- Remove the pressure plate (9) and spacer tube (3).
- Pull the split pin (27) out of the pressure fitting (4).


You can now rotate the pressure fitting.

- Turn the pressure fitting anti-clockwise to the desired position.

Mount the equipment as follows:

- Insert a new steel split pin to ISO 1234, 2.5 × 40 mm, in the pressure fitting.
- Secure the split pin so it cannot fall out.
- Mount the spacer tube and the pressure plate.
- Place the lock on the correct hexagon head bolt.

- Insert the four hexagon head bolts through the holes in the pressure plate and into the holes in the body (22).
- Tighten the hexagon head bolts to a torque of 20 Nm.
- Install the diaphragm actuator of type MPA equipment as described on page 33.



Starting up the equipment



WARNING

Component parts that get hot during operation can cause burnings.

- Always wear thermally insulated and heat resistant safety gloves when operating the lever.



WARNING

Risk of crushing and burns from moving parts.


Type MPA equipment is driven and controlled remotely. They can therefore open or close without warning.

- Never reach into moving parts during operation.
- Wear sturdy, insulated and heat-resistant protective gloves to actuate the emergency lever.

- Actuate the equipment after the steam generating unit or pressure vessel has powered up, as described in the following section.

The equipment must automatically seal itself tightly.

- If the equipment is not tightly sealed, actuate it several times.
- Check whether medium is escaping from the inspection hole (6).
- If it is, retighten the stuffing box, as described on page 25.



Operating the equipment

The intervals required for the boiler blowdown must be determined for each individual steam boiler and have to be stipulated by the operator.

Operating the PA

Intermittent boiler blowdown



WARNING

Risk of burns from hot parts during operation.

- Wear insulated and heat-resistant protective gloves to actuate the lever.



WARNING


Risk of injury if the lever springs back into its starting position without being under control.

- Do not allow the lever to spring back in this way.
- Hold the lever firmly and move it slowly to its starting position.

To carry out blowdown, proceed as follows:

- Release the lever by turning the lock (2) anticlockwise as far as it will go.
- Press the lever (1) down as far as it will go, and hold it down for around two to three seconds.

The control pin (5) must be in its lowest position.



The pressed lever is under spring force.

- Return it to its starting position slowly.
- If the seal is leaking due to foreign bodies, perform blowdown several times.
- If the valve will still not close, dismantle it as described on page 26.
- Clean the valve components.
- Replace defective components.
- Lock the lever by turning the lock clockwise as far as it will go.

Opening the valve continuously

WARNING



Risk of burns from hot parts during operation.


- Wear insulated and heat-resistant protective gloves to actuate the lever.

WARNING



Risk of injury if the lever springs back into its starting position without being under control.

- Do not allow the lever to spring back in this way.
- Hold the lever firmly and move it slowly to its starting position.



To have the valve continuously open, proceed as follows:

- Release the lever by turning the lock (2) anticlockwise as far as it will go.
- Press the lever (1) down as far as it will go, and hold it down there.
- Turn the lock clockwise as far as it will go.
- Release the lever slowly until it is held in place by the lock.

The valve is now continuously open. The control pin (5) must be in its lowest position.

- To close the valve once more, proceed in the reverse order.

Operating the MPA

Do not work on the equipment while it is operating.



An optional emergency lever is available for MPA equipment. This allows you to actuate the equipment even without the diaphragm actuator.

- You will find information on retrofitting the emergency lever on page 35.



WARNING

Risk of crushing and burns from moving parts.


Type MPA equipment is driven and controlled remotely. They can therefore open or close without warning.

- Never reach into moving parts during operation.
- Wear sturdy, insulated and heat-resistant protective gloves to actuate the emergency lever.

- Before emergency operation of the equipment using the emergency lever, make sure the supply line to the actuator is shut off.
- For blowdown only, position the emergency lever (11) on the clevis (7) as shown.
- Press the emergency lever down and hold in this position for two to three seconds.

The valve is open.

- After blowdown, remove the emergency lever from the equipment.



After operation



DANGER

If the equipment is used in contaminated areas there is a risk of severe injuries or death caused by harmful substances in or on the equipment.

- Only qualified personnel are allowed to perform work on contaminated equipment.
- Always wear the protective clothing prescribed for contaminated areas when working on the equipment.
- Make sure that the equipment is completely decontaminated before carrying out any service work.
- Follow the pertinent instructions for handling the hazardous substances in question.



DANGER

Personnel working on pipes are exposed to safety risks and may suffer severe injuries, poisoning or even loss of life.

- Make sure that no hot or hazardous fluid is in the equipment or the pipes.
- Make sure that the pipes upstream and downstream of the equipment are depressurised.
- Make sure that the installation is switched off and protected against unauthorised or unintended activation.
- Make sure that the equipment and the pipes have cooled down to room temperatures.
- Wear protective clothing that is suitable for the fluid and, if necessary, wear protective gear.

For more information on suitable protective clothing and safety gear refer to the safety data sheet of the fluid in question.



DANGER

Risk of bruises when working on the equipment during operation.

- Switch off the equipment if you have to work close to any moving equipment parts.
- Make sure that the equipment cannot be switched on inadvertently.

Attention!

Damage to the equipment due to improper maintenance work.

- Make sure that only qualified personnel performs maintenance work.

A qualified person must be acquainted with and experienced in the following:

- Working on pressure equipment
- Lifting loads
- Assembling and disassembling the equipment
- The qualified personnel must observe and follow the instructions given in this operating manual and in the applicable documents.

Removing external dirt deposits

- Use fresh water and a cloth to remove dirt and contaminants from the equipment body.

Required tools for servicing

You will need the following tools for equipment servicing or maintenance:

- ▶ Size 13 combination spanner, DIN 3113, form B
- ▶ Size 16 combination spanner, DIN 3113, form B
- ▶ Size 17 combination spanner, DIN 3113, form B
- ▶ Size 18 combination spanner, DIN 3113, form B
- ▶ Size 19 combination spanner, DIN 3113, form B
- ▶ Size 28 combination spanner, DIN 3113, form B
- ▶ Size 32 combination spanner, DIN 3113, form B
- ▶ Size 36 combination spanner, DIN 3113, form B
- ▶ Size 41 combination spanner, DIN 3113, form B
- ▶ Torque wrench 1-12 Nm, ISO 6789
- ▶ Torque wrench 20-120 Nm, ISO 6789
- ▶ Torque wrench 80-400 Nm, ISO 6789
- ▶ Socket wrench 13 x 250, DIN 3112
- ▶ Punch 20 x 200, steel
- ▶ Punch 20 x 200, CuZn (brass)
- ▶ Pin punch 8 x 150, DIN 6450 C
- ▶ Piston-type grease gun
- ▶ Hammer

Tightening torques

Attention!

Malfunctions due to incorrect tightening torques.

- ▶ Tighten the screws, nuts and bolts listed in the following table only with the indicated torques.

Part	Torque
Sealing plug (20)	350 Nm
Union nut (24)	55 Nm
Hex nuts (10)	20 Nm
Hexagon head bolt	20 Nm
Diaphragm actuator (13)	120 Nm
Hex nuts (38)	5 Nm
Hex nuts (45)	12 Nm

Maintaining the equipment

Maintenance schedule

Interval	Component	Activity
1 month	Cone	Move cone by at least one complete stroke.
	Stuffing box seal	Check tightness via visually inspect via inspection hole. Replace a leaky stuffing box.
3 months	<ul style="list-style-type: none"> ▶ Connections ▶ Body gasket ▶ Cone guide 	Visual inspection for the following points: <ul style="list-style-type: none"> ▶ Tightness ▶ Cleanliness ▶ Wear Replace leaky or worn components. Remove dirt.
	<ul style="list-style-type: none"> ▶ Cone ▶ Seat bushing 	Measure the temperature to check the valve is closing perfectly. Replace leaky or worn components.
12 months	Actuator fastening	Check that actuator is securely seated on the equipment and inspect bolts. Tighten loose connections. Lubricate guide bushing.
36 months	Overall equipment	Check condition of inner parts. Replace faulty or worn components.

Retightening the stuffing box




WARNING

Risk of burns from hot parts during operation.

- Wear insulated and heat-resistant protective gloves to actuate the lever.

If medium escapes via the inspection hole (6), retighten the stuffing box.

- Insert a pin punch (28) through the hole in the spacer tube and into the hole (29) in the union nut.
- Turn the pin punch clockwise until the following conditions are satisfied:
 - ▶ The valve must be able to open and close.
 - ▶ No more medium escapes from the inspection hole.
- If you are unable to eliminate the leak, replace the stuffing box as described on page 29.



Lubricating the components

Attention!


Equipment may be damaged if unsuitable lubricant is used.

- Use only specified lubricants.

- Lubricate all moving parts of the equipment every three months.


You must lubricate the guide bushing of the MPA every 12 months. Use a lubricant with the same properties as WINIX 5000.

- Inject the lubricant in the lubricating nipple (15) using a piston-type grease gun.



Servicing the equipment and installing spare parts

You may exchange the following component parts in case of wear or damage:



No.	Designation	Stock code			
		PA 46/47	PA 48	MPA 46/47	MPA 48
19, 30, 31, 32, 33, 34	Stuffing box, comprising: <ul style="list-style-type: none"> ▶ Sealing ring D 38 × 44 ▶ Sealing ring D 52 × 60 ▶ Base bushing ▶ 1 packing ▶ 2 wipers ▶ Stuffing ▶ 15 disc springs 	335064	338094	335064	338094
17, 19, 21, 30, 31, 32, 33, 34	Cone, seat bushing and stuffing box DN 20, DN 25, DN 32 Stuffing box, comprising: <ul style="list-style-type: none"> ▶ Sealing ring D 38 × 44 ▶ Base bushing ▶ 1 packing ▶ 2 wipers ▶ Stuffing ▶ 15 disc springs 	335063	338093	335063	338093
17, 19, 21, 30, 31, 32, 33, 34	Cone, seat bushing and stuffing box DN 40, DN 50 Stuffing box, comprising: <ul style="list-style-type: none"> ▶ Sealing ring D 52 × 60 ▶ Base bushing ▶ 1 packing ▶ 2 wipers ▶ Stuffing ▶ 15 disc springs 	335065	338095	335065	338095
35	Control diaphragm	–		335131	
12, 36	Guide bushing with washer and spacer (conversion kit for diaphragm actuator of MPA 26)	–		335130	
12, 13	Diaphragm actuator with spacer (retrofit kit)	–		337866	
7, 11	Emergency lever, complete	–		337867	338073
–	Lever extension	338039	338075	–	


Removing the diaphragm actuator from MPA models

You can tell that a diaphragm is damaged from the following circumstances:

- ▶ The valve does not open perfectly
- ▶ You can hear the sound of escaping medium at the pressure relief hole on the underside of the diaphragm actuator
- ▶ Medium is escaping from the pressure relief hole on the underside of the diaphragm actuator.

Replace a damaged diaphragm as follows:


- Unfasten the medium connection (14) from the diaphragm actuator.
- Remove the diaphragm actuator (13) from the equipment.



Removing the lever and lock from PA models


Remove the lever as follows:

- Remove the retainer of the folding spring bolt (26) from the clevis (7).
- Pull the folding spring bolt out of the clevis.
- Remove the lever (1).
- Unscrew the hexagon head bolt (10) that is securing the lock.
- Remove the lock (2).
- Screw the hexagon head bolt back in.
- Tighten the hexagon head bolt to a torque of 20 Nm.



Removing the stuffing box and cone

- Remove the diaphragm actuator from type MPA equipment as described on page 28.
- Remove the lever from type PA equipment as described on page 28.
- Remove the hexagon head bolts (10) from the pressure plate.
- Remove the pressure plate (9).
- Remove the spacer tube (3).
- Pull the split pin (27) out of the pressure fitting and cone.
- Unscrew the pressure fitting (4) from the cone using a size 28 open-end spanner.
- Remove the spring (25).
- Unscrew the union nut (24) from the body using a size 32 open-end spanner.
- Remove the sealing plug (20) and gasket (19) from the body.
- Pull the cone (17) down and out of the body.
- Remove the stuffing box (23).




Replacing the stuffing box and inner parts

- Remove the stuffing box and cone as described on page 29.
- Replace the stuffing box with a new one.
- Mount the equipment as described on page 31.

Replacing the seat bushing and cone

When replacing the seat bushing and cone, you also need to replace the stuffing box.

- Remove the stuffing box and cone as described on page 29.
- Using a steel punch, knock the seat bushing (21) out of the body (22) as shown.



Attention!


Positioning the seat bushing incorrectly in the body can lead to malfunctions.

- Rotate the seat bushing so that two facing holes are in the direction of flow of the equipment.

- Turn the body (22) to the position shown in the illustration.

The seat bushing has four holes at right angles to one another (37).

- Insert the seat bushing (21) in the body so that two facing holes are in the direction of flow of the equipment.
- Using a brass punch, secure the seat bushing in the body as shown.



- Mount the equipment as described on page 31.

Replacing the diaphragm


You can tell that a diaphragm is damaged from the following circumstances:

- ▶ The valve does not open perfectly
- ▶ You can hear the sound of escaping medium at the pressure relief hole on the underside of the diaphragm actuator
- ▶ Medium is escaping from the pressure relief hole on the underside of the diaphragm actuator.

Replace a damaged diaphragm as follows:

- Unfasten the medium connection (14) from the diaphragm actuator.
- Slacken the hex nuts (39) on the diaphragm actuator.

- Remove the hexagon head bolts (38) from the top section of the diaphragm actuator (13).
- Lift the top section off the diaphragm actuator.
- Remove the diaphragm (35).



- Clean all parts of the diaphragm actuator before assembly.
- Insert the new diaphragm in the bottom section of the diaphragm actuator.
- Align the holes in the diaphragm with the holes in the bottom section.
- Mount the top section on the bottom section.
- Align the holes in the top section with the holes in the diaphragm and the bottom section.
- Insert the hexagon head bolts in the top section.
- Place the hex nuts on the hexagon head bolts.
- Tighten the hexagon head bolts crosswise to a torque of 5 Nm.

Attention!

Tightening threaded connections to the wrong torque can cause property damage or malfunctions.

- Always tighten threaded connections to the specified torque.

You will find an overview of permitted torques on page 23.

- Check whether medium is escaping from between the top and bottom sections of the diaphragm actuator.
- If leaks are present, tighten the bolts in the diaphragm actuator crosswise to the specified torque.
- If medium continues to escape, please contact the manufacturer.
- Grease the guide bushing as described on page 25.

Assembling the equipment



WARNING

Hot fluid spitting out of the equipment may cause injuries and scalding.

- Carry out a pressure test whenever the upper and lower body parts have been taking apart and fitted together again.

- Clean all component parts before re-assembly.
- Grind the cone into place using grinding compound.

The grinding compound must have the same properties as F400.

- Insert the parts of the stuffing box in the body as follows:


- ▶ Base bushing (30)
 - ▶ Wiper (31)
 - ▶ Packing 14 × 28 × 21 (32)
 - ▶ Wiper (31)
 - ▶ Stuffing (33)
 - ▶ 15 disc springs (34).
- Insert the disc springs in the position illustrated.
 - Coat the thread of the union nut with temperature-resistant lubricant.

The lubricant must have the same properties as OKS 217.

- Secure the stuffing box with the union nut.
- Insert the cone (17) in the body.
- Coat the thread of the sealing plug (20) with temperature-resistant lubricant.

The lubricant must have the same properties as OKS 217.

- Place the gasket (19) on the sealing plug.
- Screw the sealing plug and gasket into the body to a torque of 350 Nm.



- Coat the stuffing box thread with temperature-resistant lubricant.

The lubricant must have the same properties as WINIX® 2150.

- Position the cone so that the hole (37) is perpendicular to the direction of flow.
- Screw the union nut (24) onto the body to a torque of 55 Nm using a size 32 open-end spanner.
- Coat the contact surfaces of the spring (25) with temperature-resistant lubricant.

The lubricant must have the same properties as OKS 217.


- Position the spring on the union nut.
- Screw the pressure fitting (4) onto the cone using a size 28 open-end spanner.

The holes for the split pin in the pressure fitting and the cone must lie over one another.

- Insert the split pin (27) through the pressure fitting into the cone.
- Secure the split pin so it cannot fall out.
- Mount the spacer tube (3).
- Align the spacer tube so that the inspection hole (6) is facing the right.
- Mount the pressure plate (9) on the pressure piece.
- Insert the four hexagon head bolts (10) through the pressure plate and into the body.

In PA equipment, mount the lock (2) on the hexagon head bolt (10).

- Tighten the four hexagon head bolts crosswise to a torque of 20 Nm.
- Fit the lever on type PA equipment as described on page 16.
- Mount the diaphragm actuator in type MPA equipment as described on page 33.
- To check the equipment is functioning correctly, carry out several blowdown operations.
- Check whether medium is escaping from the inspection hole (6).
- If it is, retighten the stuffing box, as described on page 25.




Retrofitting the equipment

Mounting the diaphragm actuator

You can convert a manually operated PA to an MPA with diaphragm actuator. To do this, you require the diaphragm actuator with stock code 337866.

The diaphragm actuator contains the following components:

- ▶ Diaphragm actuator
- ▶ Spacer
- Remove the lever (1) as described on page 28.
- Remove the guide bushing (8).
- Push the folding spring bolt (26) through the hole in clevis (7).
- Press the retainer of the folding spring bolt onto the clevis.
- Slacken the hexagon head bolt (10) that is securing the lock.
- Remove the lock (2).
- Tighten the hexagon head bolt to a torque of 20 Nm.




You can now install the diaphragm actuator components.

- Place the spacer (12) on the pressure plate (9).
- Coat the connection sleeve (16) of the diaphragm actuator with temperature-resistant lubricant.

The lubricant must have the same properties as OKS 217.

- Screw the connection sleeve on the diaphragm actuator (13) into the pressure plate to a torque of 120 Nm.




- Connect the control medium (compressed air, pressurised water) to the G 3/8 fitting of the diaphragm actuator with a maximum pressure of 8 bar.
- To check the equipment is functioning correctly, carry out several blowdown operations.


Installing the diaphragm actuator of MPA 26 or MPA 27

You can retrofit the diaphragm actuator of an MPA 26 or MPA 27 in a PA 46 or PA 47. To do so, you will require the conversion kit with stock code 335130.

- Please also read and adhere to the instructions in the MPA 26/27 installation & operating manual.
- Slacken the hex nuts (39) on the diaphragm actuator.
- Remove the hexagon head bolts (38) from the top section of the diaphragm actuator (13).
- Lift the top section off the diaphragm actuator.
- Remove the diaphragm (35).



- Remove the washer (36) and guide bushing.
- Insert the new guide bushing and washer from the conversion kit in the hole in the bottom section of the diaphragm actuator.



- Clean all parts of the diaphragm actuator before assembly.
- Insert the new diaphragm in the bottom section of the diaphragm actuator.
- Align the holes in the diaphragm with the holes in the bottom section.
- Mount the top section on the bottom section.
- Align the holes in the top section with the holes in the diaphragm and the bottom section.
- Insert the hexagon head bolts in the top section.
- Place the hex nuts on the hexagon head bolts.
- Tighten the hexagon head bolts crosswise to a torque of 5 Nm.

Attention!

Tightening threaded connections to the wrong torque can cause property damage or malfunctions.

- Always tighten threaded connections to the specified torque.

You will find an overview of permitted torques on page 23.

- Connect the control medium (compressed air, pressurised water) to the G 3/8 fitting of the diaphragm actuator with a maximum pressure of 8 bar.
- Check whether medium is escaping from between the top and bottom sections of the diaphragm actuator.
- If leaks are present, tighten the bolts in the diaphragm actuator crosswise to the specified torque.
- If medium continues to escape, please contact the manufacturer.
- Grease the guide bushing as described on page 25.


Mounting the emergency lever

An emergency lever is available as an accessory for MPA models. This emergency lever enables you to operate the equipment even if the diaphragm actuator fails. In order to use the emergency lever, you must mount the supplied clevis on the pressure plate.

Proceed as follows:

- Insert the clevis (7) in the hole (41) in the pressure plate as shown.
- Fasten the clevis with the hexagon head bolt (40).
- Tighten the hexagon head bolt to a torque of 20 Nm.

You can now insert the emergency lever in the clevis when needed, as described on page 21.




Retrofitting the proximity switches

The optional proximity switches transmit the message that the end positions (open and closed) have been reached to a control system. You can retrofit either one proximity switch, or two. If you retrofit one proximity switch only (retrofit kit 337980), this is used to indicate whether the valve is closed. Two proximity switches indicate whether the valve is open or closed. To do this, you require the retrofit kit 337946 proximity switches for MPA 4x.

You require the following tools to fit proximity switches:

- ▶ Size 16 combination spanner, DIN 3113, form B
 - ▶ Size 17 combination spanner, DIN 3113, form B
 - ▶ Torque wrench 20-120 Nm, ISO 6789
- Push each of the two brackets (42) over a hexagon head bolt.



- Remove the normal control pin.
- Insert the supplied extended follower pin (5) in the hole for the control pin with thread-locking adhesive.


The thread-locking adhesive must have the same properties as Loctite® 620.

- Fit a hex nut (45) and shim (44) to the proximity switch (43), and insert in the bracket (41).
- Secure the proximity switch with a shim (44) and hex nut (45).
- Align the proximity switch as shown.

Dimension "X" must be 0.8 mm (0.032 ") minimum and 1.6 mm (0.063 ") maximum.

- Tighten the hex nuts to a torque of 12 Nm.
- Connect the proximity switch to the isolation amplifier.

You will find the relevant instructions in the manufacturer's installation & operating manual.



- Check the operation of the proximity switch, as described in the manufacturer's installation & operating manual.

Troubleshooting

Problem	Cause	Remedy
Fluid escapes (equipment is leaking).	The equipment or the body is damaged.	Replace the equipment with a new one.
Fluid escapes (equipment is leaking).	A gasket is damaged.	Replace the gasket with a new one. Clean gasket seating surfaces.
Fluid escapes (equipment is leaking).	The connections are not tight.	Provide the connections with leakproof seals.
Fluid escapes (equipment is leaking).	The stuffing box packing has not been tightened enough.	Tighten the stuffing-box packing hand tight. Make sure that the stuffing box packing does not impair the movement of the internals.
Fluid escapes (equipment is leaking).	The stuffing-box packing is damaged.	Replace the stuffing-box packing.
The equipment does not close fully.	The equipment contains dirt, deposits or foreign bodies.	Open and close the equipment several times quickly. Clean all inner parts. Replace damaged inner parts.
The cone moves jerkily or with difficulty, or is jammed.	Malfunctioning actuator or accessory.	Follow the instructions in the actuator or accessory installation & operating manual.
	Control system malfunction.	Follow the instructions in the control system installation & operating manual.
	The stuffing box hinders the stroke of the cone.	Slightly slacken the union nut. If the stuffing box continues to hinder the cone stroke, replace the stuffing box.

- If faults occur that are not listed above or cannot be corrected, please contact our Technical Service or authorized agency in your country.

Putting the equipment out of operation

Removing harmful substances



DANGER

If the equipment is used in contaminated areas there is a risk of severe injuries or death caused by harmful substances in or on the equipment.

- Only qualified personnel are allowed to perform work on contaminated equipment.
- Always wear the protective clothing prescribed for contaminated areas when working on the equipment.
- Make sure that the equipment is completely decontaminated before carrying out any service work.
- Follow the pertinent instructions for handling the hazardous substances in question.

Qualified personnel must have extensive experience with and a working knowledge of:

- ▶ pertinent rules and regulations concerning handling hazardous substances
- ▶ special regulations for handling the hazardous substances encountered on site
- ▶ using the required personal protective equipment (PPE) and clothing



CAUTION

Environmental damage may be caused by poisonous fluid residues.

- Before disposing of the equipment make sure that it is clean and free of fluid residues.
- For the disposal of all materials observe the pertinent legal regulations concerning waste disposal.

- Remove all residues from the equipment.
- For the disposal of all residues observe the pertinent legal regulations concerning waste disposal.

Removing the equipment



DANGER

Personnel working on pipes are exposed to safety risks and may suffer severe injuries, poisoning or even loss of life.

- Make sure that no hot or hazardous fluid is in the equipment or the pipes.
- Make sure that the pipes upstream and downstream of the equipment are depressurised.
- Make sure that the installation is switched off and protected against unauthorised or unintended activation.
- Make sure that the equipment and the pipes have cooled down to room temperatures.
- Wear protective clothing that is suitable for the fluid and, if necessary, wear protective gear.

For more information on suitable protective clothing and safety gear refer to the safety data sheet of the fluid in question.



CAUTION

Risk of injuries if the equipment falls down.

- When removing the equipment make sure the it is safely held in place and cannot fall down.

Suitable measures are for instance:

- ▶ Equipment that is not too heavy may be supported by a second person.
- ▶ For heavy equipment use suitable lifting equipment of sufficient strength.

- Detach the end connections of the equipment from the pipes.
- Put the equipment onto a suitable base.
- Store the equipment as described on page 14.

Re-using equipment after storage

Observe the following instructions if you want to remove the equipment and use it again somewhere else:

- ◆ Make sure that the equipment is free of any fluid residues.
- ◆ Make sure that all connections are in good condition and leak-free.
- ◆ If necessary re-work welded connections in order to ensure that they are in good working condition.
- Use the equipment only for its intended purpose and the service conditions for which it was specified.

Returning the valve

You can return the valve to your contractual partner.

- Make sure that all harmful substances are removed from the valve.
- Insert the stoppers in the connections.
- Observe the instructions in section "Transporting the equipment" from page 14.
- Pack the valve in its original packaging or in a suitable transport packaging.

The transport packaging must protect the valve from damage in the same way as the original packaging.

- Add the completed and signed decontamination declaration to the valve. The decontamination declaration must be attached to the packaging so that it is accessible from outside.
- Register the return delivery with your contractual partner before returning the valve.

Disposing of the equipment



CAUTION

Environmental damage may be caused by poisonous fluid residues.

- Before disposing of the equipment make sure that it is clean and free of fluid residues.
- For the disposal of all materials observe the pertinent legal regulations concerning waste disposal.


The equipment is made from the following materials:

Component	PA 46, PA 47, PA 48, MPA 46, MPA 47, MPA 48	
	DIN/EN	ASTM
Body ¹	1.0460	SA 105
Union nut ¹	1.0460	SA 105
Sealing plug ¹	1.7225	SA 193 B7
Sealing ring PA 46, PA 47, MPA 46, MPA 47	1.4301	–
Sealing ring PA 48, MPA 48	2.4068	–
Seat (hardened)	1.4034	–
Cone (hardened)	1.4122	–
Disc springs	1.8159	–
Spring	1.1200	–
Diaphragm actuator (MPA only)	Galvanised steel (1.0334)	–
Packing	PTFE yarn	PTFE yarn
Control diaphragm (MPA only)	EPDM	EPDM

¹ Pressure-bearing components

Technical data

Dimensions and weights



Dimension	PA	MPA
Ø D [mm]	–	235
H1 [mm]	See tables below	
H2 [mm]	DN 20-32: 55 DN 40/50: 80	DN 20-32: 55 DN 40/50: 80
H3 [mm]	250	360
H4 [mm]	350	–
H5 (space required for removing pressure plate) [mm]	25	25
X [mm]	PA 46/PA 47: 480 PA 48: 540	–
L [mm]	See tables below	

Leave sufficient space for servicing. When the valve is securely installed, a minimum space of 150 mm is required for removing or subsequently installing the actuator!

PA 46/MPA 46, PN 40 flange

DN	[mm]	20	25	32	40	50
	[in]	¾	1	1¼	1½	2
H1	[mm]	105	115	140	150	165
L	[mm]	150	160	180	200	230
Weight of PA	[kg]	8.8	9.3	10.6	13.8	15.6
Weight of MPA		13.2	13.7	15.0	18.2	20.0

PA 46/MPA 46, CLASS 150 flange

DN	[mm]	20	25	32	40	50
	[in]	¾	1	1¼	1½	2
H1	[mm]	98.4	107.9	117.5	127.0	152.4
L	[mm]	150	160	180	230	230
Weight of PA	[kg]	8.8	9.3	10.6	13.8	15.6
Weight of MPA		13.2	13.7	15.0	18.2	20.0

PA 46/MPA 46, CLASS 300 flange

DN	[mm]	20	25	32	40	50
	[in]	¾	1	1¼	1½	2
H1	[mm]	117.5	123.8	133.3	155.6	165.1
L	[mm]	150	160	180	230	230
Weight of PA	[kg]	8.8	9.3	10.6	13.8	15.6
Weight of MPA		13.2	13.7	15.0	18.2	20.0

PA 46/MPA 46, butt-weld end,**EN 12627 but with joint type ISO 9692-1 code no. 1.3 (30° chamfer), DIN 2559-2**

DN	[mm]	20	25	32	40	50
	[in]	¾	1	1¼	1½	2
For tube	[mm]	26.9×2.3	33.7×2.6	42.4×3.6	48.3×2.6	60.3×3.2
L	[mm]	200	200	200	250	250
Weight of PA	[kg]	8.2	8.2	8.9	12.0	13.3
Weight of MPA		12.6	12.6	13.3	16.4	17.7

PA 46/MPA 46, butt-weld end, ASME B16.25, Schedule 40, ASME B36.10

DN	[mm]	20	25	32	40	50
	[in]	¾	1	1¼	1½	2
For tube	[mm]	26.7×2.9	33.4×3.4	42.2×3.6	48.3×3.7	60.3×3.9
L	[mm]	200	200	200	250	250
Weight of PA	[kg]	8.2	8.2	8.9	12.0	13.3
Weight of MPA		12.6	12.6	13.3	16.4	17.7

PA 47/MPA 47, PN 63 flange

DN	[mm]	25	40	50
	[in]	1	1½	2
H1	[mm]	140	170	180
L	[mm]	190	220	250
Weight of PA	[kg]	9.3	13.8	15.6
Weight of MPA		13.7	18.2	20.0

PA 48/MPA 48, PN 100 flange

DN	[mm]	25	40	50
	[in]	1	1½	2
H1	[mm]	140	170	195
L	[mm]	190	220	250
Weight of PA	[kg]	9.9	14.4	17.8
Weight of MPA		13.7	18.2	22.2

PA 47/48 MPA 47/48, CLASS 600 flange

DN	[mm]	25	40	50
	[in]	1	1½	2
H1	[mm]	123.8	155.6	165.1
L	[mm]	216	216	250
Weight of PA 47	[kg]	9.3	13.8	15.6
PA 48		9.9	14.4	16.2
Weight of MPA		13.7	18.2	20.0

**PA 47/48, MPA 47/48, butt-weld end,
EN 12627 but with joint type ISO 9692-1 code no. 1.3 (30° chamfer), DIN 2559-2**

DN	[mm]	25	40	50
	[in]	1	1½	2
For tube	[mm]	33.7×2.6	48.3×2.6	60.3×3.2
L	[mm]	200	250	250
Weight of PA 47	[kg]	8.2	12.0	13.3
PA 48		8.8	12.6	13.9
Weight of MPA		12.6	16.4	17.7

PA 47/48 MPA 47/48, butt-weld end, ASME B16.25, Schedule 80, ASME B36.10


DN	[mm]	25	40	50
	[in]	1	1½	2
For tube	[mm]	33.4×4.5	48.3×5.1	60.3×5.5
L	[mm]	200	250	250
Weight of PA 47	[kg]	8.2	12.0	13.3
PA 48		8.8	12.6	13.9
Weight of MPA		12.6	16.4	17.7

PA 47/48 MPA 47/48, socket-weld end, DIN EN 12760, ASME B16.11, CLASS 3000

DN	[mm]	20	25	32	40	50
	[in]	¾	1	1¼	1½	2
For tube	[mm]	26.9×26.7	33.7×33.4	42.4×42.2	48.3×48.3	60.3×60.3
L	[mm]	200	200	200	250	250
Weight of PA 47	[kg]	7.4	7.7	8.6	11.4	12.6
PA 48		8.0	8.3	9.2	12.0	13.2
Weight of MPA		11.8	12.1	13.0	15.8	17.0

Flow diagram

The diagram shows the maximum flow of hot water.
 The flow is influenced by the differential pressure.
 The differential pressure is calculated from the pressure upstream of the equipment minus the pressure downstream of the equipment.




- A Flow
- B Differential pressure
- 1 DN 40, DN 50
- 2 DN 20, DN 25, DN 32

Control pressure for MPA

The medium for the diaphragm actuator is compressed air or pressurised water. The control pressure must not exceed 8 bar.

➤ Use the diagram below to determine the minimum control pressure based on the differential pressure.



- A Differential pressure
- B Control pressure
- 1 DN 20, DN 25, DN 32
- 2 DN 40, DN 50

Pressure & temperature ratings

Pressure & temperature ratings of PA 46 and MPA 46

Type of connection	PN 40 flange and EN butt-weld ends			
Pressure ¹ p [bar]	40.0	37.1	33.3	27.6
Temperature ¹ T [°C]	20	100	200	300

1 Operating limits for strength of body/cover to EN 1092-1

Operating data: Maximum pressure 31 [bar] at boiling temperature 237.5 [°C]

Type of connection	CLASS 150 flange			
Pressure ¹ p [bar]	19.6	17.7	13.8	10.2
Temperature ¹ T [°C]	38	100	200	300

1 Operating limits for strength of body/cover to ASME B16.34

Type of connection	CLASS 300 flange, ASME socket-weld ends and butt-weld ends			
Pressure ¹ p [bar]	51.1	46.6	43.8	39.8
Temperature ¹ T [°C]	38	100	200	300

1 Operating limits for strength of body/cover to ASME B16.34

Operating data: Maximum pressure 41.5 [bar] at boiling temperature 254 [°C]

Pressure & temperature ratings of PA 47 and MPA 47

Type of connection	PN 63 flange and EN butt-weld ends			
Pressure ¹ p [bar]	63.0	58.5	52.5	43.5
Temperature ¹ T [°C]	20	100	200	300

1 Operating limits for strength of body/cover to EN 1092-1

Operating data: Maximum pressure 46.7 [bar] at boiling temperature 261 [°C]

Type of connection	CLASS 600 flange, ASME socket-weld ends and butt-weld ends			
Pressure ¹ p [bar]	102.1	93.2	87.6	79.6
Temperature ¹ T [°C]	38	100	200	300

1 Operating limits for strength of body/cover to ASME B16.34

Operating data: Maximum pressure 55 [bar] at boiling temperature 271 [°C]

Pressure and temperature ratings of PA 48 and MPA 48

Type of connection	PN 100 flange and EN butt-weld ends			
Pressure ¹ p [bar]	100.0	97.3	83.3	69.0
Temperature ¹ T [°C]	-10/20	100	200	300

1 Operating limits for strength of body/cover to EN 1092-1

Operating data: Maximum pressure 70.0 [bar] at boiling temperature 287 [°C]

Type of connection	Flange CLASS 600, ASME butt-weld ends			
Pressure ¹ p [bar]	102.1	93.2	87.6	79.6
Temperature ¹ T [°C]	-29/20	100	200	300

1 Operating limits for strength of body/cover to ASME B16.5

Operating data: Maximum pressure 70 [bar] at boiling temperature 287 [°C]

Manufacturer's declaration

For more information on the Conformity Assessment according to European rules refer to our Declaration of Conformity or our Declaration by Manufacturer.

To download the current Declaration of Conformity or Declaration by Manufacturer go to www.gestra.com/documents or contact:

GESTRA AG

Münchener Straße 77

28215 Bremen

Germany

Telefon +49 421 3503-0

Telefax +49 421 3503-393

E-Mail info@de.gestra.com

Web www.gestra.de

This declaration is no longer valid if modifications are made to the equipment without consultation with us.



Agencies all over the world: www.gestra.de

GESTRA AG

Münchener Strasse 77

28215 Bremen

Germany

Phone +49 421 3503-0

Fax +49 421 3503-393

e-mail info@de.gestra.com

Web www.gestra.com

818447-03/05-2020_kx_mm (808565-04) © GESTRA AG Bremen Printed in Germany