



INSTALLATION AND MAINTENANCE INSTRUCTIONS

IM-8-601-US

April 2014


Vortex PhD Inline Vortex Flowmeters



Table of Contents

Section 1 – Product Introduction	3	Sensor Menu.....	30
Principle of Operation	3	Diagnose Group.....	30
Features	3	Reset Menu.....	30
Section 2 - Inspection	4	Service Menu	32
Equipment.....	4	Personalize Group	33
I.D. Plate	4	Password Menu	33
Calibration Sheet	4	Display Menu	33
EZ Logic Interface Map	4	Exiting Programming Submenus.....	34
Section 3 - Guidelines	5	Section 6 – Service	35
Piping.....	5	Integral Assembly	35
Straight Run Requirement.....	5	Remote Assembly.....	36
Meter Location	6	Sensor Removal.....	37
Mounting.....	7	General.....	37
General.....	7	Integral	37
Integral/ Remote Mounting	7	Remote.....	38
Section 4 – Installation	8	Sensor Replacement	38
Mechanical.....	8	Sensor Functionality Test	39
General.....	8	Trouble Shooting Chart	40
Flanged Style	8	Section 7 – Ordering	41
Wafer Style	9	Model and Suffix Codes	41
Remote Mount	9		
Wall Mount.....	9		
Pipe Mount	9		
Dimensions and Weights Integral	10		
Wafer Style	10		
Flanged Style.....	11		
Dimensions and Weights Remote.....	12		
Electrical	13		
General.....	13		
Jumper Settings.....	13		
Grounding	15		
D.C. Power and Signal Wiring.....	17		
110/220 V AC Power and Signal Wiring.....	18		
Remote Wiring.....	19		
Section 5 – EZ Logic Programming	20		
EZ Logic User Interface	20		
Interface Map.....	21		
Keypad Activation.....	22		
Movement Through Interface	22		
Altering Real Number Data	23		
Altering Preset Data.....	24		
Display Menu	25		
Accessing Programming Submenus	25		
Configure Group	26		
Basic Menu	26		
Output Menu.....	27		
Fluid Menu	30		

PRINCIPLE OF OPERATION



The Vortex PhD measures volumetric flow rate by detecting the frequency at which alternating vortices are shed from a bluff body inserted into the flow stream. These vortices are known as Von Karman vortices. The Vortex PhD calculates the flow velocity using the following equation:


$$Q = \frac{f}{K}$$

Where


Q = flow rate

f = vortex shedding frequency

K = calibration constant




The linear range of the flowmeter (where Strouhal number is constant) is for Reynolds numbers between 20,000 and 7,000,000. (The Strouhal and Reynolds numbers are dimensionless and characterize the flow conditions.)



Passage of a vortex causes a slight bow of a wing placed downstream of the bluff body. The bend is measured by a piezoelectric crystal sensor in contact with the top of the wing.

Microprocessor based electronics amplify, filter, and convert the sensor input into either a 4-20 mA or frequency output. Locally displayed flowrate and totals in user-selectable, engineering units are available.

FEATURES

- EZ Logic user interface
- Fully welded design
- 4-20 mA or frequency outputs
- Removable sensor under flow conditions
- Line sizes: 1 to 12"
-  approved – Class I, Division 2, Groups A, B, C, and D; and Dust-ignition Proof for Class II, Division 2, Groups F, and G hazardous (classified) locations.
- CSA approved – Class I, Division 1, Groups B, C, and D; Dust-ignition Proof for Class II, Division 1, Groups E, F, and G; and Class III hazardous locations.

SECTION 2 – INSPECTION

EQUIPMENT

Upon receiving your Spirax Sarco flowmeter, verify that all items on the packing list are present. In addition, check for possible shipping damage. Notify the freight carrier or your Spirax Sarco representative if any has occurred.

I.D. PLATES

A permanent identification plate is attached to your Vortex PhD. This I.D. plate contains information on model, serial/W.O., date, pressure, temperature, K-factor, and line location (if supplied by customer). Verify that this information is consistent with your order.

Standard

VORTEX PhD™ VORTEX SHEDDING FLOWMETER		↑ FIELD WIRING ↑ ↓ ELECTRONICS ↓	spirax sarco 2150 MILLER DR., LONGMONT, CO 80501
MODEL No.:		OUTPUT:	
TAG No.:		MWP:	PSIG @ 100°F
SERIAL/W.O. No.:		FLANGE RATING:	
DATE CODE:		K FACTOR:	
MADE IN USA		CAUTION: OPEN CIRCUIT BEFORE REMOVING EITHER COVER	SUPPLY: 24 VDC NOM, 42 VDC MAX AT 35 mA MAX PROCESS TEMP 752°F (400°C)

CSA

VORTEX PhD™ VORTEX SHEDDING FLOWMETER		↑ FIELD WIRING ↑ ↓ ELECTRONICS ↓	spirax sarco 2150 MILLER DR., LONGMONT, CO 80501
MODEL No.:		MWP:	MEGAPASCAL @ 25°C
TAG No.:		MWP:	PSIG @ 100°F
SERIAL/W.O. No.:		FLANGE RATING:	
DATE CODE:		K FACTOR:	
MADE IN USA		A SEAL SHALL BE INSTALLED WITHIN 45cm OF THE ENCLOSURE. CAUTION: OPEN CIRCUIT BEFORE REMOVING EITHER COVER. UN SCELLEMENT DOIT ÊTRE INSTALLÉ À MOINS DE 45cm DU BOITIER. ATTENTION: OUVRIR LE CIRCUIT AVANT D'ENLEVER LE COUVERCLE.	SUPPLY: (NEMA-4X) 24 VDC NOM, 42 VDC MAX AT 35 mA MAX. PROCESS TEMP: 752°F (400°C) MAX. AMBIENT TEMP: 140°F (60°C) CL I GP. B, C, D; CL II GP. E, F, G; CL III

FM

VORTEX PhD™ VORTEX SHEDDING FLOWMETER		↑ FIELD WIRING ↑ ↓ ELECTRONICS ↓	spirax sarco 2150 MILLER DR., LONGMONT, CO 80501
MODEL No.:		OUTPUT:	
TAG No.:		MWP:	PSIG @ 100°F
SERIAL/W.O. No.:		FLANGE RATING:	
DATE CODE:		K FACTOR:	
MADE IN USA		CAUTION: OPEN CIRCUIT BEFORE REMOVING EITHER COVER. FOR DIVISION 1, A SEAL SHALL BE INSTALLED WITHIN 18 INCHES OF THE ENCLOSURE.	SUPPLY: 24VDC NOM, 42VDC MAX AT 35 mA MAX PROCESS TEMP: 752°F (400°C) CL I DIV. 1 GP. B, C, D CL II DIV. 1 GP. E, F, G T4 AT 140°F MAX. AMBIENT CL I DIV. 2 GP. A, B, C, D CL II DIV. 2 GP. F, G NEMA 4X

110/220

VORTEX PhD™ VORTEX SHEDDING FLOWMETER		↑ FIELD WIRING ↑ ↓ ELECTRONICS ↓	EMCO 600 DIAGONAL HIGHWAY, LONGMONT, CO 80501
MODEL No.:		OUTPUT:	
TAG No.:		MWP:	PSIG @ 100°F
SERIAL/W.O. No.:		FLANGE RATING:	
DATE CODE:		K FACTOR:	
MADE IN USA		CAUTION: OPEN CIRCUIT BEFORE REMOVING EITHER COVER	SUPPLY: 110/220 VAC, 60 Hz MAX PROCESS TEMP 752°F (400°C)

CALIBRATION SHEET

Make sure to save the calibration data sheet when unpacking your new meter. The calibration sheet is important in setting up and monitoring the performance of your meter.

EZ LOGIC INTERFACE MAP


This map shows how the meter has been programmed at the factory. If your application changes, contact your Spirax Sarco representative for an updated map.

PIPING


Straight Run Requirements

Note: The straight run of piping must have the same nominal diameter as the meter.

Without Spirax Sarco Flow Rectifier



With Spirax Sarco Flow Rectifier




NOTE: D = flowmeter nominal diameter

PIPING
(continued)


Meter Location

Recommended meter locations are shown.




MOUNTING

General




Meter can be installed at any angle.

Integral/ Remote Mounting




Sensor and electronics can be mounted either integral or remote. For integral mounting, the temperature of the medium and/or the ambient temperature must be within the shaded area of the graph shown. It is possible to shield the electronics from the high temperature of the piping system with thermal insulation blankets.

Integral Mounting



Sensor and electronics are mounted as one unit.


Remote Mounting



If the temperature of the medium and/or the ambient temperature exceeds the parameters of the shaded area of the graph shown, remote mounting is necessary. There are two options for remote mounting, pipe or wall. The distance between sensor and the electronics must not exceed 50'. If remote mounting is ordered, mounting clamps and plate, and 33' of cable is supplied (50' of cable can be ordered as an option.)

MECHANICAL
(continued)

Wafer Style




Place the meter body between flanges; take care that the gaskets do not protrude into the bore. Install bolts. Tighten the bolts until snug; the bolts should be snug enough to hold the meter, yet loose enough to allow movement. Align the upstream end of the flowmeter by measuring from the outside edge of the flowmeter body to the outside diameter of the flange at several points. Adjust the position of the meter body until these measurements are within 1/16" of each other for meter sizes 2" and less, and 1/8" for larger sizes. Repeat for the downstream end of the meter. The alignment of the inlet to the meter is more critical than the outlet; i.e., if the piping system is warped such that both ends cannot be aligned, sacrifice the downstream alignment.

Tighten all bolts.


Remote Mount

Remote mount can be either pipe or wall mount. Secure the electronics conduit mounting bracket to either a 2" pipe or support structure. Position the conduit caps and the 3/4" NPT connections, so they can be easily accessed.



Wall Mount

For wall mounting, use 1/4" bolts (not supplied).




Pipe Mount

For pipe mounting, use the U-Bolts included with the remote mount kit. Note: For horizontal installation, mount transmitter below piping.

MECHANICAL
(continued)

Dimensions and Weights Integral
Wafer Style available in stainless steel 1-3" (25-80mm) only.



WAFER CONNECTION

Wafer connection is available in stainless steel 1-3" (25-80mm) only. The schedule of the mating pipe's internal diameter \geq dimension "D".

SIZE [in]	A [in]	B [in]	C [in]	D [in]	Approx Wt [lb]
1	10.8	2.2	4.1	0.957	13
1.5	10.5	3.1	4.1	1.500	14
2	10.8	3.6	5.0	1.939	17
3	11.5	5.0	7.0	2.900	32


English Weights & Dimensions: Wafer

SIZE [mm]	A [mm]	B [mm]	C [mm]	D [mm]	Approx Wt [kg]
25	274	55.9	104.6	24.3	5.9
40	267	78.5	104.6	38.1	6.4
50	274	91.9	127.0	49.3	7.7
80	292	127.0	177.8	73.7	14.5

Metric Weights & Dimensions: Wafer

MECHANICAL
(continued)

**Dimensions and Weights Integral
Flanged Style**



The number of bolt holes and their diameter depend upon ANSI or DIN standard.

Notes:

1. The schedule of the mating pipe's internal diameter \geq dimension "C".
2. N/A = Not Available, C/F = Consult Factory

SIZE [in]	A [in]	B [in]	C [in] Stainless Steel		C [in] Carbon Steel		C [in] Hastelloy	Approx. Wt [lb]		
			150# 300# Flanges	600# Flange	150# 300# Flanges	600# Flange	150# 300# 600# Flanges	150# Flange	300# Flange	600# Flange
1	10.7	7.6	0.957	0.957	N/A	N/A	0.957	18	20	20
1.5	10.7	8.1	1.500	1.500	N/A	N/A	1.500	22	28	28
2	13.2	8.5	1.939	1.939	N/A	N/A	1.939	31	36	36
3	13.8	9.0	2.900	2.900	N/A	N/A	2.900	51	60	60
4	14.3	9.5	3.826	3.826	N/A	N/A	3.826	55	72	99
6	15.3	13.6	5.761	5.761	5.761	5.761	C/F	92	116	140
8	16.3	18.5	7.625	7.625	7.625	7.625	C/F	144	182	220
10	17.4	18.5	10.020	9.750	10.020	9.750	C/F	180	260	440
12	18.4	18.5	12.000	11.750	11.938	11.374	C/F	265	365	535


English Weights & Dimensions: Flange

SIZE [mm]	A [mm]	B [mm]	C [mm] Stainless Steel		C [mm] Carbon Steel		C [mm] Hastelloy	Approx. Wt [kg]		
			PN 16 PN 40 Flanges	PN 64 Flange	PN 16 PN 40 Flanges	PN 64 Flange	PN 16 PN 40 PN 64 Flanges	PN 16 Flange	PN 40 Flange	PN 64 Flange
25	272	192.0	24.3	N/A	N/A	N/A	24.3	8.2	9.1	N/A
40	272	206.2	38.1	N/A	N/A	N/A	38.1	10.0	12.7	N/A
50	335	215.9	49.3	49.3	N/A	N/A	49.3	14.1	16.3	16.3
80	350	228.6	73.7	73.7	N/A	N/A	73.7	23.1	27.2	27.2
100	363	241.3	97.2	97.2	N/A	N/A	97.2	25.0	32.7	44.9
150	389	346.2	146.3	146.3	146.3	146.3	C/F	41.7	52.6	63.5
200	414	469.9	193.7	193.7	193.7	193.7	C/F	65.3	82.6	99.8
250	442	469.9	254.4	247.7	254.5	247.7	C/F	81.6	117.9	199.6
300	467	469.9	304.8	298.5	303.2	288.9	C/F	120.2	165.6	242.7

Metric Weights & Dimensions: Flange

MECHANICAL
(continued)

Dimensions and Weights
Remote




ELECTRICAL

General

To avoid personal injury, property damage from electrical shock, contact with live electrical systems or from combustible material, or contact with explosive gases which can be ignited by electrical arcing: wiring and conduit must be installed in accordance with national, local laws, standards, codes, and industry practices. Furthermore, for explosion proof applications, install a suitable conduit seal no more than 18 inches from the conduit connection.

Jumper Settings

The flowmeter jumpers are factory configured for each specific application. Additional configuration should not be required except for application changes. Jumper settings can be accomplished by exposing the filter (base) board located in the electronics conduit; *before* any disassembly is done, the user should be properly grounded using proper electrostatic discharge (ESD) precautions. To expose the filter board, remove conduit cap and unscrew the display board screws. Gently remove the display board from the electronics stack. Disregard previous if your flowmeter does not have a display. Unscrew the hex standoff bolts, and remove the electronics stack from the base board.




ELECTRICAL
(continued)

Standard Jumper Settings

Jumper positions JP(1-4), (5-8), and (9-18) indicate input signal parameters for each size and fluid type. Jumper positions JP1 and JP2 are pulse output driver jumpers. JP1 is installed at the factory .

Standard Filter Board



JP (5-8)

JP (1-4)

JP (9-18)

JP2

JP1


Pulse Driver Jumpers

Pulse Driver (JP1/JP2) Configuration Table
Pulse and analog output (JP1) installed at factory
Pulse output only (JP2)

Filter Settings For Liquids	Filter Settings For Gases	Amplitude Settings For Liquids And Gases	Dual Amplitude Settings For Liquids And Gases
<div>JP (1-4) JP (5-8) 1"</div> <div>JP (1-4) JP (5-8) 1.5"</div> <div>JP (1-4) JP (5-8) 2"</div> <div>JP (1-4) JP (5-8) 3"</div> <div>JP (1-4) JP (5-8) 4"</div> <div>JP (1-4) JP (5-8) 6"</div> <div>JP (1-4) JP (5-8) 8"</div> <div>JP (1-4) JP (5-8) 10"</div> <div>JP (1-4) JP (5-8) 12"</div>	<div>JP (1-4) JP (5-8) 1"</div> <div>JP (1-4) JP (5-8) 1.5"</div> <div>JP (1-4) JP (5-8) 2"</div> <div>JP (1-4) JP (5-8) 3"</div> <div>JP (1-4) JP (5-8) 4"</div> <div>JP (1-4) JP (5-8) 6"</div> <div>JP (1-4) JP (5-8) 8"</div> <div>JP (1-4) JP (5-8) 10"</div> <div>JP (1-4) JP (5-8) 12"</div>	<div>JP (9-18) 1"</div> <div>JP (9-18) 1.5"</div> <div>JP (9-18) 2"</div> <div>JP (9-18) 3"</div> <div>JP (9-18) 4"</div> <div>JP (9-18) 6"</div> <div>JP (9-18) 8"</div> <div>JP (9-18) 10"</div> <div>JP (9-18) 12"</div>	<div>JP (9-18) 1"</div> <div>JP (9-18) 1.5"</div> <div>JP (9-18) 2"</div> <div>JP (9-18) 3"</div> <div>JP (9-18) 4"</div> <div>JP (9-18) 6"</div> <div>JP (9-18) 8"</div> <div>JP (9-18) 10"</div> <div>JP (9-18) 12"</div>


ELECTRICAL
(continued)

Grounding



Meter

To ensure proper electrical noise rejection, connect a ground strap (size 8 AWG or larger wire) from the ground screw (attached to the outside of the electronics enclosure) to a known earth ground (not the pipe).




Power Supply

Shielded cable should be at least 18 AWG or larger. Connect wire from shielded cable to earth ground at the power supply. Insulate the other end of the wire (from electrical conduit) at the meter.

ELECTRICAL
(continued)


Accessing Field Wiring Terminals



The field wiring terminal for power and signal wiring may be accessed by removing the field wiring conduit.

D.C. Power and Signal Wiring


The Vortex PhD™ may be operated using a 24 VDC power supply. It is unique in its ability to supply both the 4-20 mA and pulse output, simultaneously. The installation of jumpers JP1 and JP2 on the base board determines the pulse output. JP1 is installed at the factory; the other configurations represent typical field wiring diagrams.



Analog Output (JP1 installed or no jumpers)
Scalable 4-20 mA output, 2 wire principle. A load resistor may be installed on the supply or return line. Permissible load resistance values are shown in the graph.

ELECTRICAL
(continued)

D.C. Power and Signal Wiring (continued)



**Simultaneous Pulse and Analog Output
(JP1 installed)**


Simultaneous 4-20 mA and pulse output for a high impedance electronic counter. Load resistor in the supply line. Pulse output will vary from:

$$0-1 \text{ V to } V_{\text{pulse}} = V_s - (I \cdot R_{\text{load}})$$

Note: Load resistor may also be placed in the return line. Pulse output will vary from $V_{\text{pulse}} = (I \cdot R_{\text{load}}) + 1$ to V_s .

where:

- V_{pulse} = pulse output amplitude
- V_s = power supply voltage
- I = current (4-20 mA)
- R_{load} = load resistance (see graph)



Pulse Output Only (JP2 installed)

This option is for pulse output only using a low impedance electromechanical counter. V_{pulse} will vary from:


$$0-1 \text{ V to } V_{\text{pulse}} = V_s \left(\frac{R_c}{R_c + 6800} \right)$$

$$\text{Note: } R_c \geq 6800 \left(\frac{V_c}{V_s - V_c} \right)$$

Note:

Where:

- V_{pulse} = pulse output amplitude
- R_c = counter impedance
- V_s = power supply voltage
- V_c = minimum required voltage to trip counter



Pulse Output Only (No Jumpers)

This is an open collector pulse output using a high impedance electronic counter. V_{pulse} will vary from:

$$0-1 \text{ V to } V_{\text{pulse}} = V_s \left(\frac{R_c}{R_c + R_{\text{pulse}}} \right)$$

$$\text{Note: } R_{\text{pulse}} \geq \left(\frac{V_s}{0.16} \right)$$

Note:


Where:

- V_{pulse} = pulse output amplitude
- R_c = counter impedance
- V_s = power supply voltage
- V_c = minimum required voltage to trip counter

ELECTRICAL (continued)


110/220 VAC Power and Signal Wiring

The Vortex PhD™ may be operated using a 110 or 220 VAC power supply. The power supply board converts the 110/220 VAC to 24 VDC. It is unique in its ability to supply both the 4-20 mA output and the pulse output simultaneously. The installation of jumpers JP1 and JP2 on the bottom of the 110/220 VAC power supply controls the output selection. JP1 is installed at the factory.



Analog Output (JP1 installed or no jumpers)

Scalable 4-20 mA output, 2 wire principle. Load resistor may be installed on supply or return line. R_{load} must be 250 Ω .




Simultaneous Pulse and Analog Output (JP1 installed)

Simultaneous 4-20 mA and pulse output for a high impedance electronic counter. Load resistor in the supply line. Pulse output will vary from:

$$0-1 \text{ V to } V_{pulse} = 24 - (I \cdot R_{load})$$

where:

$$\begin{aligned} V_{pulse} &= \text{pulse output amplitude} \\ I &= \text{current (4-20 mA)} \\ R_{load} &= \text{load resistance (250 } \Omega) \end{aligned}$$



Pulse Output Only (JP2 installed and analog jumper installed)

This option is for pulse output only. V_{pulse} will vary from:

$$0-1 \text{ V to } V_{pulse} = 24 \left(\frac{R_c}{R_c + 6800} \right)$$

$$\text{Note: } R_c \geq 6800 \left(\frac{V_c}{24 - V_c} \right)$$

Note:

$$\begin{aligned} \text{Where: } V_{pulse} &= \text{pulse output amplitude} \\ R_c &= \text{counter impedance} \\ V_c &= \text{minimum required voltage to trip counter} \end{aligned}$$

ELECTRICAL (continued)


Remote Wiring

Output wiring from the remote electronics is identical to the integral electronics. However, the wiring from the remote electronics conduit to the electrical junction box is not, and must be performed in the field.


Connect the remote cable to the terminal block in the junction box as shown. If nonconductive conduit is used, attach a ground strap from the ground screw on the remote electronics conduit to the ground screw on the sensor conduit.

Run rigid conduit from the conduit entry on the remote conduit to the conduit mounted on the meter body.


Note: If the remote cable is cut to a shorter length, insulate shield with tape at electrical junction box.



FIELD WIRING SIDE



ELECTRONICS SIDE



SECTION 5 – EZ LOGIC PROGRAMMING


EZ LOGIC USER INTERFACE

General


The EZ Logic User Interface is a menu driven interface, consisting of the top display menu, and nine programming submenus. The submenus are called: Basic, Output, Fluid, Sensor, Reset, Service, Password, HART, and Display. These submenus are grouped by functionality.

The first group is called Configure; the second, Diagnose; and the third, Personalize. The Configure group is comprised of the Basic, Output, Fluid, and Sensor submenus. These submenus configure the flowmeter for operation in a specific application. The Diagnose group consists of the Reset and Service submenus each containing information relating to flowmeter maintenance. Finally, the Personalize group contains the Password, HART and Display submenus. This group allows the user to customize the flowmeter by choosing display parameters or changing the password.


Each group has its own icon: Configure "**C**", Diagnose "**D**", and Personalize "**P**". These icons appear in the upper (or lower), right hand corner of the display to help the user identify their location within the interface map.




INTERFACE MAP



KEYPAD ACTIVATION



There are two ways to access the interface map from the keypad. The first is to remove the conduit cap, and depress the membrane keys using your fingers.




The second method is to use the magnet wand. This allows the keys to be activated through the conduit cap, and is required to maintain the explosion proof rating.

To activate keys, place the magnetic wand on the targeted area and remove. Note: magnetic wand is only supplied, as a standard tool, with the explosion proof meters.

Caution: Do *not* place magnet wand near magnetically sensitive items, such as: credit cards, card keys, etc...

MOVEMENT THROUGH
INTERFACE




The interface was designed to be simple. For example, if you would like to go right, across the column headings, press the right arrow key.

To move up or down through each column, use the up or down arrow key. Note: each column is set up as a loop; once you reach the bottom (using the down arrow key), pressing the down arrow key again will move you to the top of the column heading.

The enter key is used to exit the programming submenus.

ALTERING REAL NUMBER DATA

Keys are also used to alter data within a selected block within a submenu. Note: below is an example of only one of many parameters that can be altered in a block; refer to submenu descriptions for more information.



In order to alter data, press the enter key. A cursor will appear under the first digit. Note: blinking icon will disappear.

Press the right arrow key to move the cursor to the desired digit.


Pressing the up-arrow key will change the value of the digit. Possible choices for each digit are: 0-9, blank space, or a decimal point.

The values may also be changed by pressing the down arrow key.

After the desired changes are made, press the enter key to store the new value; the blinking icon will reappear.

ALTERING PRESET
DATA

Some blocks in the programming submenus are for choosing user-selectable, engineering units. The example below illustrates how to select, and change (in the submenu block called "Flw unit") units for flow rate. (For a complete list of specific submenu options, refer to the submenu descriptions.)




Press the enter key; the blinking *cursor* will appear (the blinking *icon* will disappear).

Press the up-arrow key to change the volume unit (in the numerator).

To change the time unit (in the denominator), press the down-arrow key.

After the desired changes are made, press the enter key to store the new value; the blinking *icon* will reappear.

DISPLAY MENU



The display menu will appear as soon as the meter is powered up. The display menu has four options.

Continuously displays the actual flow rate, in the units selected in the "Flw unit" submenu.

Continuously displays the totalized flow, in the units selected in the "Tot unit" submenu.


Displays the percentage of full scale flow, and a corresponding bar graph.

The electronics monitor and record errors that may occur during operation. Push the right-arrow key to scroll through error codes; see the troubleshooting section for error code messages.

ACCESSING PROGRAMMING SUB-MENUS

In order to enter the programming submenus, the user must hold down the right-arrow key for 2 seconds; then enter the correct password to access the submenus. If the correct password is entered, the display will read "Full Access." If an incorrect password is entered, the display will read "Read Only," and the user will not be able to alter any programming.

The flowmeter comes from the factory without a password, therefore, holding down the right-arrow key will allow "Full Access." Refer to the Personalize group to add, or change, the password. Note: When in the programming submenus, the meter will be "off line." The last values of the totalizer and the flowrate (before going "off line") will be stored until the user returns to the display menu.



CONFIGURE GROUP

Basic
↓ menu **C**

Flow Unit	Flw unit gal/min
Totalizer Unit	Tot unit 1X gal
Maximum Flow	Max flow 37.4025
Minimum Flow	Min flow 1.87013
M-Factor	M-factor 0150

Meter size	M-Factor
0.5"	320
1"	255
1.5"	160
2"	125
3"	85
4"	45
6"	30
8"	30
10"	30
12"	30

The units chosen for flow rate in this block will show in the display menu. Also, the engineering units chosen here will be the same for the max flow and min flow used to scale the 4-20 mA and frequency output.

Arrow up to scroll through the volume units, down to scroll through the time units. Possible flow units : gallons, bbl, cm³, liters, m³, lb, tons, grams, kilograms, metric tons, standard ft³, normal m³, ft³, and in³. Possible time units: seconds, minutes, hours, and days.

The totalizer units chosen will show in the display menu. The counting of the totalizer can be changed by increasing, or decreasing, the multiplier. Up-arrow key to scroll through multipliers, down-arrow key to scroll through units. Possible multipliers: x1, x10, x100, x10³. Possible units: gallons, bbl, cm³, liters, m³, lb, tons, grams, kilograms, metric tons, standard ft³, normal m³, ft³, and in³.

Maximum flow value sets the 20 mA point, and the scaled frequency output. Note: The units for flow rate are selected in the "Flw unit" block.


Minimum flow sets the cutoff value where the output drops to 4 mA, and/or the scaled frequency output drops to 0 Hz. This value *cannot* be programmed below the published minimum flow rate of the meter.

M-factor sets the signal input filter. The M-factor is factory determined, and programmed, during calibration. However, for best performance, the M-factor should be reset during actual flow conditions.

Note: Before the M-factor can be reset, the flowmeter must be operating at least 1/10 of the meter's maximum flow rate (3.2 ft/sec for liquids, 26 ft/sec or more for gases).

To reset the M-factor, change the value to 0000; press the enter key. Wait approximately 5 seconds; the meter will automatically reset the M-factor. If the sensor input signal is too weak (due to the flow rate not being at least 1/10 of the meter's maximum flow rate) the electronics will *not* auto set the M-factor. The display will read "Too Low NOT SET" (for 1 second), and the previous M-Factor will be displayed.


These are **nominal** M-factor settings for different size meters. These numbers are only to be used as a reference guide. Each meter will have an M-factor that will vary slightly from these nominal values.

CONFIGURE GROUP
(continued)


(continued)

Noise LevelNoise Lv
010 %

This value sets the no flow, cutoff level. If the input signal drops below this value, the meter will not output or display a flow rate. The Noise level can be set from 1-100%. 0% represents no flow, 100 % represents 100% of the meter's maximum flow (this is not the maximum flow for the specific application programmed in the Basic Menu). If the value is programmed as 000, the meter will perform an automatic Noise level setting. After 5 seconds, the meter will return with the new calculated value. For best results, auto set the noise level with the pump on, and down stream valve closed to ensure no flow conditions. **The programming assumes there is NO flow in the pipe when the auto setting is made, otherwise, the meter will not display any output.**

**Analog Output**4-20 mA
On

Linear analog output set by min. and max. flow. Toggle on/off with the up and down-arrow keys.

4-20 TC
05 sec**Analog Output Time Constant**

Dampens the analog output. Analog time constant can be set from 0-99 sec.

Output Zero TimeZero TM
0 sec

Number of seconds, before output drops to zero, after the actual flow drops below the programmed minimum flow.

Frequency/Pulse Output SetupFreq out
Scl freq

Type of Frequency/Pulse output can be selected here. The possible output options are: scaled frequency, vortex frequency, direct frequency, pulse -, pulse +, and transition. The frequency/pulse output can be disabled by choosing "off" as the output selection. The display changes depending on output option selected; refer to EZ Logic Map.

CONFIGURE GROUP
(continued)

Output
↓ Menu C

(continued)

Scaled Frequency*
Output

Freq out
Scl freq

Freq max
10 kHz

Freq TC
05 sec

Vortex Frequency*
Output

Freq out
Vor freq

Freq TC
05 sec


Direct*
Frequency Output

Freq out
Direct

*When connecting any Spirax Sarco flow processor to the Vortex PhD meter, select vortex frequency (Vor freq) as the OUTPUT SETUP.

Note: When connecting the Vortex PhD flowmeter to an Spirax Sarco flow processor, select vortex frequency (Vor freq) as the OUTPUT SETUP.
Linear output frequency scaled between minimum and maximum flow, and maximum output frequency (see graph below).

Maximum Output Frequency
Sets the maximum output frequency. Available settings: 500 Hz, 1 kHz, 3 kHz, 5 kHz, or 10 kHz.



Frequency Output Time Constant
Dampens the frequency output. Frequency output time constant can be set from 0-99 sec.

Output frequency will be the true shedding frequency with a 50% duty cycle, where:

$$\text{FLOW} = \frac{\text{Freq}}{\text{K} - \text{Factor}} \left(\frac{\text{ft}^3}{\text{s}} \right)$$

Frequency Output Time Constant
Frequency output time constant can be set from 0-99 sec; default is 5 seconds.



Output frequency will be the true shedding frequency. This is an instantaneous representation of the flow, where:

$$\text{FLOW} = \frac{\text{Freq}}{\text{K} - \text{Factor}} \left(\frac{\text{ft}^3}{\text{s}} \right)$$

CONFIGURE GROUP
(continued)

Output
↓ Menu **C**

(continued)

Pulse -	Freq out Pulse -	Per puls 10,000	Per pulse With this output selection, one negative pulse is generated each time the totalizer increments. The increment is set by the Per pulse and pulse unit. 	
		Puls unt ft³		Pulse Unit Possible units: gal, bbl, cm³, lit, m³, lb, tons, grams, kilograms, metric tons, standard ft³, normal m³, ft³, and in³.
		Puls with 50 mSec		Pulse Width Possible pulse width settings: 5 msec, 50 msec, 500 msec, 1 sec, and 5 sec. Note: Programmed pulse width must be less than the actual output signal pulse width, at maximum flowrate.
	Freq out Pulse +	Per puls 10,000	Per pulse With this output selection, one positive pulse is generated each time the totalizer increments. The increment is set by the Per pulse and pulse unit. 	
		Puls unt ft³		Pulse Unit Possible units: gal, bbl, cm³, lit, m³, lb, tons, grams, kilograms, metric tons, standard ft³, normal m³, ft³, and in³.
		Puls with 50 mSec		Pulse Width Possible pulse width settings: 5 msec, 50 msec, 500 msec, 1 sec, and 5 sec. Note: Programmed pulse width must be less than the actual output signal pulse width, at maximum flowrate.
	Freq out Transit	Per puls 10,000	Per pulse With this output selection, the totalizer increments with each transition from low state to high state. The increment is set by Per pulse and Pulse unit.	
		Puls unt ft³		Pulse Unit Possible units: gal, bbl, cm³, lit, m³, lb, tons, grams, kilograms, metric tons, standard ft³, normal m³, ft³, and in³. Actual fluid density of your application, in lbm/ft³.

CONFIGURE GROUP

(continued)

Fluid
↓ Menu **C**

Fluid Density	Density 62.4000
Reference Density	Ref Den 0.000000
Density Range	Dens Rng 1.5
Fluid Viscosity	Viscos 1 cP
Fluid Temperature	Temp 0100° F

The reference density is programmed in lbm/ft³. It is the density of the application fluid at standard conditions, and is used for displaying and scaling standard or normal flow rates. If the reference density is set to zero, it will default to the fluid density value.

The default setting is 1.5 or the user may input the maximum density of the application fluid, divided by the minimum density.

The default setting is 1.5 or the user may input the maximum density of the application fluid, divided by the minimum density.

The fluid viscosity used to calculate the Reynolds number.

The nominal fluid temperature. It is used to compensate for changes in the internal diameter of the pipe, by shifting the K-Factor.

Sensor
↓ Menu **C**

Size	Size 1 in.
Calibration Factor	Meter K 2400.00
Reynolds Number	Re #1 0.000
K-Factor	Ke #1 0.000
Serial	000000 – 000 WO#
Tag Number	Tag # 00000000

Toggle through 1" to 12" size meters.

Calibrated meter K-factor in pulses/ft³. (The K-factor value is also located on the meter serial tag I.D.)

Reynolds #1 – 8 utilized for linearization purposes. When set to zero – Meter K is used.

K-Factor #1 – 8 utilized for linearization purposes. When set to zero – Meter K is used.

Meter body serial/work order number (view only). (Also located on the meter serial tag I.D.)

Meter tag number (view only).

DIAGNOSE GROUP

Reset
↓ Menu **D**

Totalizer Reset	Total Reset N
-----------------	------------------

User can reset the totalizer by selecting yes (Y).

DIAGNOSE GROUP

(continued)

Reset
↓ Menu **D**

(continued)

Set Defaults

Defaults
No

User can reset the meter to the original programmed defaults, shown below. **Note: choosing "Yes" will erase any changes made to the meter programming.**

Programmed Defaults								
Basic menu C	Output menu C	Fluid menu C	Sensor menu C	Reset menu D	Service menu D	Password menu P	HART menu P	Display menu P
↑ ↓	↑ ↓	↑ ↓	↑ ↓	↑ ↓	↑ ↓	↑ ↓	↑ ↓	↑ ↓
Flw unit gal/min	4-20 mA On	Density 62.4000	Size 1 in.	Total Reset No	Sub Freq 0000 Hz	Set Pass 0000	HART On	FlowRate Show
Tot unit x1 gal	4-20 TC 05 sec	Ref Den 0.000000	Meter K 2400.00	Defaults No	4-20 Out 0%			Total Show
Max flow -	Zero TM 0 sec	Dens Rng 1.5	000000 – 000 WO#		Freq Out 00000 Hz			BarGraph Show
Min flow -	Freq out Vor Freq	Temp 70°F	Tag # 00000000		4 mA Cnt 1270			Err Code Show
M-factor 0300					20mA Cnt 6900			TotReset Yes
Noise Lv 003 %					Version 2.30			Dsply TC 05 Sec
								Scan Off
								Flow Res 3 digits

Vor freq
Freq TC
05 Sec

Service
↓ Menu **D**

Substitute
Frequency

Sub freq
0000 Hz

Simulated Analog
Output

4-20 Out
0.000%

Simulated
Frequency
Output

Freq out
Scl freq

This frequency will simulate a vortex shedding frequency for the display and the output. Note: this value must be set to zero before the meter will return to the actual frequency input.

Simulation of the analog output: 0 % flow and 100% flow (4 - 20 mA). Can be set at any value between 0 and 100%. (Operates only while in this display.)

Simulation of the frequency output: 0 - 10,000 Hz. Only visible if the pulse output is selected to be either scaled frequency "Scl freq" or vortex frequency "Vor freq." (Operates only while in this display.)

DIAGNOSE GROUP
(continued)

Service

↓ Menu **D**

(continued)

Input Signal Amplitude	Vor Ampl 0%
Vortex Frequency	Vor Freq 0 Hz
4 mA Calibration Value	4 mA Cnt 1270
20mA Calibration Value	20mA Cnt 7150

Condulet Head
(Field Wiring Side)

Multimeter

Power Supply

Software Revision	Version 2.10
Self Diagnostics	Error code 1

Input signal level: 0 -100% of meter's maximum. (Not based on maximum flow, it is specific to the application, and programmed in the Basic Menu). (view only).

The raw input frequency from the sensor (view only.)

Sets the # of units, the microprocessor must send to the current output circuit, to generate 4 mA.

Sets the # of units, the microprocessor must send to the current output circuit, to generate 20 mA.

Wiring diagram to calibrate the 4-20 mA output . To calibrate the 4 mA count, go to "4 mA cnt"; press enter. Read current value from multimeter. The value, on the multimeter, should be 4 ± 0.012 mA. If value deviates by more than ± 0.012 mA, adjust the microprocessor count until the multimeter value equals 4 mA; press enter.

For the 20 mA count, go to "20mA cnt," and repeat the steps above.

Revision number of the software used is displayed (view only.)


Displays current error codes. Once the error condition no longer exists, the error code is cleared. Push the right- arrow key to scroll through the errors (if there is more than one.) See trouble shooting section for error code descriptions (view only).

PERSONALIZE GROUP


<div> <div>Password</div> <div>↓ Menu P</div> </div>	<div> <div>Set New Password</div> <div>Set Pass 1000</div> </div>	<p>A password can be added or changed in this block. If 0000 is selected, there will be no password, and there is unlimited access.</p>																		
<div> <div>HART</div> <div>↓ Menu P</div> </div>	<div> <div>HART Enable/Disable</div> <div>HART On</div> </div>	<p>User may turn the meter's HART communication capabilities on or off. (Compatible with HART 268 communicator.)</p>																		
<div> <div>Display</div> <div>↓ Menu P</div> </div>	<table border="1"> <tr> <td data-bbox="482 644 716 678">Flowrate</td> <td data-bbox="724 644 979 758"> <div>FlowRate Show</div> </td> </tr> <tr> <td data-bbox="482 793 716 827">Totalizer</td> <td data-bbox="724 793 979 907"> <div>Total Hide</div> </td> </tr> <tr> <td data-bbox="482 942 716 976">Bar Graph</td> <td data-bbox="724 942 979 1056"> <div>BarGraph Show</div> </td> </tr> <tr> <td data-bbox="482 1089 716 1123">Error Code</td> <td data-bbox="724 1089 979 1203"> <div>Err Code Show</div> </td> </tr> <tr> <td data-bbox="482 1236 716 1270">Totalizer Reset</td> <td data-bbox="724 1236 979 1350"> <div>TotReset Yes</div> </td> </tr> <tr> <td data-bbox="482 1383 716 1497"> <div>Display Time Constant</div> </td> <td data-bbox="724 1383 979 1497"> <div>Dsply TC 05 Sec</div> </td> </tr> <tr> <td data-bbox="482 1530 716 1564">Scan</td> <td data-bbox="724 1530 979 1644"> <div>Scan On</div> </td> </tr> <tr> <td data-bbox="482 1677 716 1711">Scan Time</td> <td data-bbox="724 1677 979 1791"> <div>ScanTime 05 Sec</div> </td> </tr> <tr> <td data-bbox="482 1824 716 1858">Flow Resolution</td> <td data-bbox="724 1824 979 1925"> <div>Flow Res 8 digits</div> </td> </tr> </table>	Flowrate	<div>FlowRate Show</div>	Totalizer	<div>Total Hide</div>	Bar Graph	<div>BarGraph Show</div>	Error Code	<div>Err Code Show</div>	Totalizer Reset	<div>TotReset Yes</div>	<div>Display Time Constant</div>	<div>Dsply TC 05 Sec</div>	Scan	<div>Scan On</div>	Scan Time	<div>ScanTime 05 Sec</div>	Flow Resolution	<div>Flow Res 8 digits</div>	<p>Show or Hide the flowrate from the display menu.</p> <p>Show or Hide totalizer from the display menu.</p> <p>Show or Hide the bar graph from the display menu.</p> <p>Show or Hide error codes from the display menu.</p> <p>If set to "Yes" and the enter key pressed, then the totalizer will be reset in the display mode.</p> <p>Sets the dampening of the flowrate in the display mode.</p> <p>Turns the automatic scrolling of the display menu on or off.</p> <p>The amount of time that each display is shown in the display mode. ("Scan" must be "On".)</p> <p>Selects how many significant digits of the flow rate to display .</p>
Flowrate	<div>FlowRate Show</div>																			
Totalizer	<div>Total Hide</div>																			
Bar Graph	<div>BarGraph Show</div>																			
Error Code	<div>Err Code Show</div>																			
Totalizer Reset	<div>TotReset Yes</div>																			
<div>Display Time Constant</div>	<div>Dsply TC 05 Sec</div>																			
Scan	<div>Scan On</div>																			
Scan Time	<div>ScanTime 05 Sec</div>																			
Flow Resolution	<div>Flow Res 8 digits</div>																			

EXITING
PROGRAMMING
SUBMENUS

The programming submenus can only be exited at the top of each submenu heading. To exit, press the enter key. The display will read "Exit." Toggle to "Yes" with the up or down-arrow key; press enter. If you have made any changes and want to save them, press enter when prompted by "Save Changes."




INTEGRAL ASSEMBLY Style shown: 2" through 12" flanged meter bodies



REMOTE ASSEMBLY

Style shown: All wafer meter bodies, 1" and 1.5" flanged meter bodies.




SENSOR REMOVAL

General

The process pressure must be less than 750 psig before the sensor can be removed. Employ electrostatic discharge (ESD) precautions when handling the electronics.


Integral



Disconnect power; remove conduit cap from electronics side of conduit. Remove the three display board screws. Carefully, disconnect display board from underlying board. **Note: Disregard previous if you don't have a local display.** Loosen the three, hex, standoff bolts, (bolts are retained, and only require about three revolutions to disconnect.) Remove the electronics stack from the conduit. Disconnect the sensor female connector from the base board. Using a crescent wrench, unscrew the conduit adaptor from the sensor body. **Note: There are two different conduit adaptor styles, depending on meter size.** Remove adaptor from sensor body; use care to allow the sensor wires to pass freely through it. Using a 5/8" deep well socket (with the wires passing through the wrench opening) and a crescent wrench, unscrew the retaining nut holding the piezoelectric crystal sensor housing in place. Remove sensor.


SENSOR REMOVAL (continued)

Remote




Sensor removal for a remote installation is the same as the integral installation with the following exceptions: 1) the sensor is disconnected from the remote mount condulet on the sensor body instead of at the remote electronics, and 2) the sensor is connected to a terminal strip in the remote mount condulet with spade lugs instead of a female connector.

SENSOR REPLACEMENT



Apply high temperature (-95 to +2600°F), Nickel-Based, anti-seize, lubricant compound, or equivalent, to the threaded portion of the sensor retaining nut. Install the sensor by guiding it into the sensor well until contact can be felt with the bottom. There are two tabs to control the orientation of the sensor. Thread the sensor retaining nut, into the sensor well, until it is hand tight. Tighten the sensor retaining nut with a 5/8" deep well socket (with the wires passing through the wrench opening) to a torque of 20 ft-lbs for a 1" meter, and 40 ft-lbs for all other sizes. If a torque wrench is not available, a rule of thumb for sensor tightening is: 1/8 turn beyond hand tight = 25 ft-lbs of torque; and 1/4 turn beyond hand tight = 40 ft-lbs of torque. Reconnect the sensor, and replace the condulet, reversing the instructions above.

**SENSOR
FUNCTIONALITY
TEST**

Functionality testing should be performed at the electronics conduit, regardless of type of the meter (integral or remote). Use proper ESD precautions at all times.

Disconnect the power. Remove the electronics stack from the conduit, and place it into an anti-static bag. Verify proper connection of the sensor to the filter (base) board. Disconnect the sensor from the filter (base) board. Check the resistance between the black wire and the blue wires. Insert solid wire (approx. 1/32" diameter) into the sensor female connector, to serve as leads. The resistance should be at least 20 M Ω . Check the resistance between all three wires and earth ground (the conduit or meter body). The resistance should also be at least 20 M Ω .

Check the sensor output voltage using an oscilloscope with a x10 probe (power should still be disconnected for this test, and the flowrate should be greater than 1/3 of the flowmeter's maximum flowrate.) Connect the ground lead of the scope to the black sensor wire. Connect the scope probe to one blue sensor wire. The output should be a sine wave, approximately 10 mV to 5 V in amplitude. As the flow rate increases, the amplitude and the frequency should increase. Disconnect the positive lead, and attach it to the other blue sensor wire. The output should be approximately the same voltage and frequency.

TROUBLE SHOOTING CHART

Symptom	Output signals	Error Code	Possible reason	Solution
Blank display	0-4 mA or 0 Hz		Supply voltage	Check supply voltage on the terminal board of the meter
				Check resistance of the current loop. Refer to analog output section for permissible values
			Defective Electronics	Replace electronics stack in the meter
Displays flow without output signal	<4 mA		Current output not selected	Turn 4-20 mA to "On" in output menu
	0 Hz		Frequency output not selected	Select frequency/pulse output option in output menu
No flow display or output at flow	4 mA or 0 Hz	1	Minimum flow setting too high	Reduce minimum flow in basic menu
			M-factor set too low	Auto set M-factor in Basic menu (flow>1/10 Q _{max})
		2	No signal from piezoelectric crystal	Check resistance across sensor wires: should be more than 20 Mohms
Shows flow without flow in pipe	Undefined		Pipe vibration or media pulsations disturbing the flow signal	Auto set M-factor in Basic menu (flow>1/10 Q _{max})
				Increase minimum flow setting in Basic menu until output goes to 4 mA or 0 Hz
				Auto set noise level in Basic menu
				Support pipe to reduce vibration
Unstable flow signal	Unstable		Pipe vibration and/or flow pulsations disturb flow measurement	Auto set M-factor in Basic menu (flow>1/10 Q _{max})
			Air bubbles in the media	Follow piping guidelines
			Pulsating flow	Increase the time constant for outputs and display
Measuring error	>20 mA	3	Flow exceeds 110% of Maximum flow	Make sure the sensor is correctly sized and check maximum flow setting in Basic menu
	>10 kHz max		Flow exceeds 110% of Maximum flow	Make sure the sensor is correctly sized and check maximum flow setting in Basic menu
	0 Hz	5	Volume/pulse too low or pulse width too long	Check volume/pulse and pulse width in Output menu for the flow measured
			Wrong calibration constant	Check that the K-factor in the Sensor menu corresponds to the value on the nameplate of the meter
	4 mA offset at no flow		4 mA calibration value incorrect	Calibrate 4 mA point in Service menu (pg.32)
	20 mA offset at max. flow		20 mA calibration value incorrect	Calibrate 20 mA point in Service menu (pg.32)

MODEL AND SUFFIX CODES

PhD Vortex Shedding Flowmeter

Category	Description	Suffix Codes
Wetted parts	Stainless Steel (sizes 1–12") Carbon Steel (Stainless steel wing) (sizes 6–12")	PhD-90 PhD-92
Fluid Type	Steam or gas Liquid	... S L
Line Size	1" 1.5" 2" 3" 4" 6" 8" 10" 12" 25 mm 40 mm 50 mm 80 mm 100 mm 150 mm 200 mm 250 mm 300 mm	... 10 15 20 30 40 60 80 100 120 DN25 DN40 DN50 DN80 DN100 DN150 DN200 DN250 DN300
Connection Type	Wafer (1" to 3" only) Flange	... W F
Connection Rating	ANSI Class 150 ANSI Class 300 ANSI Class 600 DIN, PN 16 DIN, PN 40 DIN, PN 64	... 150 300 600 PN 16 PN 40 PN 64
Options	No indicator/totalizer option ¹ FM approved ^{2,7} CSA approved ^{3,7,8} Local Indicator and Totalizer Remote Mount Electronics Integral 110 Vac input ⁴ Integral 220 Vac input ⁴	... STD FM CSA LOC-TOT RMT 110 220
Sensor Wires (Internal)	Teflon, -40° to 400°F (-40° to 204°C) Fiberglass, 150° to 750°F (65° to 400°C)	... T F

Example:

PhD-90S-60-F-300-LOC-TOT-RMT-T

Compatibility Chart

Notes:

- Has 4-20 mA or 50% duty cycle frequency output. A 50% duty cycle frequency can be scaled.
- Certified by FM for Class I, Div.1, Groups B, C and D; Class II, Div.1, Groups E, F, and G; Class I, Div.2, Groups A, B, C, and D; Class II, III, Div.2, Groups F and G, NEMA 4X locations.
- Certified by CSA for Class I, Div.1, Groups B, C, and D; Class II, Div.1, Groups E, F, and G; Class III.
- Not available with European CE Mark or FM, CSA or approvals.
- One manual is included with each meter. Extra manuals are available online at www.spiraxsarco.com/us
- For oxygen cleaning and material certifications, refer to ACCESSORIES AND MISCELLANEOUS section.
- Magnet wand is included with UL and CSA approved meters only. If required on non-approved meters, wand must be ordered as a spare part.
- PhDs are NOT PED approved for sales into European Union countries.

Compatibility Chart:	S	F	C	L	R	A	C	S	C
Compatible	T	M	S	A	M	A	C	S	C
Incompatible	D		A	T	T	C	S	S	E
STD									
FM									
CSA									
LOC-TOT (LT)									
RMT									
110/220 (AC)									
CARBON STEEL (CS)									
STAINLESS STEEL (SS)									
EUROPEAN CE (CE)									

Spirax Sarco Technical Support Department
Toll Free at: 1-800-356-9362



SPIRAX SARCO, INC. • 2150 Miller Drive • Longmont, CO 80501
PHONE 303-682-7060 • Fax 303-682-7069
www.spiraxsarco.com/us