


**TVA Flowmeter
for Saturated Steam Service
Installation and Maintenance Instructions**



1. *Safety information*
2. *General product information*
3. *Installation*
4. *Commissioning*
5. *Operation*
6. *Maintenance*
7. *Spare parts*
8. *Fault finding*
9. *Settings table*

1. Safety information

Safe operation of this unit can only be guaranteed if it is properly installed, commissioned and maintained by a qualified person (see Section 1.11) in compliance with the operating instructions. General installation and safety instructions for pipeline and plant construction, as well as the proper use of tools and safety equipment must also be complied with.

Manufacturer:-

Spirax Sarco Ltd
Charlton House
Charlton Kings
Cheltenham
Glos
GL53 8ER

The product is designed and constructed to withstand the forces encountered during normal use. Use of the product for any other purpose, or failure to install the product in accordance with these Installation and Maintenance Instructions, could cause damage to the product, will invalidate the (CE) marking, and may cause injury or fatality to personnel.

EMC directive

The product complies with the Electromagnetic Compatibility Directive 2004/108/EC. A technical file with a reference number of 'UK Supply TVA flowmeter' supports the Spirax Sarco claim that the product complies with the requirements of the Directive and the product can be used in Class A (heavy industrial) and Class B (domestic/commercial areas).

The following conditions should be avoided as they may create interference above the heavy industrial limits if:

- The product or its wiring is located near a radio transmitter.
- Cellular telephones and mobile radios may cause interference if used within approximately 1 metre (39") of the product or its wiring. The actual separation distance necessary will vary according to the surroundings of the installation and the power of the transmitter.

If this product is not used in the manner specified by this IMI, then the protection provided may be impaired.

1.1 Intended use

Referring to the Installation and Maintenance Instructions, name-plate and Technical Information Sheet, check that the product is suitable for the intended use / application. The product listed complies with the requirements of the European Pressure Equipment Directive 97/23/EC, carries the (CE) mark when so required. The product falls within the following Pressure Equipment Directive categories:

Product	Group 1 Gases	Group 2 Gases	Group 1 Liquids	Group 2 Liquids
TVA flowmetering system DN50 to DN100	-	1	-	-

- i) The product has been specifically designed for use on saturated steam only which is in Group 2 of the above mentioned Pressure Equipment Directive.

-
- ii) Check material suitability, pressure and temperature and their maximum and minimum values. If the maximum operating limits of the product are lower than those of the system in which it is being fitted, or if malfunction of the product could result in a dangerous overpressure or overtemperature occurrence, ensure a safety device is included in the system to prevent such over-limit situations.
 - iii) Determine the correct installation situation and direction of fluid flow.
 - iv) Spirax Sarco products are not intended to withstand external stresses that may be induced by any system to which they are fitted. It is the responsibility of the installer to consider these stresses and take adequate precautions to minimise them.
 - v) Remove protection covers from all connections and protective film from all name-plates, where appropriate, before installation on steam or other high temperature applications.

1.2 Access

Ensure safe access and if necessary a safe working platform (suitably guarded) before attempting to work on the product. Arrange suitable lifting gear if required.

1.3 Lighting

Ensure adequate lighting, particularly where detailed or intricate work is required.

1.4 Hazardous liquids or gases in the pipeline

Consider what is in the pipeline or what may have been in the pipeline at some previous time. Consider: flammable materials, substances hazardous to health, extremes of temperature.

1.5 Hazardous environment around the product

Consider: explosion risk areas, lack of oxygen (e.g. tanks, pits), dangerous gases, extremes of temperature, hot surfaces, fire hazard (e.g. during welding), excessive noise, moving machinery.

1.6 The system

Consider the effect on the complete system of the work proposed. Will any proposed action (e.g. closing isolation valves, electrical isolation) put any other part of the system or any personnel at risk?

Dangers might include isolation of vents or protective devices or the rendering ineffective of controls or alarms. Ensure isolation valves are turned on and off in a gradual way to avoid system shocks.

1.7 Pressure systems

Ensure that any pressure is isolated and safely vented to atmospheric pressure. Consider double isolation (double block and bleed) and the locking or labelling of closed valves. Do not assume that the system has depressurised even when the pressure gauge indicates zero.

1.8 Temperature

Allow time for temperature to normalise after isolation to avoid the danger of burns and consider whether protective clothing (including safety glasses) is required.

1.9 Tools and consumables

Before starting work ensure that you have suitable tools and/or consumables available. Use only genuine Spirax Sarco replacement parts.

1.10 Protective clothing

Consider whether you and/or others in the vicinity require any protective clothing to protect against the hazards of, for example, chemicals, high/low temperature, radiation, noise, falling objects, and dangers to eyes and face.

1.11 Permits to work

All work must be carried out or be supervised by a suitably competent person. Installation and operating personnel should be trained in the correct use of the product according to the Installation and Maintenance Instructions.

Where a formal 'permit to work' system is in force it must be complied with. Where there is no such system, it is recommended that a responsible person should know what work is going on and, where necessary, arrange to have an assistant whose primary responsibility is safety.

Post 'warning notices' if necessary.

1.12 Handling

Manual handling of large and/or heavy products may present a risk of injury. Lifting, pushing, pulling, carrying or supporting a load by bodily force can cause injury particularly to the back. You are advised to assess the risks taking into account the task, the individual, the load and the working environment and use the appropriate handling method depending on the circumstances of the work being done.

1.13 Residual hazards

In normal use the external surface of the product may be very hot. If used at the maximum permitted operating conditions the surface temperature of some products may reach temperatures of 250°C (482°F).

Many products are not self-draining. Take due care when dismantling or removing the product from an installation (refer to 'Maintenance instructions').

1.14 Freezing

Provision must be made to protect products which are not self-draining against frost damage in environments where they may be exposed to temperatures below freezing point.

1.15 Disposal

Unless otherwise stated in the Installation and Maintenance Instructions, this product is recyclable and no ecological hazard is anticipated with its disposal providing due care is taken.

1.16 Returning products

Customers and stockists are reminded that under EC Health, Safety and Environment Law, when returning products to Spirax Sarco they must provide information on any hazards and the precautions to be taken due to contamination residues or mechanical damage which may present a health, safety or environmental risk. This information must be provided in writing including Health and Safety data sheets relating to any substances identified as hazardous or potentially hazardous.

— 2. General product information —

This manual explains how to install, commission and maintain the Spirax Sarco TVA flowmeter for use on saturated steam.

2.1 Product description

The Spirax Sarco TVA flowmeter is designed to reduce the cost of flowmetering and is used as an accurate means to measure saturated steam flowrates and record total flow. The TVA flowmeter is a stand alone device and requires no other equipment, such as differential pressure transmitters, pressure sensors, etc. to calculate mass flowrates of saturated steam.

2.2 Equipment delivery and handling

Factory shipment

Prior to shipment, the Spirax Sarco TVA flowmeter is tested, calibrated and inspected to ensure proper operation.

Receipt of shipment

Each carton should be inspected at the time of delivery for possible external damage. Any visible damage should be recorded immediately on the carrier's copy of the delivery slip. Each carton should be unpacked carefully and its contents checked for damage.

If it is found that some items have been damaged or are missing, notify Spirax Sarco immediately and provide full details. In addition, damage must be reported to the carrier with a request for their on-site inspection of the damaged item and its shipping carton.

Storage

If a flowmeter is to be stored prior to installation, the environmental storage conditions should be at a temperature between 0°C and 55°C (32°F and 130°F), and between 10% and 90% relative humidity (non-condensing).

2.3 Sizes and pipe connections

DN50, DN80 and DN100

The TVA flowmeter is of a wafer design, suitable for fitting between the following flanges:

EN 1092 PN16, PN25 and PN40

BS 10 Table H

ASME (ANSI) B 16.5 Class 150 and 300

Korean Standard KS 20.





Fig. 1 TVA flowmeter

2.4 Pressure/temperature limits



 The product should not be used in this region due to the limitations of the software.

PMA	Maximum allowable pressure @ 239°C (460°F)	Saturated steam 32 bar g (464 psi g) otherwise as the specified flange rating	
TMA	Maximum allowable temperature	239°C	(460°F)
	Minimum allowable temperature	0°C	(32°F)
* PMO	Maximum operating pressure for saturated steam service	Horizontal flow	32 bar g (464 psi g)
		Vertical flow	7 bar g (101 psi g)
	Minimum operating pressure	0.6 bar g	(8.7 psi g)
TMO	Maximum operating temperature	239°C	(460°F)
	Minimum operating temperature	0°C	(32°F)
	Maximum electronics ambient temperature	55°C	(130°F)
	Maximum electronics humidity level	90% RH (non-condensing)	
Δ PMX	Maximum differential pressure	The pressure drop across the TVA flowmeter at the maximum rated flow is nominally 750 m bar (300 inches wg) for the DN50, and 500 m bar (200 inches wg) for the DN80 and DN100	
	Cold hydraulic test pressure of:	52 bar g	(754 psi g)

* Important note

Caution: If the electronic housing is mounted at an angle of 45° (or more) from the vertically downward position the PMO (maximum operating pressure) must be limited to 7 bar g (101 psi g).




Fig. 2 Installation limiting conditions

2.5 Technical data


IP rating	IP65 with correct cable glands.
Power supply	Loop powered nominal 24 Vdc
Outputs	4-20 mA (proportional to mass flow) Pulsed output V_{max} 28 Vdc, R_{min} 10 k Ω , V_{on} 0.7 V_{max}
Communication port	EIA 232C 15 m limit - See Section 4.11
Performance	System uncertainty to ISO 17025 (95% confidence to 2 STD) $\pm 2\%$ of reading over the range of 10% to 100% of maximum rated flow $\pm 0.2\%$ FSD from 2% to 10% of maximum rated flow Turndown: up to 50:1

2.6 Electrical connections

Electrical connections	M20 x 1.5
------------------------	-----------

2.7 Materials

Flowmeter body	Stainless steel 1.4408 CF8M
Internals	431 S29/S303/S304/S316
Spring	Inconel® X750 or equivalent
Flowmeter stem	Stainless steel 431 S29
Electronics housing	Aluminium alloy LM 25



2.8 Dimensions/weights (approximate) in mm and kg

Size	A	B	C	D	E	Weight
DN50	35	103	322	160	65	2.67
DN80	45	138	334	160	65	4.38
DN100	60	162	344	215	65	7.28

3. Installation

Note: Before actioning any installation observe the 'Safety information' in Section 1. To meet its specified accuracy and performance it is essential that the following installation guidelines are followed carefully. For steam applications sound steam engineering practices should be followed, including the use of separators. The installation must conform to all relevant construction and electrical codes.

CAUTION: If the electronic housing is mounted at an angle of 45° (or more) from the vertically downward position the PMO (maximum operating pressure) must be limited to 7 bar g (101 psi g) - see Figure 4.




Fig. 4
Installation limiting conditions


Fig. 5 Typical installation

3.1 Environmental conditions

The flowmeter should be located in an environment that minimises the effects of heat, vibration, shock and electrical interference. (Pressure / temperature limits are detailed in Section 2.4).

CAUTION: Do not lag (insulate) the TVA flowmeter or mating flanges as this may result in excessive temperatures in the electronics. Exceeding specified temperature limits will invalidate the warranty, adversely effect the performance and may damage the TVA flowmeter, see Figure 6.

Fig. 6 Pipeline insulation



Other considerations

Be sure to allow sufficient clearance for:

- Installation of conduit/wiring.
- Removal of the enclosure end caps.
- Viewing of the display. **Note** electronics housing and display can be rotated.

Warning: Do not install the flowmeter outdoors without additional weather protection to prevent damage due to freezing.

3.2 Mechanical installation

Warning: Do not alter the adjustment nut at the back of the TVA flowmeter shaft, as this will affect the flowmeters calibration.

Orientation

The TVA flowmeter can be installed in any orientation when the pressure is below 7 bar g (101 psi g), see Figures 7, 8 and 9.

When the pressure is above 7 bar g the TVA flowmeter must be installed in a horizontal pipe, with the electronics housing below the body, see Figure 9.

Note: The TVA flowmeter operates with flow in one direction only. It is not intended for use with bi-directional flow. The TVA flowmeter is clearly marked with a direction of flow arrow.




Fig. 7 Vertical flow limited to 7 bar g




Fig. 8 Horizontal flow limited to 7 bar g

CAUTION: If the electronic housing is mounted at an angle of 45° (or more) from the vertically downward position the PMO (maximum operating pressure) must be limited to 7 bar g (101 psi g) - see Figure 4.




Fig. 9 Horizontal flow up to 32 bar g


Rotating the electronics enclosure

The electronics housing can be rotated 270° to enable sufficient clearance for installation. To rotate the electronics housing, carefully remove the 4 x end cap screws. Support the weight of the end cap and loosen (**do not remove**) the end cap 'lock screw'. The electronics housing can now be rotated to the required position.

Retighten the 'lock screw' (3 N m or 26.5 lbf in) and replace end cap and 4 x end cap screws. See the adjacent diagram.

Do not loosen or remove the grub screw adjacent to the 'lock screw'.

Warning: Do not loosen / remove the stem from the main body of the unit.



Upstream/downstream pipework

The TVA flowmeter should be installed in pipework manufactured to BS 1600 or ASME (ANSI) B 36.10 Schedule 40, which corresponds to the following pipeline internal diameters.

Nominal diameter	Nominal internal diameter
50 mm	52 mm
80 mm	77 mm
100 mm	102 mm

For different pipe standards/schedules, if the flowmeter is being operated at the extreme of its published maximum range, and maximum accuracy is required, downstream spool pieces manufactured from BS 1600 or ASME (ANSI) B 36.10 Schedule 40 pipe should be used.

It is important that the internal upstream and downstream diameters of pipe are smooth. Ideally seamless pipes should be used and there should be no intrusive weld beads on the internal diameter. It is recommended that slip-on flanges be used to avoid any intrusive weld beads on the internal diameter of the pipe.

Note: See Figures 10 to 13 for other considerations which need to be noted before determining the correct installation location.

The TVA flowmeter normally only requires a minimum of 6 pipe diameters upstream and 3 downstream of clear straight pipe. These dimensions assume a measurement from a single 90° bend (see Figure 10).




Fig. 10

If any of the following configurations are present upstream of the TVA flowmeter:

- Two right angled bends in two planes.
- Pressure reducing valve.
- Partly open valve.

Then it is recommended that the minimum upstream clear pipework is doubled to 12 diameters (See Figure 11).




Fig. 11

Avoid installing the TVA flowmeter downstream of an actuated valve as rapid cycling of the valve could give rise to inaccurate results or damage the flowmeter. See Figure 12. In configurations where there is more than one rapid acting pressure reducing valve close coupled, the TVA flowmeter should be installed with a minimum of 25 upstream and 3 downstream pipe diameters away from the valves. Safety valves should also be as far away as possible from the flowmeter - at least 25D.




Fig. 12

To install the TVA flowmeter pipeline unit into existing pipework and for aiding possible flowmeter removal, a spool piece can be fabricated locally to the dimensions given below (see Figure 13).

Size	DN50	DN80	DN100
Dimension A	180 mm	240 mm	300 mm
	7.1 in	9.5 in	11.8 in




Fig. 13

Location in pipework

Bolt ring gaskets having the same internal diameter of the pipework are recommended. This will prevent possible inaccuracies being created by the gasket protruding into the pipe.

It is important that the TVA flowmeter is located centrally in the pipework as any eccentricity may cause inaccurate readings. The TVA flowmeter has integral centering webs, which locate on the internal diameter of the pipework (see Figure 14).




Fig. 14 Integral centering webs




Fig. 15 Gaskets fitted correctly




Fig. 16 Gaskets fitted incorrectly




Fig. 17 Gaskets and pipe offline, fitting incorrectly

3.3 Electrical installation

The TVA flowmeter is a loop powered device. This Section describes loop wiring and shows typical conductor terminations (The EIA 232C (RS 232) wiring is discussed in Section 4.11, page 28). It also considers the effect of connecting additional equipment (e.g. recorder, loop powered display) to the loop.

Wiring the TVA flowmeter

The wiring terminals can be accessed by removing the end cap of the enclosure. A typical loop wiring diagram is shown in Figure 18.

If an M750 display unit is purchased from Spirax Sarco for use with the TVA flowmeter, the M750 must be configured to the flow of the TVA flowmeter @ 20 mA. If the TVA flowmeter 4 - 20 mA output is rescaled (see Section 4.6.1), it is important that the 20 mA input valve on the M750 is also rescaled.

Notes:

The flowmeter must be earthed. The TVA is supplied with a 1 metre earthing lead attached to a 4 mm threaded hole at the rear of the enclosure close to the 20 mm conduit holes. An alternative earth cable can also be attached.

Please ensure all paint is removed to ensure a low resistance connection is made. The earth cable should be at least 4 mm sq and the use of a crimp is recommended. Remove the silica gel from the enclosure after commissioning.




Fig. 18 Wiring diagram

Power supply requirements

A nominal 24 Vdc is needed to power the flowmeter. However, the TVA flowmeter will operate correctly as long as the power supply is in the range shown in Figure 19. A single, stand-alone, supply may be capable of powering several transmitters. It can be mounted in a control room or in the field, but cannot be on the same loop. Follow the power supply manufacturer's recommendations with regard to mounting and environmental considerations.

The graph (Figure 19) shows the range of power supply voltages and loop resistances over which the TVA flowmeter is capable of operating. The loop resistance includes all the wiring.




Fig. 19

Cable length

Generally the maximum cable length between the TVA flowmeter and the power supply is 300 m.

However the actual cable length is governed by the number of network devices, the total resistance of the network and the cable capacitance.

Suggested cable type: for both loop and pulse should be shielded twisted pairs, each core, seven stranded wire with cross sectional area of 0.5 mm².

Cable glands suitable for M20 x 1.5 to EN 50262 / IP68 are recommended.

The cable gland / body torque setting is 5 Nm.

The gland nut torque setting (with cable fitted) is 5 Nm.

4. Commissioning

After all mechanical and electrical work has been completed, the following commissioning instructions should be followed.

The TVA flowmeter should be commissioned with the flow through the unit isolated.

Note: The TVA flowmeter is factory set to display data in metric units. To commission the TVA to display imperial units see Section 4.4.2, page 24.




Fig. 20 TVA flowmeter display unit

All commissioning is carried out through the display unit installed behind the front end cap of the TVA flowmeter enclosure. The display unit consists of a small LCD display and a 5 button keypad.

As all the commissioning settings are stored in a non-volatile memory, it is possible to connect a 9 V PP3 battery to the TVA flowmeter's 4 - 20 mA loop power supply and commission the unit uninstalled. However, the TVA flowmeter should still be zeroed in-line (see Section 4.5.3) and its operation checked. The M750 display unit can be used to provide a remote display function if required, utilising the linear output.

Rotating the display

The display can be rotated through 180° to enable ease of commissioning. To rotate the display disconnect the power supply, remove the mounting screws on the display unit, carefully remove the display unit and rotate. Carefully replace the display unit and replace mounting screws. Do not force the display unit into position. Reconnect the power supply.

Note: Electrostatic discharge (ESD) procedures should be followed while rotating the display.

4.1 Run mode

Normally, the TVA flowmeter will operate in the run mode, displaying the total flow, flow, power, pressure or temperature of the fluid passing through the pipeline.

After initial power up, the TVA flowmeter will automatically enter the run mode and all commissioning menus can be accessed from this mode. (See Section 4.2, Commissioning mode, for details on how to commission).

In the run mode the fluid data is displayed on several screens which can be accessed by pressing the up or down keys. The display shows a numeric value and an arrow indicating the reading type, i.e. total flow, flow, power, pressure or temperature. All units (except °C) are implied with imperial or metric units being indicated by another arrow. The value of total flow is shown in two parts. The first five digits of the total flow will be displayed and after 10 seconds the following five digits will be displayed. To access the first five digits of total flow again it will be necessary to scroll up or down and return to the total flow display.





Fig. 21

4.1.1 Run mode data sequence



The following chart indicates the run mode data display sequence. Depending on the configuration, the flow units will be:

Units	Steam
Metric	Kg/h, KW, bar g, °C
Imperial	lb/h, MBtu/h, psi g, °F

The TVA flowmeter is factory set to display steam data in metric units and pressing the up or down keys will scroll through the following data.




Fig. 22

4.1.2 Error display messages

Any errors that occur will be displayed in the run mode. The errors will alternate with the normal run mode display and will be prioritised. The errors will be latched and can only be cancelled by pressing the 'OK' button. Once the error message has been cancelled the display will show the next (if any) error.

Any continuous error will reinstate itself 2 seconds after it has been cancelled, and will be indicated by a flashing exclamation mark (!).

Certain errors will also cause the 4-20 mA alarm signal to be initiated.

The error messages are displayed over two screens and are:


**POWER
OUT** = Power interrupted.

**NO
SIGNL** = No signal from sensor.
= (This can also activate
the 4-20 mA alarm).

**SENSR
CONSt** = Signal from sensor constant.
= (This can also activate
the 4-20 mA alarm).

**HIGH
FLOW** = Flow above the maximum.


4.3 TVA flowmeter commissioning flow chart




Error Messages


These alternate with the normal run mode display. They will be prioritised and will be latched when they occur. Pressing the 'OK' button will cancel the displayed alarm and allow the next one to be viewed. A continuous alarm will re-occur on the display 2 seconds after it has been cancelled.

Power interrupted	POWER OUT	
No signal from sensor	NO SIGNL	The 4-20 mA alarm can also be activated
Signal from sensor constant	SENSR CONST	The 4-20 mA alarm can also be activated
Flow above maximum	HIGH FLOW	Shows when flow exceeds maximum





4.4 BASIC DATA Sub menu



4.4.1 dRy

Pressing the right key will display the dryness fraction. This is the dryness fraction of the saturated steam being measured. This can then be edited to suit the application. Press the 'OK' button to confirm the selection.

After the dryness fraction is entered the display will automatically step to the next sub menu and show 'UNItS'

4.4.2 UNItS

The units displayed and transmitted can be selected between metric (MEt), and imperial (IMP). A summary of the units is detailed in the Table below.

Units	Steam
Metric	Kg/h, KW, bar g, °C
Imperial	lb/h, MBtu/h, psi g, °F

Select either 'MEt' or 'IMP' and press the 'OK' button to confirm.

4.4.3 CLEAR tOtAL

This function is used to clear the total by pressing and holding the 'OK' key for 3 seconds.

Note: The total is backed-up every 8 minutes in the TVA flowmeter's non-volatile memory. If power is lost the TVA flowmeter could lose up to 8 minutes worth of totalised steam.

4.4.4 AtMOS PRES


This value compensates the flowrates for atmospheric pressure. It should be used if a high degree of accuracy is required or when the TVA flowmeter is installed high above sea level.

Note: Values up to two decimal places can be entered.

If metric units are selected pressure units are bar absolute, for imperial units psi absolute.

4.5 MEtER Sub-menu

This sub-menu contains information about the flowmeter and is used to zero the flowmeter and clear the total.



4.5.1 dIR

dIR is the orientation that the TVA flowmeter is installed in. The TVA flowmeter can be installed with horizontal flow up to a pressure of 32 bar g (464 psi g). For installations that require vertical flow either up or down the maximum pressure must not exceed 7 bar g (101 psi g). By selecting down or up the effect of gravity on the cone is taken into account.

Note: Upon entering the **dIR** sub-menu, **HORIZ** is **always** shown first. The actual direction selected is the one which is flashing.

4.5.2 S/N

This is the factory set serial number of the TVA flowmeter and is displayed by pressing the right key.

4.5.3 ZErO MEtER

This function is used to zero the TVA flowmeter manually to compensate for any electronic drift.

The procedure for zeroing the flowmeter is as follows:

- Isolate the pipeline where the flowmeter is installed and ensure that there is no flow. The line temperatures should be above 5°C (41°F) and below 30°C (86°F).
- Press and hold the 'OK' button for three seconds.

On completion the display will step back to S/N.

If 'ZErO ErrOr' is displayed, check to ensure that the line is isolated with no flow. If 'tEMP ErrOR' is displayed the line temperature is below 5°C (41°F). Allow the temperature to move above 5°C (41°F) and re-zero. **Note: The flowmeter should ideally be zeroed once every 12 months.**


4.5.4 CLEAR tOtAL

This function is used to clear the total by pressing and holding the OK key for 3 seconds.


Note: The total is backed-up every 8 minutes in the TVA flowmeter's non-volatile memory. If power is lost the TVA flowmeter could lose up to 8 minutes worth of totalised steam.

4.6 OutPutS Sub-menu

This sub-menu allows both the 4-20 mA and pulsed outputs of the flowmeter to be configured.



4.6.1 4-20 mA Output sub-menu



The 4-20 mA sub-menu allows re-ranging and re-calibrating of the 4-20 mA output.

4.6.2 SOURCE

This changes the source data for the 4-20 mA between flow and power.

4.6.3 SEt 4 mA

This sets the value for the flowrate or power, which is equivalent to 4 mA. The minimum value that can be set as 4 mA is 0 and the maximum is the 20 mA equivalent value less one.

4.6.4 SEt 20 mA

This sets the value for the flowrate or power, which is equivalent to 20 mA. The minimum value that can be set as 20 mA is the 4 mA equivalent value plus one and the maximum is the meters rated maximum at 32 bar g. The 20 mA value must always be a minimum of one greater than the 4 mA value.

4.6.5 CHECK 4 mA


This allows the 4 mA value to be re-calibrated. A digital volt meter/multimeter should be connected in series with the 4-20 mA output. Pressing the right arrow button will display OP = 4 mA and the TVA flowmeter will output a steady 4 mA. If the multimeter does not read 4 mA the up and down arrow buttons can be pressed to alter this current until 4 mA exactly is indicated. Pressing the 'OK' button confirms the setting.

4.6.6 CHECK 20 mA

This allows the 20 mA value to be re-calibrated. A digital volt meter/multimeter should be connected in series with the 4-20 mA output. Pressing the right arrow button will display OP = 20 mA and the TVA flowmeter will output a steady 20 mA. If the multimeter does not read 20 mA the up and down arrow buttons can be pressed to alter this current until 20 mA exactly is indicated. Pressing the 'OK' button confirms the setting.

4.6.7 Pulse Output

This sub-menu allows the pulsed output to be configured.



4.6.8 PULSE

This selects whether the pulsed output is to be used or disabled.

4.6.9 SORCE

This selects the source data for the pulsed output. The source data can be either unit mass per pulse (tOtAL) or unit energy per pulse (ENRgy).

4.6.10 NUM/PULSE


This allows the total mass, or energy, which is equivalent to one pulse to be configured. Units are dependent on the UNIt setting. Metric units will be kg for total or MJ for energy, imperial units will be lb for total or MBtu for energy.

4.6.11 PULSE WIDTH

This allows the width of the pulse to be set. The width can be set in 0.01 second increments from 0.02 seconds to a maximum of 0.2 seconds.

4.7 tESt sub-menu

The tESt sub-menu allows access to the TVA flowmeter's diagnostic tools. From here the display, 4-20 mA and pulse outputs can be tested.



4.7.1 dISP

This allows the display to be tested. Pressing the right button will cause all the segments on the display to be turned on. Pressing the left button cancels the test and steps to the next stage.

4.7.2 4-20 mA Out

This allows the 4-20 mA output to be tested. By editing the value and pressing the 'OK' button the output can be set to the selected output. This current will continue to be transmitted for five minutes unless the cancel option is chosen.

4.7.3 PULSE OUT


This allows the pulsed output to be tested. By selecting 'ON' or 'OFF' the desired test state of the pulsed output can be selected. Once the 'OK' button is pressed the pulsed output will remain in the selected state for five minutes or until the cancel option is chosen.

4.7.4 CANCEL

This allows the 4-20 mA output and pulsed output test signal selected above to be cancelled before the five minutes duration has expired.

4.8 ALARM sub-menu

This sub-menu gives access to setting the action that is required on the 4-20 mA output when an error is detected by the TVA flowmeter electronics. It also gives access to the power alarm function.



4.8.1 O/P ALARM

HIGH	If the self-diagnostic electronics determine that the sensor output has been constant for a period of time, or is not giving out a signal, it will set the 4-20 mA output to 22 mA.
LOW	If the self-diagnostic electronics determine that the sensor output has been constant for a period of time, or is not giving out a signal, it will set the 4-20 mA output to 3.8 mA.
OFF	This disables the 4-20 mA alarm function.

4.8.2 POWER ALARM

OFF	This disables the 4-20 mA alarm function (default).
ON	This enables the power alarm function.


4.9 SW.VER

This allows the software version to be viewed.



4.10 Set PASS

This allows the default pass code to be changed to a user defined value. It is important that if the default pass code is changed that the new value is noted and kept safe. The new pass code can be recorded on the Table in Section 9, page 32.



4.11 EIA 232C (RS 232) communications

The TVA flowmeter has a MODbus EIA 232C compatible communications link. This enables users to easily interrogate the TVA flowmeter for steam data using either a dumb terminal or a P.C. loaded with a simple terminal emulation program. The connection length is limited to 15 metres and must be in the same building/area as the TVA flowmeter.

The TVA flowmeter communication protocol is set up as follows and is fixed:-

TVA flowmeter UART set up	
Baud rate	1200
Data bits	7
Stop bits	One
Parity	None
Echo	Off

The response time of the TVA flowmeter is less than 0.5 seconds. If the PC asks for data faster than this (i.e. twice per second), the TVA flowmeter will answer the first request it received, any later requests will be ignored.

4.11.1 Using the EIA 232C communications

It is assumed that:

- The electrical wiring for the EIA 232C communications has been carried out in accordance with the EIA 232C standard. Please note the TVA EIA 232C connection requires a connector RJ11 linked to a 9 way D-type adaptor. Figure 23 illustrates the TVA flowmeter's RJ11 socket from the front.

The table below lists the RJ11 socket's pin connections. The signals are named from the PC (or data terminal) end.

RJ11 pin	9-way D-type	Signal
1		Not used
2	→ 4	DTR
3	→ 5	GND
4	→ 2	RX
5	→ 3	TX
6	→ 8	CTS




Fig. 23 RJ11 socket

- The communications protocol has been set up on the communicating device as described earlier in this Section. The following is a Table of operating codes in ASCII characters:-

User transmits	Note: [LF] means line feed	The TVA responds by transmitting
AT[LF]		Total in kg [LF]
AR[LF]		Flowrate in kg/h [LF]
AB[LF]		Pressure in bar g [LF]
AC[LF]		Line temperature in Celsius [LF]
AP[LF]		Power in KW [LF]
AE[LF]		Water equivalent flowrate in l/min [LF]

4.12

After installation or maintenance ensure that the system is fully functioning. Carry out tests on any alarms or protective devices.

5. Operation

The TVA flowmeter operates by measuring the strain produced on a moving cone by an instantaneous flowrate. This strain is then converted into a density compensated mass flowrate and is transmitted via a single loop powered 4 - 20 mA output and pulsed output. The unique design of the TVA flowmeter produces the high turndowns and high accuracy required in process applications.

6. Maintenance

The TVA flowmeter should be zeroed using the zero meter sub-menu at least once a year. This will remove any electronic long term drift that may occur. Frequency of re-calibration depends upon the service conditions experienced by the meter and the application. Re-calibration frequency can be typically between 2 and 5 years.

Replacement of the TVA flowmeter display electronics

To replace the electronics:

- Disconnect the power supply.
- Remove the front housing.
- Remove the mounting screws on the display unit and carefully remove the electronics.
- Carefully unplug the ribbon cable.
- Reconnect the ribbon cable to the new electronics and carefully replace.
- Replace the mounting screws and reconnect the power supply.

Note: Electrostatic discharge (ESD) procedures should be followed while installing the new electronics.

Do not force the electronics / display unit into position.

7. Spare parts

Spare electronics for the TVA flowmeter are available from Spirax Sarco and consist of:

- TVA flowmeter replacement display and electronics with front housing.

It is important that the serial number of the TVA flowmeter is given at the time of ordering.

Example: 1 off Spirax Sarco display and electronics panel for a DN100 TVA flowmeter having the following Serial number D_____.

8. *Fault finding*

Many faults which occur on commissioning are found to be due to incorrect wiring or setting up, therefore it is recommended that a thorough check is carried out should there be a problem. The TVA flowmeter display has in-built diagnostic features and will indicate a number of errors on the display and via the 4-20 mA output.

The errors will alternate with the normal run mode display and will be shown according to priority. The errors will be latched and can only be cancelled by pressing the 'OK' button. Once the error message has been cancelled the display will show the next (if any) error.

Any continuous error will re-instate itself 2 seconds after it has been cancelled, and will be indicated by a flashing exclamation mark (!).

Symptom	Possible cause	Action
Display is blank	dc voltage is not within the range of 9-28 Vdc. Supply connected with reverse polarity. Electronics faulty.	Check power supply/current connections. See Section 3.3. Change polarity. Refer to: Spirax Sarco Ltd
Display shows: NO SIGNL	Insufficient supply voltage. Current loop resistance is greater than Rmax. Electronics faulty.	Check supply voltage is between 9 and 28 Vdc. Check current loop resistance and reduce if necessary. Check current output electronics (refer to Sections 4.6 and 4.7). Refer to: Spirax Sarco Ltd
Display shows: POWER Out	Power supply interrupted.	Ensure power supply is secure and cancel error using the OK key. Totals transmitted may not be valid.
Display shows: SENSR CONST	Cone jammed. Electronics Faulty.	Remove unit from pipeline and check cone movement. Check current output electronics (refer to Sections 4.6 and 4.7). Refer to: Spirax Sarco Ltd
Display shows: HIGH FLOW	Meter undersized.	Check sizing and replace if necessary.
Constant 3.8 mA	Error signal set to Low.	Check display for errors and rectify as above. Check current output electronics (refer to Sections 4.6 and 4.7).
Constant 22 mA	Error signal set to High.	Check display for errors and rectify as above. Check current output electronics (refer to Sections 4.6 and 4.7).

Symptom	Possible cause	Action
Flow indicated responds to changes in actual flow but value indicated does not correspond to actual flowrate	<p>Flowmeter not properly centred in the pipeline.</p> <p>Gaskets at the flowmeter protrude into the pipe bore.</p> <p>Irregularities on the surface of the pipe bore.</p> <p>Signal falsified due to bi-phase medium.</p> <p>Insufficient upstream/ downstream pipe lengths.</p> <p>Flow direction reversed.</p>	<p>The axis of the flowmeter bore should be aligned with that of the pipe.</p> <p>See Section 3, Figs 15, 16 and 17 for proper installation of gaskets.</p> <p>Pipe bore should be free of irregularities.</p> <p>Bi-phase media are not permitted. Use a separator for wet steam applications to remove moisture droplets from the steam.</p> <p>See Section 3 for correct lengths of upstream and downstream pipes.</p> <p>Check flow direction arrow on primary.</p>
Pulse output is incorrect	<p>Pulse output incorrectly set.</p> <p>Pulse width incorrectly set.</p> <p>Pulse output is overloaded.</p> <p>Pulse output electronics faulty.</p>	<p>Check programming of pulse output, Section 4.6.7.</p> <p>Check maximum pulse width of counter electronics.</p> <p>Check load ratings.</p> <p>Test pulse output. If faulty replace unit.</p>
DIVAp^{plus} produces large amount of noise (banging and clattering)	<p>Upstream/downstream installation lengths incorrect.</p>	<p>Re-install following the installation guidelines (Section 3).</p>
Non zero flow indicated when no actual flow is in the pipe.	<p>Unit not zeroed at commissioning.</p> <p>4 mA output not calibrated.</p> <p>4 mA retransmission set to a value higher than zero.</p> <p>Interference.</p>	<p>Zero unit.</p> <p>Calibrate 4 mA output (Section 4.6.5).</p> <p>Reset 4 mA.</p> <p>Check earthing.</p>

9. Settings table

This Table shows all changeable options, and enables records to be made of any changes made to the pass code or other settings. It provides a convenient reference should future changes be required.

Sub-menu	Changeable settings	Factory settings	Customer settings	Further changes
Basic data	Dryness fraction	1.0		
	Units	Metric		
	Nominal pressure			
	Atmospheric pressure	1.01 bar a		
Outputs	4-20 mA			
	Source data	Flow		
	4 mA setting	0		
	20 mA setting	Flowmeter maximum @ 32 bar g		
	Pulse	ON		
	Source data	Total		
	Number of pulses	1 per kg		
	Pulse width	50 mS		
Error		High		
Pass code		7452		