

UTM20 Series Ultrasonic Transit-time Flowmeters

Installation and Maintenance Instructions



Contents

1. Scope of This Manual

1.1	Typographic Conventions	6
-----	-------------------------	---

2. Unpacking and Inspection

3. Safety

3.1	Terminology and Symbols	7
3.2	Considerations	

4. Introduction

5. Dimensions

5.1	Remote Enclosure	9
5.2	Wall Mount Bracket	
5.3	Panel Mount Enclosure	10

6. Operation

6.1	Keypad Operation on the Home Screen	11
6.2	Keypad Operation in the Menu Structure	12
6.3	Selecting an Option in a Parameter Selection List	13
6.4	Entering a Number	14

7. Installation

7.1	Overview	
7.2	Installation Considerations	15
7.3	Equipment Required	
7.4	Installing the Transducers	
7.5	Installing a Meter with a Remote Transmitter and Fixed Transducers	16
7.6	Installing a Meter with a Remote Transmitter and Adjustable Transducers	20
7.7	Installing a Panel-Mount Meter	24

8. Wiring the Transmitter

8.1	Torque Requirements	26
8.2	Electrical Symbols	
8.3	Connection Data	27
8.4	Rated Conditions of Terminals	
8.5	Wiring the Transducer	28
8.6	Power	30
8.7	9 to 28V DC Power	
8.8	20 to 26V AC Power	31
8.9	Mains Power	32
8.10	4 to 20 mA Output Wiring	33
8.11	Digital Outputs Wiring	34
8.12	RS485 Output	36
8.13	Digital Input Wiring	
8.14	AquaCUE/BEACON Endpoint Wiring	37
8.15	RTD Interface Wiring (Energy Models Only)	
8.16	Auxiliary Output Card Wiring	39
8.17	Installing the MicroSD Card	40
8.18	Connecting the USB Cable	
8.19	Initial Meter Setup	41

9. Menu Map

10. Parameter Descriptions by Menu

10.1	Main Menu Structure	44
10.2	Setup > Units	
10.3	Setup > Meter	48
10.4	Setup > Meter > Pipe	49
10.5	Setup > Meter > Fluid	
10.6	Setup > Meter > Spacing	50
10.7	Setup > Meter > Flow Setup	
10.8	Setup > Meter > Advanced	51
10.9	Setup > Meter > Calibration	55
10.10	Setup > Input/Output > Current #1 (or Current #2)	56
10.11	Setup > Inputs/Output > Output #1 (or Output #2 or Output #3)	57
10.12	Setup > Inputs/Output > Aux Output #1 (or Aux Output #2)	60
10.13	Setup > Inputs/Output > Input	
10.14	Setup > Inputs/Output > RTD (Energy Models Only)	61
10.15	Setup > Communications	62
10.16	Setup > Data Logging (Service Level Access)	66
10.17	Setup > Options	
10.18	Setup > Passcode Setup > Security	67
10.19	Setup > Passcode Setup > Passcode Recovery	68
10.20	Display Menu	69
10.21	Information Menu	
10.22	Diagnostics Menu	70
10.23	Reset Menu	73

11. Troubleshooting

11.1	Out of Specification Messages	
11.2	Error Messages	74
11.3	Check Function Codes	
11.4	View Alarm and Message Buffer	
11.5	Warning and Alarm Message Codes	75
11.6	Symptoms	80

12. Replacement Procedures

12.1	Replacing an AC Module	82
12.2	Replacing the Communication or Dry Contact Board	83
12.3	Replacing the Main Board	
12.4	Firmware Update	84

13. Specifications

13.1	System	85
13.2	Transmitter	86
13.3	Transducers	88
13.4	RTD Kits	
13.5	SoloCUE Flow Device Manager Software	89

14. Part Number Construction

14.1	UTM20 Flow Meters for Pipes 2" and Smaller	90
14.2	UTM20 Flow Meters for Pipes 2" and Smaller for Class I, Div 2 Hazardous Locations	92
14.3	UTM20 Flow Meters for Pipes 25" and Larger	94
14.4	UTM20 Flow Meters for Pipes 25" and Larger for Class I, Div 2 Hazardous Locations	96
14.5	UTM20 Flow Meters for Pipes Larger than 2" for ATEX/EICEx Hazardous Locations	98
14.6	UTM20 Energy Meters for Pipes 2" and Smaller	100
14.7	UTM20 Energy Meters for Pipes 25" and Larger	102

15. North American Pipe Schedules

1. Scope of This Manual

This manual is intended to help you get the UTM20 meter up and running quickly. Read this manual carefully before attempting any installation or operation. Keep the manual accessible for future reference.

1.1 Typographic Conventions

-
- In step-by-step instructions, bold text indicates items on the screen you need to select or act upon.
Example: Click the Setup menu.
 - Names of parameters, options, boxes, columns and fields are italicized.
Example: The value displays in the Status field.
 - Messages and special markings are shown in quotation marks.
Example: "Error" displays in the title bar.
 - In most cases, software screen text appears in the manual as it does on the screen. For example, if a word is capitalized on the screen, it is capitalized when referred to in the manual.
-

2. Unpacking and Inspection

Upon opening the shipping container, visually inspect the product and applicable accessories for any physical damage such as scratches, loose or broken parts, or any other sign of damage that may have occurred during shipment.

Note

If damage is found, request an inspection by the carrier's agent within 48 hours of delivery and file a claim with the carrier. A claim for equipment damage in transit is the sole responsibility of the purchaser.

3. Safety

3.1 Terminology and Symbols



Indicates a hazardous situation, which, if not avoided, will result in death or serious personal injury.



Indicates a hazardous situation, which, if not avoided, could result in death or serious personal injury.



Indicates a hazardous situation, which, if not avoided, could result in minor or moderate personal injury or damage to property.

3.2 Considerations

The installation of the UTM20 meter must comply with all applicable federal, state, and local rules, regulations, and codes.

Do not use sharp objects when operating the device (such as using a pen to press buttons on the keypad).

When the UTM20 meter is a part of a system, it is configured in a fail-safe operation so that if the transmitter signal is compromised, the UTM20 meter will not cause harm to the system.

Important

Not following instructions properly may impair safety of equipment and/or personnel.



After de-energizing, delay 5 minutes before opening.

4. Introduction

⚠ WARNING

This equipment includes some external non-metallic parts. The user shall therefore ensure that the equipment is not installed in a location where it may be subjected to external conditions (such as high-pressure steam) which might cause a build-up of electrostatic charges on non-conducting surfaces. Additionally, cleaning of the equipment should be done only with a damp cloth.

The UTM20 transit time meter measures volumetric flow and heating/cooling energy rates in clean liquids as well as those with small amounts of suspended solids or aeration, such as surface water or sewage. UTM20 ultrasonic flow and energy meters clamp onto the outside of pipes and do not contact the internal liquid.

The UTM20 meter is available in two versions:

-
- A flow meter for water delivery, sewage, cooling water, alcohols, chemical
 - A heating/cooling energy flow meter used in conjunction with dual clamp-on RTDs for temperature measurement—ideal for hydronic process and HVAC applications
-

Transit time flow meters measure the time difference between the travel time of an ultrasound wave going with the fluid flow and against the fluid flow. The time difference is used to calculate the velocity of the fluid traveling in a closed-pipe system. The transducers used in transit time measurements operate alternately as transmitters and receivers. Transit time measurements are bi-directional and are most effective for fluids that have low concentrations of suspended solids and are sonically conductive.




Fig. 1 Meter operation

An ultrasonic meter equipped with heat flow capabilities measures the rate and quantity of heat delivered or removed from devices such as heat exchangers. By measuring the volumetric flow rate of the heat exchanger liquid, the temperature at the inlet pipe and the temperature at the outlet pipe, the energy usage can be calculated.

By applying a scaling factor, this heat flow measurement can be expressed in various units (Btu, Watts, Joules, Kilowatts and others).

5. Dimensions

Note: Installation instructions begin on page 15.

5.1 Remote Enclosure




Fig. 2

5.2 Wall Mount Bracket




Fig. 3

UTM20 Series Ultrasonic Transit-time Flowmeters

5.3 Panel Mount Enclosure




Fig. 4

6. Operation

6.1 Keypad Operation on the Home Screen



Fig. 5



The MENU/BACK key enters menu structure.



The DOWN ARROW key toggles between flow rate, flow total, velocity and flow rate with flow total.



The RIGHT ARROW key has no function.



The ENTER key has no function.

6.2 Keypad Operation in the Menu Structure



Fig. 6

The cursor bar highlights the submenu or parameter that will be viewed or edited. The scroll bar on the right indicates the relative position the cursor bar is at on the list when there are more than 4 items.

- MENU/BACK returns to parent menu (up a level). If at the Main (top level) menu, returns to the Home Screen.
- DOWN ARROW scrolls the list.
- RIGHT ARROW and ENTER have the same function in the menu structure and advance to the submenu or to read/edit a parameter.

6.3 Selecting an Option in a Parameter Selection List



Fig. 7

The active option in the parameter list has a filled-in box on the left side. The scroll bar on the right indicates the relative position the cursor bar is at on the list when there are more than 4 items.

- DOWN ARROW scrolls the list.
- ENTER selects the option and the box on the left side fills in to show the item is selected.
- MENU/BACK exits parameter editing and returns to the parent menu (up a level).

6.4 Entering a Number



Fig. 8

The parameter name and current value is displayed in the top portion of the screen. Edit the number on the bottom right of the screen.

- MENU/BACK exits parameter editing and returns to parent menu (up a level). The parameter remains at the value displayed in the top portion of the screen.
- DOWN ARROW cycles through the numbers and other options.
- RIGHT ARROW moves the cursor to the right. Once it reaches the rightmost digit or a space, the cursor moves to the leftmost digit.
- ENTER accepts the value.

7. Installation

7.1 Overview

Each of the installation steps that follow is explained on the following pages. The actual installation procedures differ slightly, depending on whether the transducers are fixed or adjustable.

If the transducers are fixed, you will:

1. Install the transducers.
2. Install the transmitter.
3. Wire the transmitter.
4. Program the meter.

If the transducers are adjustable, you will:

1. Install the transmitter.
2. Wire the transmitter.
3. Set up the meter (select the optimum transmission mode, enter the site information, and enter the fluid and pipe properties).
4. Install the transducers.
5. Complete the meter programming.

7.2 Installation Considerations

Mount the transmitter in a location:

- Where little vibration exists.
- That is protected from corrosive fluids.
- That is within the transmitters ambient temperature limits:
-4 to 140 °F (-20 to 60 °C); relative humidity 0 to 85%, non-condensing; altitude 2000 m max.
- That is out of direct sunlight. Direct sunlight may increase transmitter temperature above the maximum limit.
- That protects the oleophobic vent from materials that may plug or seal the vent.

7.3 Equipment Required

- Screwdrivers, wide blade and tiny blade (for securing wires to the terminal blocks)
- User manual for the transducers
- Four #8 or M4 screws, if mounting the transmitter on a wall
- Stainless steel banding straps, if mounting the transmitter on a pipe

7.4 Installing the Transducers

See the user manual for your particular transducer for installation instructions.

7.5 Installing a Meter with a Remote Transmitter and Fixed Transducers

Locate the transmitter within the length of the transducer cables supplied or exchange the cable for one of proper length.

See the dimensions section for enclosure and mounting dimension details. Allow enough room for door swing, maintenance and conduit entrances.

Important

When routing wires to the transmitter, make sure the cables are not twisted, pinched or hanging loosely.

1. Install the fixed transducers according to instructions in the transducer user manual.
2. Attach the mounting bracket to a wall (with 4 customer-supplied #8 or M4 screws, see "Wall Mount Bracket" in dimensions) or to a pipe (with mounting straps).




Fig. 9




Fig. 10

3. Align the transmitter's bracket with the mounted bracket. Use a 4 mm hex tool to secure the 4 provided screws from the sides through the mating holes. See Figure 9.
4. If necessary, you can rotate the mounting bracket in 90° increments to accommodate the final orientation of the transmitter. From inside the enclosure, remove the 4 screws holding the bracket. Rotate the bracket and replace the screws. See Figure 10.




Fig. 11




Fig. 12

5. Insert a wire for earth ground under the grounding bracket (see Figure 12) and screw it down tight.
6. Partially loosen the 2 enclosure captive screws on the left side of the transmitter cover. Completely loosen the 2 screws on the right side. Grasp and lift the cover and open it to the left. The cover remains attached and the left screws act as a hinge.




Fig. 13




Fig. 14




Fig. 15

7. Use conduit holes where cables enter the enclosure from the bottom. Use suitably certified plugs to seal any holes that are not used for cable entry. A cable gland kit is included for inserting the transducer and power cables.




Fig. 24

Note: Use suitably certified fittings/plugs to maintain the watertight integrity of the enclosure. Generally, the right conduit hole (viewed from front) is used for power, the left conduit hole for transducer connections, and the center holes are used for I/O wiring.

8. Install the wires through the gland nuts and connect the wires to the removable terminal blocks. See "Wiring the Transmitter" on page 26.
9. Wire the transducers to the transmitter.
10. Plug the wired terminal blocks into the main board.
11. Reassemble the cover. Torque the cover screws to 45 in-lb.
12. Set up the meter. See "Initial Meter Setup" on page 41 for instructions.

7.6 Installing a Meter with a Remote Transmitter and Adjustable Transducers

- Locate the transmitter within the length of the transducer cables supplied or exchange the cable for one of proper length.
- Install the transducers after entering the pipe settings into the transmitter and determining the spacing and mounting method.
- See pages 9 and 10 for enclosure and mounting dimension details. Allow enough room for door swing, maintenance and conduit entrances.

Important

When routing wires to the transmitter, make sure the cables are not twisted, pinched or hanging loosely.

1. Attach the mounting bracket to a wall (with 4 customer-supplied #8 or M4 screws, see "Wall Mount Bracket" on page 9 for dimensions) or to a pipe (with mounting straps).
2. Align the transmitter's bracket with the mounted bracket. Use a 4 mm hex tool to secure the 4 provided screws from the sides through the mating holes. See Figure 19 .




Fig. 17




Fig. 18

3. If necessary, you can rotate the mounting bracket in 90° increments to accommodate the final orientation of the transmitter. From inside the enclosure, remove the 4 screws holding the bracket. Rotate the bracket and replace the screws. See Figure 17.




Fig. 19




Fig. 20

4. Insert a wire for earth ground under the grounding bracket (see Figure 20) and screw it down tight.
5. Partially loosen the 2 enclosure captive screws on the left side of the transmitter cover. Completely loosen the 2 screws on the right side. Grasp and lift the cover and open it to the left. The cover remains attached and the left screws act as a hinge.




Fig. 21




Fig. 22




Fig. 23

6. Use conduit holes where cables enter the enclosure from the bottom. Use suitably certified plugs to seal any holes that are not used for cable entry. A cable gland kit is included for inserting the transducer and power cables.




Fig. 24

Note: Use suitably certified fittings/plugs to maintain the watertight integrity of the enclosure. Generally, the right conduit hole (viewed from front) is used for power, the left conduit hole for transducer connections, and the center holes are used for I/O wiring.

7. Install the wires through the gland nuts and connect the wires to the removable terminal blocks. See "8. Wiring the Transmitter"
8. Set up the meter. See "Initial Meter Setup" on page 41 for instructions.
9. Install the adjustable transducers according to instructions in the transducer user manual.
10. Wire the transducers to the transmitter.
11. Plug the wired terminal blocks into the main board.
12. Reassemble the cover. Torque the cover screws to 45 in-lb.

7.7 Installing a Panel-Mount Meter

1. Measure and cut a mounting hole into the customer-supplied panel to the dimensions seen below .
2. Remove the 4 screws and 4 'O' rings holding the front of the unit to the frame.
3. Verify that the gasket is secure in the mounting bezel.
4. Guide the front of the unit through the panel cutout.
5. Insert the 4 screws through the front of the unit and the panel.
6. Apply one 'O' ring to each screw from the back of the panel.
7. Align the front of the unit to the frame.
8. Tighten the 4 screws and torque them to 45 in-lb.




Fig. 25 Panel cut out dimensions




Fig. 26 Installation exploded view

8. Wiring the Transmitter

Important:

Select field wiring means rated for 5 °C above the maximum area temperature when it is possible that the temperature will exceed 55 °C.

To access terminal strips for wiring, loosen the 4 enclosure captive screws. Grasp and lift the cover and open it to the left. The cover remains attached and the left screws act as a hinge.

8.1 Torque Requirements

The tightening torque requirements for the screw connections of the plug-in terminals are 4.4 lb-in. (0.5 Nm) minimum to 5.3 lb-in. (0.6 Nm) maximum.

8.2 Electrical Symbols






Function	Direct Current	Alternating Current	Earth (Ground)	Protective Ground	Chassis Ground
Symbol					

Fig. 27 Electrical symbols




Fig. 28 Wiring connectors

8.3 Connection data

Description	Minimum	Maximum
Conductor cross section solid	0.2 mm ²	2.5 mm ²
Conductor cross section flexible	0.2 mm ²	2.5 mm ²
Conductor cross section flexible, with ferrule without plastic sleeve	0.25 mm ²	2.5 mm ²
Conductor cross section flexible, with ferrule with plastic sleeve	0.25 mm ²	2.5 mm ²
Conductor cross section AWG	24	12
2 conductors with same cross section, solid	0.2 mm ²	1 mm ²
2 conductors with same cross section, stranded	0.2 mm ²	1.5 mm ²
2 conductors with same cross section, stranded, ferrules without plastic sleeve	0.25 mm ²	1 mm ²
2 conductors with same cross section, stranded, TWIN ferrules with plastic sleeve	0.5 mm ²	1.5 mm ²
AWG according to UL/CUL	30	12

8.4 Rated Conditions of Terminals

- Mains AC 85 to 264V AC
Wire 18 to 12 AWG UL AWM 1007 Type 1007
- 9 to 28V DC, 20 to 26V AC
Wire 20 AWG UL AWM 1007 Type 1007
- Transducer Cables
Badger Meter supplied cable
- Digital Outputs/Inputs, Current Output, RS485, RTD or Encoder Interface
- Wire 28 to 12 AWG UL AWM 1007 Type 1007

8.5 Wiring the Transducer




Fig. 29 Wiring connections

Notes:

- Submersible transducer cables are larger diameter. Each cable requires a separate conduit hole. The standard yellow cable and high temperature cables are small enough to use a single cable gland with a 2-hole grommet.
- Transducer cables have two wire-color combinations. For the blue and white combination, the blue wire is positive (+) and the white wire is negative (-). For the red and black combination, the red wire is positive (+) and the black wire is negative (-). The transducer wires are labeled to indicate which pair is upstream or downstream.

1. Guide the transducer terminations through a conduit hole in the bottom of the enclosure.
2. Secure the transducer cable with the supplied conduit nut (if flexible conduit was ordered with the transducer).
3. Install the ferrite to the cable:
 - a. To open the ferrite, pull the fastener away from the body of the ferrite.
 - b. Wrap the cable tightly around half of the ferrite and place the cable into the groove.
 - c. Snap the ferrite shut.




Fig. 30

4. The terminals within the transmitter are screw-down barrier terminals. Connect the wires at the corresponding screw terminals in the transmitter. Observe upstream and downstream orientation and wire polarity. See below.




Fig. 31 Upstream/downstream transducer

8.6 Power

Connect power to the screw terminal block in the transmitter.

Low voltage power can use any available conduit hole in the enclosure.

Line voltage AC power must use the right conduit hole, which is aligned with the terminal block on the AC power board.

Use wiring practices that conform to local and national codes such as The National Electrical Code Handbook in the U.S.

CAUTION

Any other wiring method may be unsafe or cause improper operation of the transmitter

Note: This transmitter requires clean electrical line power. Do not operate this transmitter on circuits with noisy components (such as fluorescent lights, relays, compressors, or variable frequency drives). Do not use step-down transformers from high voltage, high amperage sources. Do not run signal wires with line power within the same wiring tray or conduit.

8.7 9 to 28V DC Power

The transmitter may be operated from a 9 to 28V DC source, as long as the source supplies a maximum of 8 Watts of power.

Connect the DC power to 9 to 28V DC In, power return, and chassis ground, as below .

Note: DC-powered transmitters are protected from major catastrophe with an internal 2.0 Amp slow-blow fuse. If this fuse is blown, replace the transmitter or return it to the factory for repair.

IMPORTANT: A Class II DC power supply is required.




Fig. 32 Power supply 9 to 28V DC

8.8 20 to 26V AC Power

The transmitter may be operated from a 20 to 26V AC source, as long as the source supplies a maximum of 8 Watts of power. Connect the AC power to 20 to 26V AC In, power return, and chassis ground, as below .

Note: 24V AC powered transmitters are protected from major catastrophe with an internal 2.0 Amp slow-blow fuse. If this fuse is blown, replace the transmitter or return it to the factory for repair.




Fig. 33 Power supply 20 to 28V AC

8.9 Mains Power

IMPORTANT: The measuring device does not have an internal circuit breaker. For compliance with IEC 61010-1, a switch in close proximity to the transmitter is required so that the power supply line can be easily disconnected from the mains.

The transmitter may be operated from 90 to 250V AC, 47 to 63 Hz, 24VA maximum power source.


Note: Mains AC-powered transmitters are protected with 1A, 250V AC, 5×20 mm, slow-blow, field-replaceable fuse.

⚠ WARNING

To prevent shorting out the mains AC power, you must replace the terminal block cover on the AC module after wiring the power.

Remove the terminal block covers before wiring and replace them after wiring:

1. Grasp the sides of the cover and gently pull it up.
2. Insert wires into the slots on the cover and screw them down to secure.
3. Align the cover in its original orientation over the terminal block and push down to connect.





Connect protective earth conductor to terminal 3.

Fig. 34 AC/DC power connections

8.10 4 to 20 mA Output Wiring

The 4 to 20 mA output transmits an analog current signal that is proportional to system flow rate. The 4 to 20 mA output can be internally or externally powered and can span negative to positive flow rates. Both current loops are ISOLATED from DC GND or Power.



8.11 Digital Outputs Wiring

Note: Control Output 3 available with Energy model only.




Fig. 37 Typical control out 1, 2 and 3 interface with internal pullups active




Fig. 38 Typical control out 1, 2 and 3 interface with external pullups passive

8.12 RS485 Output

The RS485 feature allows up to 126 transmitters to be placed on a single three-wire cable up to 4000 feet. All transmitters are assigned a unique numeric address that allows all of the transmitters on the cable network to be independently accessed. Either Modbus RTU or BACnet MS/TP protocol is used to interrogate the transmitters.

Flow rate and total can be monitored over the digital communications bus.

When a USB programming cable is connected, the RS485 and frequency outputs are disabled.




Fig. 39 Typical RS485 interface

8.13 Digital Input Wiring




Fig. 40 Digital input—reset totalizer

8.14 AquaCUE/BEACON Endpoint Wiring




Fig. 41 AquaCUE/BEACON wiring

8.15 RTD Interface Wiring (Energy Models Only)




Fig. 42 Two-wire RTD interface

(Note: Wire colors apply to Badger Meter PN 68996.)




Fig. 43 Three-wire RTD interface

(Note: Wire colors apply to Badger Meter PN 68996.)




Fig. 44 Four-wire RTD interface

8.16 Auxiliary Output Card Wiring




Fig. 45 Auxiliary output interface

8.17 Installing the MicroSD Card

⚠ WARNING

In a hazardous location where explosive gas or dust is present, disconnect the power before opening the enclosure and inserting or removing the microsd card. After the card is inserted or removed, close the enclosure before reapplying power.

1. In all locations, turn off power to the unit.
2. Remove the enclosure cover.
3. Put your finger in the groove of the tray and slide the tray downward. The tray springs open.




Fig. 46

4. Insert the MicroSD card.
5. Slide the cover up to close.
6. Replace the enclosure cover.

8.18 Connecting the USB Cable

Use a USB cable when connecting a UTM20 meter to a computer with SoloCUE® Flow Device Manager software.

⚠ WARNING

Do not use the mini usb port in a hazardous location where explosive gas or dust is present.
Do not open the transmitter while powered if water or spray could contact electronics or interior.

1. Open the enclosure cover.
2. Connect the USB cable to the mini USB port, aligning the pins in the cable with the holes in the port.
3. Program the transmitter.
4. Remove the USB cable and close the enclosure cover.

8.19 Initial Meter Setup

You can set up the meter using the UTM20 keypad or the SoloCUE Flow Device Manager software. This document addresses procedures using the UTM20 keypad. To use SoloCUE, see the "SoloCUE Flow Device Manager Installation Guide" available at www.badgermeter.com.

For in-depth parameter programming, see "Parameter Descriptions by Menu" on page 44.

1. Program the meter settings:

When using the keypad to set up the UTM20 meter to measure flow, press MENU/BACK to enter the main menu. In the SETUP > METER menu, enter the pipe characteristics, transducer, mounting and fluid, and record the calculated spacing as needed. Install transducer. See the transducer user manual for instructions.

2. Check calibration:

In the SETUP > METER > CALIBRATION menu, select Field for the Factor Mode. Enter the calibration and sensor factors from the transducers into the scale factor and sensor factor value.

3. Zero the meter:

Due to different pipe characteristics, the meter must be zeroed in order to maintain accuracy. The recommended method is to stop flow and make sure there is no flow before zeroing the meter. In situations in which that is not feasible, you may zero the meter while the flow is steady or enter the zero manually. Based on ZERO MODE, the SET ZERO option will be selectable.

a. If ZERO MODE is set to NO FLOW:

Check that the pipe is full of liquid and not flowing. Flow must be absolutely zero.

Securely close any valves and allow time for settling to occur.

Select SET ZERO-NO FLOW and click OK to set the new zero.

b. If ZERO MODE is set to STEADY FLOW:

Check that the pipe is full of liquid and flowing at a steady rate.

Select SET ZERO-FLOW and click OK to set the new zero.

4. Select temperature sensor (energy models only):

In the SETUP > INPUTS/OUTPUT > RTD menu, select the temperature sensor type, range and order for positive and negative energy calculations.

5. Select units:

In the SETUP > UNITS menu, select the units and format of flow rate, total and velocity, and for energy meters the energy rate, energy total and temperature.

6. Set up the flow settings:

In the SETUP > METER > FLOW SETUP menu, select flow direction, low and maximum flow cutoff, and minimum and maximum signal strength.

9. Menu Map

Note:

Passcode levels for write access to each menu are as follows:

(O) = Operator, Service or Admin

(S) = Service or Admin

(A) = Admin


If no passcode is entered, all parameters can still be read.


Home screen	
Flow Rate Flow Total Velocity Flow Rate / Flow Total *Energy Rate RecoveryPasscodeSetup	*Energy Total *Temp #1 / Temp #2 *Energy Rate / Delta Temp *Energy Rate / Energy Total Time / Date

1 Energy units only.	2 Optional card installed.	3 Based on selected option.	4 Available when security is enabled.
-------------------------	-------------------------------	--------------------------------	--

Press **V** to toggle the options.

MAIN MENU (Press to access this menu)

Press  to select a main menu option



10. Parameter Descriptions by Menu

10.1 Main Menu Structure

The transmitter's firmware has a hierarchical menu structure. See "Menu Map" on page 42 for a visual path to the parameters.

The five Main Menus used in the transmitter firmware are as follows:

Menu	Function
SETUP	Contains all of the configuration parameters for initially programming the transmitter to measure flow
DISPLAY	Configures transmitter display functions
INFORMATION	Displays system information, such as the model number and firmware version
DIAGNOSTICS	Displays system status and allows you to clear the history, reset to factory defaults and reboot the system
RESET	Resets the flow total or unlatches alarms

The following pages define the configuration parameters located in each of the menus.

10.2 Setup > Units

Use SETUP > UNITS to define the measurement standards for the transmitter. Contains all of the configuration parameters for setting the units and decimals for the readings and the totalizer mode. Requires operator level passcode or higher if security is enabled.

An asterisk (*) indicates the parameter default.

Units Submenus	Options/Descriptions			
FLOW UNITS	Select the flow rate units/interval displayed on the Home Screen FLOW UNITS are automatically converted into the selected option			
	Option	Units/Interval	Option	Units/Interval
	Fluid BBL/D	Fluid Barrels/Day (31 5 Gal)	GAL/S	US Gallons/Second
	IBBL/D	Imperial Fluid Barrels/Day (36 IG)	GAL/MIN	US Gallons/Minute
	L/S	Liters/Second	GAL/H	US Gallons/Hour
	L/MIN	Liters/Minute	MG/D	Million US Gallons/Day
	L/H	Liters/Hour	IG/S	Imperial Gallons/ Second
	M3/S	Cubic Meters/Second	IG/MIN	Imperial Gallons/ Minute
	M3/MIN	Cubic Meters/Minute	IG/H	Imperial Gallons/Hour
	M3/H	Cubic Meters/Hour	MIG/D	Million Imperial Gallons/Day
	FT3/S	Cubic Feet/Minute	OIL BBL/D	Oil Barrels/Day (42 Gal)
	FT3/MIN	Cubic Feet/Minute	AC-FT/D	Acre Feet/Day
	FT3/H	Cubic Feet/Hour		
	Custom	This selection is only available if Custom Units is enabled through SoloCUE Flow Device Manager Use SoloCUE to change the Custom Units		
FLOW DECIMALS	This is a numeric entry for the number of decimal places to display Default is 2 Options are 0 to 7			
FLOW TOTAL MODE	*GROSS FLOW FORWARD FLOW REVERSE FLOW NET FLOW		Any flow in forward and reverse direction Forward flow minus reverse flow A negative total results when reverse flow is greater than forward flow	

Units Submenus	Options/Descriptions			
FLOW TOTAL UNITS	Select the units for the flow total displayed on the Home Screen FLOW TOTAL UNITS are automatically converted into the selected option:			
	Option	Units	Option	Units
	GAL	US Gallons	Fluid BBL	Fluid Barrel (31.5 Gal)
	MGAL	Million US Gallons	L	Liter
	IGAL	Imperial Gallons	HL	Hectoliter
	AC-FT	Acre Foot	M3	Cubic Meters
	MIGAL	Million Imperial Gallons	FT3	Cubic Feet
	Oil BBL	Oil Barrels (42 Gal)		
	Custom	This selection is only available if Custom Units is enabled through SoloCUE Flow Device Manager Use SoloCUE to change the Custom Units		
FLOW TOTAL DECIMALS	This is a numeric entry for the number of decimal places to display Default is 0 Options are 0 to 7			
VELOCITY UNITS	Select the units for the velocity displayed on the Home Screen			
	*FT/S Feet/Second M/S Meters/Second			
ENERGY RATE UNITS (Energy Units Only)	Select the units for the energy rate displayed on the Home Screen ENERGY RATE UNITS are automatically converted into the selected option:			
	Option	Units	Option	Units
	BTU/H	Btu/hour	kJ/H	Kilojoules/hour
	kBTU/H	Thousand Btu/hour	MJ/H	Mega joules/hour
	MMBTU/H	Million Btu/hour	kCAL/H	Kilocalories/hour
	W	Watts	MCAL/H	Mega calories/hour
	*kW	Kilowatts	TON (RT)	Ton (Refrigeration) 1 Ton = 12,000 Btu/h
	MW	Megawatts		
ENERGY RATE DECIMAL (Energy Units Only)	This is a numeric entry for the number of decimal places to display Default is 2 Options are 0 to 7			
ENERGY TOTAL MODE (Energy Units Only)	FORWARD FLOW REVERSE FLOW NET FLOW *GROSS FLOW		Forward flow minus reverse flow A negative total results when reverse flow is greater than the forward flow Any flow in forward and reverse direction	

Units Submenus	Options/Descriptions			
ENERGY TOTAL UNITS (Energy Units Only)	Select the units for the energy total displayed on the Home Screen ENERGY TOTAL UNITS are automatically converted into the selected option:			
	Option	Units	Option	Units
	BTU	British Thermal Unit	kWH	Kilowatt Hour
	kBTU	Thousand Btu	MWh	Megawatt Hour
	MMBTU	Million Btu	kJ	Kilo Joules
	KCAL	Kilo Calories	MJ	Mega Joules
	MCAL	Mega Calories	TON-H	Ton-hour (Refrigeration)
ENERGY TOTAL DECIMALS (Energy Units Only)	This is a numeric entry for the number of decimal places to display Default is 2 Options are 0 to 7			
TEMPERATURE UNITS (Energy Units Only)	°F °C K			
DISPLAY MODE	Select the parameters to display on the Home Screen Alternatively, you can change the display from the Home Screen by pressing the DOWN button			
	*FLOW RATE	ENERGY TOTAL		
	FLOW TOTAL	TEMP #1 / TEMP #2		
	VELOCITY	ENERGY RATE / DELTA TEMPERATURE		
	RATE/TOTAL	ENERGY RATE / ENERGY TOTAL		
	ENERGY RATE	TIME / DATE		

10.3 Setup > Meter

Contains all of the configuration parameters for setting the meter Requires service level passcode or higher if security is enabled An asterisk (*) indicates the parameter default

Meter Submenus	Options/Descriptions	
TRANSDUCER	Select the transducer type:	
	UZ 2 MHZ	Option UZ when ordered with the UTM20 meter
	CX 2 MHZ	Options CA to CS and CZ when ordered with the UTM20 meter
	JZ / KZ EASYRAIL 1 MHZ	Options JZ and KZ when ordered with the UTM20 meter
	NZ / RZ / WZ 1 MHZ	Options NZ, WZ and RZ when ordered with the UTM20 meter
	HZ 1 MHZ	Option HZ when ordered with the UTM20 meter
	LZ / YZ 0.5 MHZ	Option LZ when ordered with the UTM20 meter
MOUNTING	For mounting options, see the transducer user manual Z PATH *V PATH W PATH	
Cx TYPE	DTTC TYPE is substituted for MOUNTING when TRANSDUCER DTTC is selected as the transducer type	
	CA: ½" ANSI CB: ¾" ANSI CC: 1" ANSI CD: 1¼" ANSI CE: 1½" ANSI CF: 2" ANSI CG: ½" COPPER CH: ¾" COPPER CJ: 1¼" COPPER CK: 1½" COPPER CL: 2" COPPER CM: ½" SS TUBE CN: ¾" SS TUBE CP: 1" SS TUBE CQ: 1¼" SS TUBE CR: 1½" SS TUBE CS: 2" SS IN TUBE CT: 1" COPPER	

10.4 Setup > Meter > Pipe

An asterisk (*) indicates the parameter default

Pipe Submenus	Options/Descriptions		
PIPE MATERIAL	STAINLESS 302/303	ALUMINUM	POLYPROPYLENE
	STAINLESS 304	BRASS NAVAL	HD POLYETHYLENE
	STAINLESS 304L	CARBON STEEL	LD POLYETHYLENE
	*STAINLESS 316	COPPER	PFA TEFLON
	STAINLESS 347	IRON - CAST	PVC CPVC
	STAINLESS 410	IRON - DUCTILE	PVDF
	STAINLESS 430		
PIPE TYPE	For the best accuracy, measure the outer diameter and wall thickness with a gauge and select MANUAL" or MANUAL MM		
	If you do not have a gauge, you can select an ASME/ANSI or ASTM definition Schedule, copper tubing and cast iron class are filtered based on pipe material selection		
	If stainless steel pipe, carbon steel, cvc, pcvc material is selected, the following pipe schedules are also available as applicable:		
	SCHEDULE STD	SCHEDULE 40	SCHEDULE 140
	SCHEDULE 5	SCHEDULE 60	SCHEDULE 160
	*SCHEDULE 10	SCHEDULE 80	SCHEDULE 180
	SCHEDULE 20	SCHEDULE 100	SCHEDULE STG
	SCHEDULE 30	SCHEDULE 120	
	If copper material is selected, the following types are also available:		
	TYPE K	TYPE M	TYPE L PIPE SIZE
	If cast iron pipe material is selected, the following classes are also available:		
	CLASS A	CLASS C	CLASS E CLASS G
	CLASS B	CLASS D	CLASS F CLASS H
	If ductile iron pipe material is selected, the following classes are also available:		
	CLASS 50	CLASS 52	CLASS 54 CLASS 56
	CLASS 51	CLASS 53	CLASS 55
	If aluminum or brass naval material is selected, the following is also available: PIPE SIZE (in")		
PIPE SIZE	Available only when PIPE TYPE is MANUAL; Numeric entry; min 0.5" (15 mm), max 300 in (7500 mm)		
PIPE SIZE NOMINAL	PIPE SIZE NOMINAL is substituted for PIPE SIZE when a schedule/tubing/class is selected Enumeration based on schedule; min 0.5" (15 mm), max 24" (610 mm) ½, ¾, 1, 1¼, 1½, 2, 2½, 3, 3½, 4, 6, 8, 10, 12, 14, 16, 18, 20, 24		
WALL THICKNESS	Numeric entry; *min 0.00, max 5" (125 mm); WALL THICKNESS is only useful for MANUAL METRIC and MANUAL"; It can be skipped for pipe schedule, tubing and classes		
LINER MATERIAL	NONE	HD POLYETHYLENE	TAR EPOXY
	ACRYLIC	LD POLYETHYLENE	PFE TEFLON
	ASBESTOS CEMENT	POLYPROPYLENE	GLASS PYREX
	EBONITE	POLYSTYRENE	FIBERGLASS EPOXY
	MORTAR	RUBBER	
LINER THICKNESS	Numeric entry; min 0.00, max 5 in (125 mm)		
I.D. SIZE	Numeric display in" or millimeters, based on PIPE TYPE		

UTM20 Series Ultrasonic Transit-time Flowmeters

10.5 Setup > Meter > Fluid

Fluid Submenus	Options/Descriptions				
FLUID	Water - Tap	Acetone	Ethylene Glycol 30%	Kerosene	Propylene Glycol 30%
	Raw Sewage	Ammonia	Gasoline	Methanol	Stoddard Solvent
	Water - Distilled	Benzene	Glycerin	Oil Diesel #1	Sulfuric Acid 96%
	Water - Sea 3 5%	Ethanol	Isopropanol	Oil Diesel #2	Hydrochloric Acid 36%
	Brine - 3 5%	Ethylene Glycol 100%	Jet Fuel A1/JP8	Propylene Glycol 100%	Hydrofluoric Acid 49%
	Brine - 10%	Ethylene Glycol 50%	Jet Fuel B/JP4	Propylene Glycol 50%	Custom
CUSTOM FLUID	SOUND SPEED	Numeric entry; Units ft/s or m/s based on velocity units			
	SPEED UNITS	Ft/s or m/s			
	SPECIFIC GRAVITY	Numeric entry; Specific gravity (density relative to water), pipe size and viscosity are used to calculate the Reynolds number The Reynolds number indicates whether the fluid is in turbulent, transition or laminar flow and the flow profile			
	VISCOSITY	Numeric entry; Units centipoise (cP) or mPa-s Dynamic viscosity of the fluid			
	VISCOSITY UNITS	Units centipoise (cP) or mPa-s			
	REFERENCE TEMP	Numeric entry, F or C Default 15 °C Reference temperature of viscosity and specific gravity			
	REF TEMP UNITS	F or C			
	SPECIFIC HEAT	Numeric entry; Units: joule/gram °C; min 0 01, max 65 0; Specific heat capacity is the heat capacity per unit mass of a material			

10.6 Setup > Meter > Spacing

An asterisk (*) indicates the parameter default

Spacing Submenus	Options/Descriptions
CALIBRATED SPACING	*Numeric display 0 to 300 units in" or millimeters, based PIPE settings The spacing required between two transducers based on the pipe parameters Take this measurement between the lines scribed into the side of the transducers or use the scale on the rails, if used See the transducer user manual For Cx transducers with fixed spacing, the parameter will not be shown

10.7 Setup > Meter > Flow Setup

An asterisk (*) indicates the parameter default

Flow Setup Submenus	Options/Descriptions
DIRECTION	*FORWARD REVERSE
BIDIRECTIONAL	*ENABLED DISABLED
LOW FLOW CUTOFF	Numeric entry Units and decimals are based on FLOW RATE UNITS Zero and positive values *0 0
SIGNAL CUTOFF	*30%
SIGNAL HIGH	*90%
MINIMUM FLOW	-10000 (default); min -2,000,000 Number of decimals points depends on Home Screen settings
MAXIMUM FLOW	10000 (default); max 2,000,000

10.8 Setup > Meter > Advanced

An asterisk (*) indicates the parameter default

HEAT CALCULATION (Energy meter only)	Dynasonics Calculation EN1434 TYPE Rate of Heat Delivery = $Q \times (T_{in} - T_{out}) \times C \times \rho$		
	Where:	Q =	Volumetric flow rate
		T _{in} =	Temperature at the inlet
		T _{out} =	Temperature at the outlet
		C =	Heat capacity
		ρ =	Density of fluid
DAMPING	*40 seconds	For detailed information on these parameters, see the paragraphs following this table	
SENSITIVITY	*60%		
HYSTERESIS	*5%		
BAD DATA REJECTION	*3		
FILTER METHOD	*Adaptive		
WAVE	• *AUTO automatically selects waveform based on flow speed and signal quality		
	• SIN CARROT TOP is best for low speed flow		
	• BEST BARKER is best for high speed flow		
TEMP COMPENSATION	*MANUAL TEMP #1 TEMP #2		Selection is only available for Energy meter For the Flow meter, manual temperature compensation is always on
MANUAL REF TEMP	Numeric entry -40 to 350 °F (-40 to 176 °C)		Temperature compensation adjusts the viscosity of the fluid used in Reynolds number compensation and the fluid speed of sound
REF TEMP UNITS	°F °C K	Select the units for the manual reference temperature	
REYNOLDS	*ENABLED DISABLED	Flow rate compensation based on fluid Reynolds number as the fluid changes from laminar to transitional to turbulent flow	

10.8.1 Filter Parameters

Filter Method (Default: Adaptive)

The UTM20 flow meter offers three levels of signal filtering:

- None imposes no filtering on the signal from the transducers
- Simple with Rejection uses Damping and Bad Data Rejection to filter the flow data
- *Adaptive filtering allows the meter's software routines to alter the filtering, depending on the variability of the transducer's signal. The Adaptive filter uses a combination of Damping, Bad Data Rejection, Sensitivity and Hysteresis to modify the flow input data

Damping (Range 0 to 100 Seconds; Default: 40 Seconds)

Damping is the approximate amount of time the filtering routines use to attain a 99% stable rate value. Generally, the higher the damping value, the more stable the rate readings are—but at the expense of response time.

Sensitivity (Range 0 to 100%; Default: 60%)

Sensitivity determines how fast the adaptive filtering responds to a change in rate. Increasing the sensitivity decreases the filtering, which allows the display to respond to rate changes more rapidly.

Hysteresis (Range 0 to 25%; Default: 5%)

Hysteresis creates a window around the average flow measurement reading, defining the limits at which the automatic damping increases occur. If the rate varies within the hysteresis window, greater damping occurs up to the maximum values set by the flow filter Damping entry. The filter also establishes a flow rate window where measurements outside of the window are captured by the Bad Data Rejection window. Enter the value as a percentage of actual flow rate.

For instance, a Hysteresis setting of 5% allows the flow to vary $\pm 5\%$ from the currently established flow rate without automatically decreasing the value of the Damping.

For example, if the average flow rate is 100 gpm and the Hysteresis is set to 10%, a filter window of 90 to 110 gpm is established. Successive flow measurements that reside within that window are recorded and averaged in accordance with the Damping setting. Flow readings outside of the window are rejected or accepted in accordance with the Bad Data Rejection setting. Filter settings for this example:

Filter Method	Adaptive
Damping	40 seconds
Sensitivity	60%
Hysteresis	10%
Bad Data Rejection	3




Fig. 47 Hysteresis window

Bad Data Rejection (Range 0 to 10 Samples; Default: 3)

The Bad Data Rejection setting is related to the number of successive readings that must be measured outside of a the Hysteresis value before the flow meter considers the new flow value valid. In this example, a Hysteresis setting of 10% produces a $\pm 10\%$ band centered on the current valid flow rate of 100 gpm.

The Bad Data Rejection setting is the number of successive samples that must be outside of the Hysteresis window before the flow meter considers the change in flow as real. Larger values are entered into the Bad Data Rejection window when measuring liquids that contain gas bubbles, as the gas bubbles tend to disturb the ultrasonic signals and cause more extraneous flow readings to occur. Larger Bad Data Rejection values tend to make the flow meter less responsive to rapid changes in actual flow rate.

In Figure 41, flow data falls outside the flow Hysteresis window but does not reach the minimum time specified in the Bad Data Rejection window. When data appears that is outside the Hysteresis band and shorter than the Bad Data Rejection window time, the data is rejected.




Fig. 48 Bad data (rejection)

The flow rate is again outside the original $\pm 10\%$ Hysteresis window, but the data exists for a time period greater than the Bad Data Rejection window. In this instance, the meter interprets the data as a new valid flow rate and moves the Hysteresis window to correspond with the new established flow rate.




Fig. 49 New valid flow data

10.9 Setup > Meter > Calibration

An asterisk (*) indicates the parameter default

Calibration Submenus	Options/Descriptions	
FACTOR MODE	FACTORY *FIELD	Select FIELD to set the zero and use the sensor and scale factors of the transducers
FACTORY SETTINGS	ZERO	The zero offset entered during factory calibration ZERO is for reference only and most likely the ZERO VALUE for your installation will be different from the factory ZERO Numeric display; *0 000 ns
	CAL FACTOR	One of two calibration factors unique to each transducer pair if the transmitter was used during factory calibration Numeric display # ###
	SENSOR FACTOR	One of two calibration factors unique to each transducer pair if the transmitter was used during factory calibration Numeric display # ###
ZERO MODE	MANUAL *NO FLOW STEADY FLOW	Due to different pipe characteristics, the meter must be zeroed in order to maintain accuracy The recommended method is to stop flow and make sure there is no flow before zeroing the meter In situations in which that is not feasible, you may zero the meter while the flow is steady or enter the zero manually Select the method to zero the meter
SET ZERO - NO FLOW	SET ZERO AT NO FLOW in process and confirmation screen	Check that the pipe is full of liquid and not flowing Flow must be absolutely zero Securely close any valves and allow time for settling to occur
SET ZERO - FLOW	SET ZERO AT FLOW in process and confirmation screen	Stabilize the flow to a steady level before zeroing the meter In situations where it is not possible to stop flow, use this method to zero the meter When selected, the meter will calculate the zero typically in 5 to 10 seconds and will indicate if the meter was successful or not in determining the flow
MANUAL ZERO	Numeric entry ## ### ns	Allows for manual entry of the zero value when ZERO MODE is MANUAL
ZERO VALUE	Numeric display ## ### ns	The zero offset used to calculate the flow rate If the meter is not zeroed after installation, this value will match the factory ZERO setting
SENSOR FACTOR	Numeric entry ## ### ns	The value used in calculating the zero value when zeroing the meter at steady flow This value can be found on the transducer label
SCALE FACTOR	Numeric entry	The factor used for linearizing the flow rate calculation when FIELD is selected for FACTOR MODE Enter the CAL FACTOR from the transducer

10.9.1 Factory Calibrated Procedure

Each transducer pair has a CAL FACTOR and SENSOR FACTOR on the label Verify FACTOR MODE is set to FIELD and enter the factors from the transducer into the CAL FACTOR and SENSOR FACTOR settings

Zero the meter after entering the CAL FACTOR and SENSOR FACTOR

10.9.2 Field Calibration Procedure

To calibrate the UTM20 flow meter, use a master meter or gravimetric test stand

- 1 Verify that FACTOR MODE is set to FIELD and the transducer sensor factor is entered into the SENSOR FACTOR setting
- 2 Set SCALE FACTOR set to 1
- 3 Run calibration test
- 4 Calculate the SCALE FACTOR
$$\text{SCALE FACTOR} = (\text{actual flow})/(\text{meter flow rate}) \text{ or } (\text{actual total})/(\text{meter total})$$
- 5 Enter the SCALE FACTOR

10.10 Setup > Input/Output > Current #1 (or Current #2)

Requires service level passcode or higher if security is enabled The current output, reset input and frequency/pulse/status output can be set up through the SETUP > INPUT/OUTPUT menus

An asterisk (*) indicates the parameter default

Current #1 Submenus	Options/Descriptions	
OUTPUT SOURCE	*FLOW RATE TEMPERATURE #1 TEMPERATURE #2 ENERGY FLOW VELOCITY SIGNAL STRENGTH TEST MODE DISABLED	Select the reading to be assigned to the 4 to 20 mA output Temperature and energy options only available with energy meter
RANGE	*4-20 mA 4-20 mA NAMUR 0-20 mA	Current range is NAMUR 43 compliant with lower measuring limit at 3.8 mA and upper limit at 20.5 mA and minimum alarm 3.5 mA and maximum alarm 22.6 mA
MIN VALUE	Enter the value of the reading at 4 mA Can also be the setting for the 0 mA setpoint when 4-20 mA RANGE is selected Units and decimal places based on parameter selected Negative numbers accepted	
MAX VALUE	Enter the value of the reading at 20 mA Units and decimal places based on parameter selected Negative numbers accepted	
FAILURE MODE	*MIN CURRENT MAX CURRENT LAST VALUE TEST CURRENT	When an Fxx error occurs, such as low signal strength, the transmitter will set the current output the selected value
FIXED VALUE	Enter the value for the current output when there is a failure mode This parameter is only displayed with FAILURE MODE is set to FIXED VALUE	
TEST CURRENT	Available only when OUTPUT SOURCE is in TEST MODE Default 12.00 mA To check the wiring to the control system or gauge, you can override the current output with a fixed current Numeric entry mA 0 to 22 mA	
TRIM 4 mA	Available only when OUTPUT SOURCE is in TEST MODE Set the test current to 4 mA or 0 mA, depending on the current range selected Adjusts output until PLC/DCS/BAS reads the desired value	
TRIM 20 mA	Available only when OUTPUT SOURCE is in TEST MODE Set the test current to 20 mA Adjusts output until PLC/DCS/BAS reads 20 mA	

10.11 Setup > Inputs/Output > Output #1 (or Output #2 or Output #3)

Output #1, Output #2 or Output #3 can operate independently as a frequency, totalizer pulse, direction status or alarm status output In the SETUP > INPUT/OUTPUTS > OUTPUT #1 (OR OUTPUT #2 OR OUTPUT #3) > MODE menu, select the MODE of operation Then go to the PARAMETERS menu to set up the operation for that MODE

Output #3 is available on the energy unit only An asterisk (*) indicates the parameter default

Output #1 Submenus	Options/Descriptions												
MODE	*FREQUENCY PULSE TOTAL FLOW DIRECTION ALARM DISABLED		FREQUENCY and PULSE TOTAL modes are not available with AUX OUTPUT #1 and #2 dry contact output										
PARAMETERS (Frequency Mode)	OUTPUT SOURCE	*FLOW RATE VELOCITY ENERGY FLOW (Energy meter only) TEST FREQUENCY	Select the reading to assign to the frequency output										
	VALUE AT 0 HZ	Numeric entry Units and decimal place based on parameter selected Negative numbers accepted Default -5000	Enter the maximum flow rate or velocity frequency that corresponds to maximum frequency flow rate or velocity Can be negative to indicate reverse flow The units of Maximum match the units in SETUP > MEASUREMENTS > FLOW UNITS Example 1: For a system that only has flow in one direction, the maximum flow rate is 100 gal/min, and the corresponding maximum frequency is 2000 Hz, set up the parameters to:										
	MAX VALUE	Numeric entry Units and decimal place based on source selected Negative numbers accepted Default 5000	<table><tr><td>Parameter</td><td>Value</td></tr><tr><td>Output Source</td><td>Flow Rate</td></tr><tr><td>Minimum</td><td>0 gal/min</td></tr><tr><td>Maximum</td><td>100 gal/min</td></tr><tr><td>Maximum Frequency</td><td>2000 Hz</td></tr></table>	Parameter	Value	Output Source	Flow Rate	Minimum	0 gal/min	Maximum	100 gal/min	Maximum Frequency	2000 Hz
	Parameter	Value											
	Output Source	Flow Rate											
Minimum	0 gal/min												
Maximum	100 gal/min												
Maximum Frequency	2000 Hz												
MAX FREQUENCY	Numeric entry Units in Hz Default 1 kHz	Example 2: For a system that flow is bidirectional, the flow rate ranges from -100 gal/min to 100 gal/min and the frequency at 100 gal/min is 2000 Hz, set up the parameters to:											
TEST FREQUENCY	Available when TEST MODE is selected for OUTPUT SOURCE To check the wiring to the control system or device, you can override the frequency output with a fixed frequency												

Output #1 Submenus	Options/Descriptions				
PARAMETERS (Pulse Total Mode)	OUTPUT SOURCE	*POSITIVE FLOW NEGATIVE FLOW BIDIRECTIONAL FLOW Also available for energy meters: POSITIVE ENERGY NEGATIVE ENERGY BIDIRECTIONAL ENERGY	Select whether the pulse output accumulates only on positive (forward) flow, only on negative (reverse) flow or anytime flow occurs regardless of the flow direction (bidirectional) For bidirectional, assign the direction status to the other output, if desired		
	SCALING FACTOR	Numeric entry Units and decimal place based on flow rate selection Default is 1 unit per pulse Enter the number of totalizer units per pulse The totalizer unit is in the SETUP > MEASUREMENTS menu For example, if the totalizer unit is gallons, setting the PULSES/UNIT to 10 transmits 1 pulse every 10 gallons Setting the SCALING FACTOR to 0.1 transmits 1 pulse every 0.1 gallons			
	PULSE WIDTH	Numeric entry 5 to 2000 ms Default 50 ms Enter the pulse width in milliseconds			
	PULSE STATE	*PULSE LOW PULSE HIGH	PULSE LOW, the pulse totalizer output remains in the off state and the voltage floats at the source voltage level When the pulse is triggered, the output turns on and the voltage drops to the low voltage level This setup uses the least power If the pulse needs to be at the high voltage level, use the PULSE HIGH option		
PARAMETERS (Flow Direction Mode)	OUTPUT SOURCE	*FLOW RATE ENERGY FLOW			
	DIRECTION	FORWARD ON *REVERSE ON For energy meters only: ENERGY FORWARD ENERGY REVERSE	Select whether the output is active when the flow is forward or reverse When the absolute value of the flow rate is below the cutoff, the output will not be active.		

Output #1 Submenus	Options/Descriptions		
PARAMETERS (Alarm Mode)	ALARM	*ERRORS ONLY HIGH FLOW LOW FLOW HI/ LO FLOW For energy meters only: HIGH ENERGY LOW ENERGY HI/LO ENERGY HIGH TEMP1 HIGH TEMP2 LOW TEMP1 LOW TEMP2	Select the flow condition or meter condition to trigger the alarm and turn on the output
	SET HIGH	Numeric entry Units and decimal place based on FLOW RATE selected Negative numbers accepted Default is 10000	Enter the value that the flow rate must be greater than in order to trigger an alarm SET HIGH is only visible/settable when ALARM is set to HIGH FLOW, OUT OF RANGE or ALL
	SET LOW	Numeric entry Units and decimal place based on FLOW RATE selected Negative numbers accepted Default is 0	Enter the value that the flow rate must be less than in order to trigger an alarm SET LOW is only visible/settable when ALARM is set to LOW FLOW, OUT OF RANGE or ALL
	LATCHING	*DISABLED ENABLED	When ENABLED, the output remains on after the alarm condition clears Resetting alarm latch turns off the output
	ANTI- CHATTER	SET DELAY	Enter how long the alarm condition must occur before activating the output to prevent nuisance trips Numeric entry Units: Milliseconds Default is 100 ms
		HYSTERESIS	Enter how long the alarm condition is cleared before resetting the output to prevent the output from chattering The parameter is only valid if LATCHING is DISABLED Numeric entry Default is 100 ms
		MIN ON-TIME	Numeric entry Units: Milliseconds Default is 200 ms
PULL UP RESISTOR	INTERNAL *EXTERNAL	See "Digital Outputs Wiring" on page 34	

10.12 Setup > Inputs/Output > Aux Output #1 (or Aux Output #2)

This menu shows only with card installed for AUTODETECT or CARD TYPE is set to AUX OUTPUT
An asterisk (*) indicates the parameter default.

Output #1 Submenus	Options/Descriptions		
MODE	FLOW DIRECTION ALARM DISABLED	FREQUENCY and PULSE TOTAL modes are not available with AUX OUTPUT card ALARM	
PARAMETERS (Flow Direction Mode)	OUTPUT SOURCE	*FLOW RATE ENERGY FLOW	
	DIRECTION	FORWARD ON *REVERSE ON For energy meters only: ENERGY FORWARD ENERGY REVERSE	Select whether the output is active when the flow is forward or reverse When the absolute value of the flow rate is below the cutoff, the output will not be active
PARAMETERS (Alarm Mode)	ALARM	*ERRORS ONLY HIGH FLOW LOW FLOW HI/LO FLOW For energy meters only: HIGH ENERGY LOW ENERGY HI/LO ENERGY HIGH TEMP1 HIGH TEMP2 LOW TEMP1 LOW TEMP2	Select the flow condition or meter condition to trigger the alarm and turn on the output
	SET HIGH	Numeric entry Units and decimal place based on FLOW RATE selected Negative numbers accepted Default is 10000	Enter the value that the flow rate must be greater than in order to trigger an alarm SET HIGH is only visible/settable when ALARM is set to HIGH FLOW, OUT OF RANGE or ALL
	SET LOW	Numeric entry Units and decimal place based on FLOW RATE selected Negative numbers accepted Default is 0	Enter the value that the flow rate must be less than in order to trigger an alarm SET LOW is only visible/ settable when ALARM is set to LOW FLOW, OUT OF RANGE or ALL
	LATCHING	*DISABLED ENABLED	When ENABLED, the output remains on after the alarm condition clears Resetting alarm latch turns off the output
	ANTI- CHATTER	SET DELAY	Enter how long the alarm condition must occur before activating the output to prevent nuisance trips Numeric entry Units: Milliseconds Default is 100 ms
		HYSTERESIS	Enter how long the alarm condition is cleared before resetting the output to prevent the output from chattering The parameter is only valid if LATCHING is DISABLED Numeric entry Default is 100 ms
		MIN ON-TIME	Numeric entry Units: Milliseconds Default is 200 ms

10.13 Setup > Inputs/Output > Input

An asterisk (*) indicates the parameter default

Input Submenus	Options/Descriptions	
MODE	DISABLED	Select the action to take when the input is active (based on the state)
	*RESET TOTAL	
	UNLATCH ALARM	
STATE	*ACTIVE ON HIGH	Select the voltage level to make the input active
	ACTIVE ON LOW	

10.14 Setup > Inputs/Output > RTD (Energy Models Only)


An asterisk (*) indicates the parameter default

RTD Submenus	Options/Descriptions		
TEMP SENSOR TYPE	Pt1000 2-WIRE Pt1000 3-WIRE Pt1000 4-WIRE	Pt100 2-WIRE Pt100 3-WIRE Pt100 4-WIRE	Select the temperature sensor type
RANGE	32 to 122 °F (0 to 50 °C) 32 to 212 °F (0 to 100 °C)	-40 to 392 °F (-40 to 200 °C) 4 to 86 °F (-20 to 30 °C)	Select the temperature range
DELTA TEMP	TEMP #1-TEMP #2 TEMP #2-TEMP #1		Select the order for positive and negative energy calculations
TRIM RTD #1	Adjust the offset for the temperature reading for RTD #1		See "Troubleshooting" on page 74 before adjusting the RTD input
TRIM RTD #2	Adjust the offset for the temperature reading for RTD #2		

10.14.1 Trimming the RTDs

- 1 Change the Home Screen on the transmitter to read the temperature of the RTDs
- 2 Connect a computer with SoloCUE Flow Device Manager software to the UTM20 transmitter In the Setup > Input tab, check the Temp Sensor Type and Range
- 3 With a constant temperature controlled heat source at the midpoint of the operating range, heat RTD 1 Allow time for the RTD to heat thoroughly
- 4 Compare the temperature of the heat source with the temperature reading of Temp 1 on the display In SoloCUE, adjust the Trim RTD 1 until Temp 1 matches the heat source temperature
- 5 Repeat steps #3 and #4 for RTD 2

Fig. 50
Trimming the RTDs



10.15 Setup > Communications

Requires service level passcode or higher if security is enabled For addressing information, see the "UTM20 Meter Modbus RTU Protocol" user manual or the "UTM20 Meter BACnet MS/TP Protocol" user manual, available at www.badgermeter.com

An asterisk (*) indicates the parameter default

Communication Submenus	Options/Descriptions	
EIA-485 TYPE	DISABLE *MODBUS RTU BACNET MS/TP	Either disable this feature or select a network type
MODBUS RTU SETTINGS (Displayed when MODBUS RTU is selected as the option for EIA-485 TYPE.)	ADDRESS	Numeric entry 1 to 254
	BAUD RATE	*AUTO, 9600, 19200, 38400, 57600, 76800, 115200
	ACCESS	WRITE/READ allows full access RESET/READ allows you to read any, but only write to Flow Total Reset (cannot set up meter) READ ONLY allows read only
	PARITY	*NONE ODD PARITY EVEN PARITY
	STOP BIT	*1 STOP BIT 2 STOP BITS
	RESISTOR	*DISABLED ENABLED
	WORD ORDER	BIG ENDIAN *LITTLE ENDIAN
	TIMEOUT	Numeric entry 0 to 10000 ms
BACNET MS/TP SETTINGS	MAC ADDRESS	Numeric entry 0 to 127
	BACNET ID	Numeric entry 0 to 4194303
	BAUD RATE	*9600, 19200, 38400, 57600, 76800, 115200
	ACCESS	WRITE/READ allows full access RESET/READ allows you to read any, but only write to Flow Total Reset (cannot set up meter) READ ONLY allows read only
	MAX MASTER	Numeric entry 1 to 127
	PARITY	*NONE ODD PARITY EVEN PARITY
	STOP BIT	*1 STOP BIT 2 STOP BITS
	RESISTOR	DISABLED *ENABLED

Communication Submenus	Options/Descriptions	
ENDPOINT	Select the settings to match the BEACON/AquaCUE settings. Only the flow total selected for the Home Screen will be sent. Energy totals are not supported.	
	DIAL COUNT	7, *8, 9, 10
	RESOLUTION	*OFF, 1, 10, 100, 1000, 10000, 0.1, 0.01, 0.001, 0.0001
	PROTOCOL	<div> <div>*DISABLED V1 V2 V3</div> <div>When an ORION endpoint is connected to the transmitter, select the settings to match the BEACON/AquaCUE settings. Only the flow total selected for the Home Screen will be sent. V1 protocol does not support dial counts above 7.</div> </div>
BACNET/IP (Shows only with card installed for AUTODETECT or CARD TYPE is set to BACNET/IP.)	WEBSERVER	Note: WEBSERVER is READ ONLY *ENABLED DISABLED
	CLIENT TIMEOUT	0 to 65,535 ms
	DEVICE INSTANCE	BACnet ID range: 0 to 99,999,999
	DHCP	*DISABLED ENABLED
	IP ADDRESS	Numeric entry ### ### ### ### Enter a value from 1 to 255 for the first value and 0 to 255 for the remaining values. Option not available if DHCP is enabled.
	SUBNET MASK	Numeric entry ### ### ### ### Enter each value from 0 to 255. Option not available if DHCP is enabled.
	GATEWAY	Numeric entry ### ### ### ### Enter a value from 1 to 255 for the first value and 0 to 255 for the remaining values. Option not available if DHCP is enabled.
	DNS PRIMARY	### ### ### ### Enter a value from 1 to 255 for the first value and 0-255 for the remaining values. It is not recommended to use static IP address in the range of 169.254.0.0 to 169.254.255.255 because clients may not be able to locate the DNS server.
	DNS SECONDARY	### ### ### ### Enter a value from 1 to 255 for the first value and 0 to 255 for the remaining values. It is not recommended to use static IP address in the range of 169.254.0.0 to 169.254.255.255 because clients may not be able to locate the DNS server.
	PORT	Use SoloCUE if you need to change the UDP port from the default setting: *AUTO NEGOTIATION 10 Mbit HALF DUPLEX 10 Mbit FULL DUPLEX 100 Mbit HALF DUPLEX 100 Mbit FULL DUPLEX
	ACCESS	WRITE/READ allows full access RESET/READ allows you to read any, but only write to Flow Total Reset (cannot set up meter) *READ ONLY allows read only

UTM20 Series Ultrasonic Transit-time Flowmeters

Communication Submenus	Options/Descriptions			
MODBUS TCP/IP	WEBSERVER	Note: WEBSERVER is READ ONLY *ENABLED DISABLED		
	CLIENT TIMEOUT	0 to 65,535 ms		
	WORD ORDER	BIG ENDIAN *LITTLE ENDIAN		
	DHCP	*DISABLED ENABLED		
	IP ADDRESS	Numeric entry ### ### ### ### Enter a value from 1 to 255 for the first value and 0 to 255 for the remaining values Option not available if DHCP is enabled		
	SUBNET MASK	Numeric entry ### ### ### ### Enter each value from 0 to 255 Option not available if DHCP is enabled		
	GATEWAY	Numeric entry ### ### ### ### Enter a value from 1 to 255 for the first value and 0 to 255 for the remaining values Option not available if DHCP is enabled		
	DNS PRIMARY	### ### ### ### Enter a value from 1 to 255 for the first value and 0 to 255 for the remaining values It is not recommended to use static IP address in the range of 169 254 0 0 to 169 254 255 255 because clients may not be able to locate the DNS server		
	DNS SECONDARY	### ### ### ### Enter a value from 1 to 255 for the first value and 0 to 255 for the remaining values It is not recommended to use static IP address in the range of 169 254 0 0 to 169 254 255 255 because clients may not be able to locate the DNS server		
	PORT	*AUTO NEGOTIATION 10 Mbit HALF DUPLEX 10 Mbit FULL DUPLEX 100 Mbit HALF DUPLEX 100 Mbit FULL DUPLEX		
	ACCESS	WRITE/READ allows full access RESET/READ allows you to read any, but only write to Flow Total Reset (cannot set up meter) *READ ONLY allows read only		

Communication Submenus	Options/Descriptions	
ETHERNET/IP (Shows only with card installed for AUTODETECT or CARD TYPE is set to ETHERNET/IP.)	WEBSERVER	Note: WEBSERVER is READ ONLY *DISABLED ENABLED
	DHCP	*DISABLED ENABLED
	IP ADDRESS	Numeric entry ### ### ### ### Enter a value from 1 to 255 for the first value and 0 to 255 for the remaining values Option not available if DHCP is enabled
	SUBNET MASK	Numeric entry ### ### ### ### Enter each value from 0 to 255 Option not available if DHCP is enabled
	GATEWAY	Numeric entry ### ### ### ### Enter a value from 1 to 255 for the first value and 0 to 255 for the remaining values Option not available if DHCP is enabled
	DNS PRIMARY	### ### ### ### Enter a value from 1 to 255 for the first value and 0 to 255 for the remaining values It is not recommended to use static IP address in the range of 169 254 0 0 to 169 254 255 255 because clients may not be able to locate the DNS server
	DNS SECONDARY	### ### ### ### Enter a value from 1 to 255 for the first value and 0 to 255 for the remaining values It is not recommended to use static IP address in the range of 169 254 0 0 to 169 254 255 255 because clients may not be able to locate the DNS server
	PORT	Use SoloCUE if you need to change the TCP or UDP port from the default setting:
		*AUTO NEGOTIATION 10 Mbit HALF DUPLEX 10 Mbit FULL DUPLEX 100 Mbit HALF DUPLEX 100 Mbit FULL DUPLEX
	ACCESS	WRITE/READ allows full access RESET/READ allows you to read any, but only write to Flow Total Reset (cannot set up meter) *READ ONLY allows read only

10.16 Setup > Data Logging (Service Level Access)

Requires service level passcode or higher if security is enabled

Due to FAT32 limitation on the microSD card, if the file size exceeds 4 GB, the log file will be closed and a new file started Both files will be accessible The name of the files are FILE0001.txt, FILE0002.txt, and so on Log files are automatically saved as txt files to the microSD card Before removing the microSD card, change the LOG MODE to DISABLED With an 8 GB microSD card installed, the card will have enough memory to last about 1-1/2 years when logging 8 parameters at a 1 second time interval

Data Logging Submenus	Options/Descriptions		
LOG MODE	Log files can be transferred to a computer by using SoloCUE Data logging will pause during the file transfer New log file created when parameters are added or removed from data log *DISABLED		
	CONTINUOUS	Logs when transmitter is on and operating	
	THRESHOLD	Logs when the threshold value is between the minimum and maximum values For example, only log when process equipment is operational and flow is above cutoff	
TIME INTERVAL	1 SECOND	1 MINUTE	1 HOUR
	2 SECONDS	2 MINUTES	2 HOURS
	5 SECONDS	5 MINUTES	4 HOURS
	10 SECONDS	10 MINUTES	6 HOURS
	20 SECONDS	30 MINUTES	12 HOURS
	30 SECONDS	24 HOURS	
PARAMETER #1 to . PARAMETER #8	Note: For error/alarm codes, the last 10 codes in the history are logged with commas separating the values		
	FLOW RATE	DELTA TRANSIT TIME	ENERGY TOTAL FORWARD
	FLOW TOTAL GROSS	TEMPERATURE #1	ENERGY TOTAL REVERSE
	FLOW TOTAL FORWARD	TEMPERATURE #2	ENERGY TOTAL NET
	FLOW TOTAL REVERSE	TEMP#1 - TEMP#2	SIGNAL STRENGTH
	FLOW TOTAL NET	TEMP#2 - TEMP#1	SOUND SPEED
	VELOCITY	ENERGY RATE	ERROR/ALARM CODE
	REYNOLDS	ENERGY TOTAL GROSS	NONE
THRESHOLD	If THRESHOLD control is selected, this setting will be active		
	FLOW RATE FLOW TOTAL TEMPERATURE #1	TEMPERATURE #2 DELTA TEMPERATURE ENERGY RATE	ENERGY TOTAL VELOCITY
MIN THRESHOLD	Numeric entry (plus or minus)	If THRESHOLD log model is selected, this setting will be active	
MAX THRESHOLD	Numeric entry (plus or minus)	If THRESHOLD log model is selected, this setting will be active	
DELETE LOG	Will stop recording and delete all records Prompt with a confirmation screen		

10.17 Setup > Options

Options Submenu	Options/Descriptions
CARD TYPE	<p>If CARD TYPE is set to AUTODETECT, the transmitter will automatically detect when a new card is installed and display menu for the card settings. If CARD TYPE is set to a specific communication/contact card, the card settings will remain for that card type even if it is not installed. If a different card is installed or no card is installed, a warning will be displayed on the Home Screen and the card will be inactive.</p> <p>If CARD TYPE is set to DISABLED, then the card connection will be disabled and the Ethernet and contact menus will not be displayed.</p> <p>DISABLED AUTODETECT BACNET/IP MODBUS TCP/IP ETHERNET/IP AUX OUTPUT</p>

10.18 Setup > Passcode Setup > Security

If SECURITY is enabled and you exit the MAIN MENU, you must re-enter your passcode to access the MAIN MENU again. Passcode Setup offers three levels of access. Read-Only access does not require a passcode:

- **ADMIN**—You must enter the fault ADMIN passcode 000000 to change security from DISABLE to ENABLE
- **OPERATOR**
- **SERVICE**

Security Submenus	Options/Descriptions	
SET ADMIN	6-digit passcode	Numeric entry
SET OPERATOR	6-digit passcode	Numeric entry
SET SERVICE	6-digit passcode	Numeric entry
LOGOUT TIMEOUT	1 MINUTE 5 MINUTES *10 MINUTES 20 MINUTES 30 MINUTES 60 MINUTES	When logout occurs, the display returns to the Home Screen

10.19 Setup > Passcode Setup > Passcode Recovery

An asterisk (*) indicates the parameter default

Passcode Setup Submenus	Options/Descriptions	
PASSCODE RECOVERY	Passcode recovery screen	
TEMPORARY PASSCODE	Numeric entry	After 20 attempts to enter the temporary passcode, you will be prompted to generate a new RECOVERY CODE
SECURITY	*DISABLED ENABLED	When SECURITY is enabled, you are prompted to set the service and operator passwords. If you do not, the defaults remain in place.

Only the ADMIN level can reset passcodes. If the ADMIN passcode is lost and the passcodes need to be reset, you can contact Badger Meter, provide a recovery code to the representative and request a temporary passcode.

To generate a recovery code:

- 1 Select PASSCODE RECOVERY
- 2 The next screen prompts you to generate a recovery code or cancel the request. When you request the code, it displays on the screen. Write the number in a safe place.
- 3 Press MENU/BACK and continue to operate the meter in read-only mode.

You will not be prompted to enter a passcode when you navigate the menus. You have the option of canceling the recovery process and continue to use the existing passcodes by entering the ADMIN passcode. The PASSCODE LEVEL in the DIAGNOSTIC menu will be set to RECOVERY until you successfully enter a new ADMIN passcode or cancel the recovery.

When you receive your temporary passcode, select SETUP > PASSCODE SETUP > TEMPORARY PASSCODE and enter your temporary passcode. You will automatically be prompted to enter a new ADMIN passcode (prompt will be either in the SoloCUE software utility or the front panel, depending on where the temporary passcode was entered). If you do not enter a new ADMIN passcode within 15 minutes, the recovery mode is canceled and you must request a new recovery code to reset the passcodes. TEMPORARY PASSCODE can be entered from the SoloCUE software utility or the front panel, regardless of what was used to start it.

10.20 Display Menu

Requires operator level passcode or higher if security is enabled An asterisk (*) indicates the parameter default

Display Submenus	Options/Descriptions	
LANGUAGE	*ENGLISH	English
	DEUTSCHE	German
	ESPAÑOL	Spanish
	FRANÇAIS	French
	ITALIANO	Italian
DECIMAL	## #,#	Select whether the decimal indicator is a period or a comma
DISPLAY TAG ID	*DISABLED ENABLED	Displays the TAG ID on the Home Screen Default is UTM20 Use SoloCUE to change the TAG ID
BRIGHTNESS	Select the display brightness 10 to 100% in increments of 10 Default is 70%	
CONTRAST	Adjust the screen contrast 12 to 37 Default is 24	
DIMMER	*ENABLED DISABLED	Enable the DIMMER to reduce the display BRIGHTNESS after the buttons are not pressed for the TIMEOUT period Select the BRIGHTNESS level Default is 10%
DIMMER LEVEL	OFF 10% 20% 30% 40% 50% 60% 70% 80% 90% 100%	Press any button to awaken the transmitter and return to normal BRIGHTNESS The buttons pressed will not be active for one second after the transmitter is awakened
TIMEOUT	5 MINUTES *10 MINUTES 20 MINUTES 30 MINUTES 60 MINUTES	
SET TIME	Numeric entry for 24 hour clock HH:MM	
SET DATE	Numeric entry for date YYYY-MM-DD	
DISPLAY TIME	24 HOUR AM / PM	Select format of the time to display on the Home Screen and on the SoloCUE dashboard
DISPLAY DATE	YYYY-MM-DD MM-DD-YYYY DD-MM-YYYY	Select format of the date to display on the Home Screen and on the SoloCUE dashboard

10.21 Information Menu

An asterisk (*) indicates the parameter default

Information Submenus	Options/Descriptions
VENDOR	BADGER METER
MODEL	UTM20
P.N.:	Badger Meter part number
S.N.	Serial Number
FW VERSION	Firmware Version xx xx xxx
CAL. DATE	Calibration Date YYYY-MM-DD
DATE CODE	Manufacture Date YYYY-MM-DD
TAG ID	16 characters

10.22 Diagnostics Menu

The DIAGNOSTICS menu displays system status and allows you to clear the history, reset to factory defaults and reboot the system An asterisk (*) indicates the parameter default

Diagnostics Submenus	Options/Descriptions		
READINGS	SIGNAL STRENGTH	Read-only numeric with message to indicate the quality of the ultrasonic signal	
	HISTORY	Chronological list of 120 past errors, alarms and warning messages	
	DELTA TIME FILTERED	Read-only ### ns	
	FLOW RATE RAW	Read-only unfiltered flow rate	
	FLUID SOUND SPEED	Read-only; Units are the same as VELOCITY; Measured ultrasound speed of the fluid	
	DELTA TIME RAW	Read-only ns	
	REYNOLDS NUMBER	Read-only; unitless	
	REYNOLDS FACTOR	Read-only; unitless	
	TEMPERATURE #1	Read-only; Energy meters only; Units are the same as the Home Screen.	
	TEMPERATURE #2	Read-only; Energy meters only; Units are the same as the Home Screen.	
	DELTA TEMPERATURE	The temperature difference between the two RTDs, either T1 - T2 or T2 - T1, according to the setting in INPUT/OUTPUT > RTD > DELTA TEMP	
	TOTAL OVERFLOW COUNT	Numeric integer	The TOTAL OVERFLOW COUNT increments each time the flow total exceeds the digits in the display
	ENERGY OVERFLOW	Numeric integer	The ENERGY OVERFLOW is a counter that increments each time the energy total exceeds the digits in the display

Diagnostics Submenus	Options/Descriptions		
INPUT/OUTPUT STATUS	CURRENT #1 OUTPUT	Read-only mA	
	CURRENT #2 OUTPUT	Read-only mA; Energy meters only	
	OUTPUT #1 STATUS	*ON OFF FREQUENCY PULSE DISABLED	Status of digital output If the output mode is ALARM or FLOW DIRECTION, then the output status ON or OFF is indicated Frequency and Pulse modes can operate too fast to view the ON and OFF state, so the mode is shown for the status
	OUTPUT #2 STATUS	ON OFF FREQUENCY PULSE DISABLED	
	OUTPUT #3 STATUS	ON OFF FREQUENCY PULSE DISABLED	Energy meters only
	AUX OUTPUT #1 STATUS	ON OFF PULSE DISABLED	Only with auxiliary contact output option
	AUX OUTPUT #2 STATUS	ON OFF PULSE DISABLED	Only with auxiliary contact output option
	INPUT STATUS	ON OFF	Status of digital input to reset totalizer or unlatch alarm
HARDWARE OPTIONS	CARD HARDWARE	NONE BACNET/IP MODBUS TCP/IP ETHERNET/IP DRY CONTACTS	Identifies the hardware type of communication card or contact card installed regardless of the settings
	MAC ADDRESS	xx:xx:xx:xx:xx:xx Read only Ethernet card must be installed and cable must be connected for the MAC Address to display	
	LINK STATUS	CONNECTED DISCONNECTED	Read only Ethernet link status if Ethernet card is installed and enabled

Diagnostics Submenus	Options/Descriptions		
SYSTEM (Requires service level passcode or higher if security is enabled.)	TIME	HH:MM:SS (24 hour clock)	Displays the time
	DATE	YYYY-MM-DD	Displays the date
	POWER ON TIME	In seconds	
	SIMULATION MODE	OFF 100% 90% 80% 70% 60% 50% 40% 30% 20% 10% 0%	<p>Flow Simulation provides output and display simulation based on a percentage of the full scale flow. Simulation will not accumulate the totalizers. The range of simulation includes 0 to 100% of the full scale flow.</p> <p>Use the Flow Simulation parameter to set the range of simulation in 10% increments.</p> <p>To change the Flow Simulation, from the INPUTS/OUTPUTS menu: 1 Select FLOW SIMULATION to view the Flow Simulation display 2 Click RIGHT ARROW to increment the percentage by 10, or click DOWN ARROW to decrement the percentage by 10.</p>
	PASSCODE LEVEL	READ ONLY OPERATOR SERVICE ADMIN RECOVERY	Defines the parameters, screens and actions available to a user confirmation screen
	CLEAR HISTORY	CLEAR HISTORY confirmation screen	Clears all alarms, warnings, errors and informational messages from the ALARM HISTORY buffer. This is typically done after startup or maintenance on the flow system is successfully completed.
	FACTORY RESET	FACTORY RESET confirmation screen	Resets all parameters to the values on the device when it was shipped from the factory. Any settings made will be reset.
	REBOOT	REBOOT confirmation screen	Reboots the device. The UTM20 meter does not require this manual REBOOT for any procedure, but it may be useful for system troubleshooting.

10.23 Reset Menu

Reset Submenus	Options/Descriptions
RESET FLOW TOTAL	Reset the FLOW TOTAL See the "Reset Flow Totalizer Procedure" below
UNLATCH ALARMS	Only available if alarm latch is enabled Unlatches output if alarm condition occurred and cleared See "Setup > Inputs/Output > Output #1 (or Output #2 or Output #3)" on page 57.

Reset Flow Totalizer Procedure

The flow meter accumulates the amount of flow passing through the meter into a flow totalizer To reset the flow total:

- 1 Press MENU/BACK
- 2 Select RESET from the Main Menu (Press DOWN to scroll through the list of options When RESET is the top item, press ENTER)
- 3 Select RESET FLOW TOTAL from the Reset menu (With RESET FLOW TOTAL as the top item, press ENTER)
- 4 Select OK to confirm reset

After selecting RESET FLOW TOTAL, you are prompted to confirm the reset of the flow total Press ENTER to confirm or press MENU/BACK to cancel

11. Troubleshooting

Warning and alarm messages are classified according to NAMUR 107 standards

11.1 Out of Specification Messages

Warning and alarm messages occur when the flow meter is operational, but the readings might be out of specification or an operator might need to take action. If a warning or alarm condition occurs, a warning/alarm icon with code will appear in the at the bottom of the Home Screen. The flow rate and flow total will continue to be displayed.

11.2 Error Messages

An error condition occurs when the flow rate cannot be determined, such as when the signal strength is too low. If an error condition occurs, the flow rate will be replaced with the "failed" icon, code and description.

If conditions cause multiple messages to occur, all messages will be saved to the history, but some messages may not be displayed. If an error condition occurs, warning and alarm messages will not be displayed. If multiple errors occur, each error message will cycle through and be viewable for 5 seconds. Similarly, if multiple warning or alarm conditions occur (but no error conditions), each message will cycle through and be viewable for 5 seconds.

Warning, Alarm and Error Messages automatically clear when the issue clears.

11.3 Check Function Codes

When the meter or outputs are in a test mode, a check function message appears at the bottom of the Home Screen.

11.4 View Alarm and Message Buffer

Up to 30 alarm or warning message codes are buffered on a first-in-first-out basis. To view the buffer, go to **DIAGNOSTICS > HISTORY**.

11.5 Warning and Alarm Message Codes

Failure Codes

Code	Description	Correction
F02 ELECTRONIC ERROR	Multiple watchdog timeouts occurred	Contact factory
F03 ELECTRONIC ERROR	Voltage levels are out of specification	Reboot transmitter; If error repeats, repair or replace transmitter
F10 LOW SIGNAL	Signal strength is below cutoff	Check for empty pipe, transducer spacing and parameter settings
F11 HIGH SIGNAL	Signal strength is oversaturated	Change transducer mounting for more paths or enable shunt resistor
F20 RTD #1 ERROR	Unable to detect RTD #1	Check wiring to RTD #1 connector
F21 RTD #2 ERROR	Unable to detect RTD #2	Check wiring to RTD #2 connector

Check Function Codes

Code	Description	Correction
C01 CURRENT TEST	Current output is in test mode	Change Current Output from Test Mode
C10 OUTPUT #1 FREQUENCY TEST	Output #1 is in frequency test mode	Change Output #1 from Test Mode
C11 OUTPUT #1 PULSE TEST	Output #1 is in pulse test mode	Change Output #1 from Test Mode
C12 OUTPUT #1 SWITCH TEST	Output #1 is forced on or off	Change Output #1 from Test Mode
C20 OUTPUT #2 FREQUENCY TEST	Output #2 is in frequency test mode	Change Output #2 from Test Mode
C21 OUTPUT #2 PULSE TEST	Output #2 is in pulse test mode	Change Output #2 from Test Mode
C22 OUTPUT #2 SWITCH TEST	Output #2 is forced on or off	Change Output #2 from Test Mode
C30 OUTPUT #3 FREQUENCY TEST	Output #3 is in frequency test mode	Change Output #3 from Test Mode
C31 OUTPUT #3 PULSE TEST	Output #3 is in pulse test mode	Change Output #3 from Test Mode
C32 OUTPUT #3 SWITCH TEST	Output #3 is forced on or off	Change Output #3 from Test Mode
C41 AUX #1 PULSE TEST	Aux Output #1 is in pulse test mode	Change Aux Output #1 from Test Mode
C42 AUX #1 SWITCH TEST	Aux Output #1 is forced on or off	Change Aux Output #1 from Test Mode
C51 AUX #2 PULSE TEST	Aux Output #2 is in pulse test mode	Change Aux Output #2 from Test Mode
C52 AUX #2 SWITCH TEST	Aux Output #2 is forced on or off	Change Aux Output #2 from Test Mode
C60 SIMULATION MODE	Meter is running flow simulation	Deactivate Simulation Mode

Out-of-Specification Codes

Code	Description	Correction
S01 ELECTRONIC WARNING	Fault detected and meter rebooted	Contact factory, update firmware, or repair or replace transmitter
S02 DEFAULT FAILED	Reset to factory defaults failed	Check calibration If it does not match the calibration settings on the transducer serial tag, enter field calibration settings Return to the Home Screen and continue to operate (if the reset to factory defaults is through the transmitter)
S03 LANGUAGE FILE CORRUPT	English only	Update firmware
S10 mA TOO HIGH	Flow or energy rate higher than flow rate at 20 mA output	Check the scaling of the Current #1 output
S11 mA TOO HIGH	Flow or energy rate higher than 20 mA	Check the scaling of the Current #2 output
S19 mA SUPPLY VOLTAGE ERR	Supply voltage out of range for 4-20 mA outputs	Check wiring
S20 FREQ HIGH	Value higher than max frequency output	Check the scaling of the frequency on Output #1
S21 FREQ HIGH	Value higher than max frequency output	Check the scaling of the frequency on Output #2
S22 FREQ HIGH	Value higher than max frequency output	Check the scaling of the frequency on Output #3
S30 PULSE HIGH	Pulse output is too fast for the pulse width	Check the scaling factor, units and pulse width of the pulse on Output #1
S31 PULSE HIGH	Pulse output is too fast for the pulse width	Check the scaling factor, units and pulse width of the pulse on Output #2
S32 PULSE HIGH	Pulse output is too fast for the pulse width	Check the scaling factor, units and pulse width of the pulse on Output 3
S33 PULSE HIGH	Pulse output is too fast for the pulse width	Check the scaling factor, units and pulse width of the pulse on Aux Output #1 dry contact
S34 PULSE HIGH	Pulse output is too fast for the pulse width	Check the scaling factor, units and pulse width of the pulse on Aux Output #2 dry contact
S40 HIGH FLOW	Flow rate is above high flow alarm setting	Check flow rate and Set High setting for Output #1
S41 HIGH FLOW	Flow rate is above high flow alarm setting	Check flow rate and Set High setting for Output #2
S42 HIGH FLOW	Flow rate is above high flow alarm setting	Check flow rate and Set High setting for Output #3

Code	Description	Correction
S43 HIGH FLOW	Flow rate is above high flow alarm setting	Check flow rate and Set High setting for Aux Output #1
S44 HIGH FLOW	Flow rate is above high flow alarm setting	Check flow rate and Set High setting for Aux Output #2
S45 LOW FLOW	Flow rate is below low flow alarm setting	Check flow rate and Set Low setting for Output #1
S46 LOW FLOW	Flow rate is below low flow alarm setting	Check flow rate and Set Low setting for Output #2
S47 LOW FLOW	Flow rate is below low flow alarm setting	Check flow rate and Set Low setting for Output #3
S48 LOW FLOW	Flow rate is below low flow alarm setting	Check flow rate and Set Low setting for Aux Output #1
S49 LOW FLOW	Flow rate is below low flow alarm setting	Check flow rate and Set Low setting for Aux Output #2
S50 TOTAL OVERFLOW	Accumulated flow total is greater than viewable digits	Check the totalizer units or reset the flow total to clear the overflow counter
S60 COMM TIMEOUT	Modbus master or BACnet device communication packet	Check master device poll rate and offline status Check wiring and termination resistor setting
S61 MODULE TIMEOUT	Network timeout	Check communication settings and wiring
S62 DISCONNECTED	Bluetooth connection timed out	—
S63 BLUETOOTH FAIL	Unable to initialize Bluetooth	Update firmware If error repeats, repair or replace transmitter
S64 MODULE FAILED	Unable to initialize module	Reseat module and reboot transmitter If error repeats, replace module
S65 MODULE MISMATCH	Module installed does not match settings	Replace module with correct module Check card type settings
S67 DATA LOG ERROR	microSD card is missing or full	Check microSD card If data logging is not required, disable data logging
S70 TEMP #1 LOW	Temp #1 is below low alarm setting	Check fluid temperature and RTD #1 Check alarm settings for Output #1
S71 TEMP #1 LOW	Temp #1 is below low alarm setting	Check fluid temperature and RTD #1 Check alarm settings for Output #2
S72 TEMP #1 LOW	Temp #1 is below low alarm setting	Check fluid temperature and RTD #1 Check alarm settings for Output #3
S73 TEMP #2 LOW	Temp #1 is below low alarm setting	Check fluid temperature and RTD #1 Check alarm settings for Aux Output #1
S74 TEMP #2 LOW	Temp #1 is below low alarm setting	Check fluid temperature and RTD #1 Check alarm settings for Aux Output #2

UTM20 Series Ultrasonic Transit-time Flowmeters

Code	Description	Correction
S75 TEMP #1 HIGH	Temp #1 is above high alarm setting	Check fluid temperature and RTD #1 Check alarm settings for Output #1
S76 TEMP #1 HIGH	Temp #1 is above high alarm setting	Check fluid temperature and RTD #1 Check alarm settings for Output #2
S77 TEMP #1 HIGH	Temp #1 is above high alarm setting	Check fluid temperature and RTD #1 Check alarm settings for Output #3
S78 TEMP #1 HIGH	Temp #1 is above high alarm setting	Check fluid temperature and RTD #1 Check alarm settings for Aux Output #1
S79 TEMP #1 HIGH	Temp #1 is above high alarm setting	Check fluid temperature and RTD #1 Check alarm settings for Aux Output #2
S80 HIGH ENERGY RATE	Flow rate is above high flow alarm setting	Check energy flow rate and Set High setting for Output #1
S81 HIGH ENERGY RATE	Flow rate is above high flow alarm setting	Check energy flow rate and Set High setting for Output #2
S82 HIGH ENERGY RATE	Flow rate is above high flow alarm setting	Check energy flow rate and Set High setting for Output #3
S83 HIGH ENERGY RATE	Flow rate is above high flow alarm setting	Check energy flow rate and Set High setting for Aux Output #1
S84 HIGH ENERGY RATE	Flow rate is above high flow alarm setting	Check energy flow rate and Set High setting for Aux Output #2
S85 LOW ENERGY RATE	Flow rate is above low flow alarm setting	Check energy flow rate and Set Low setting for Output #1
S86 LOW ENERGY RATE	Flow rate is above low flow alarm setting	Check energy flow rate and Set Low setting for Output #2
S87 LOW ENERGY RATE	Flow rate is above low flow alarm setting	Check energy flow rate and Set Low setting for Output #3
S88 LOW ENERGY RATE	Flow rate is above low flow alarm setting	Check energy flow rate and Set Low setting for Aux Output #1
S89 LOW ENERGY RATE	Flow rate is above low flow alarm setting	Check energy flow rate and Set Low setting for Aux Output #2
S90 TEMP #2 LOW	Temp #2 is below low alarm setting	Check fluid temperature and RTD #2 Check alarm settings for Output #1
S91 TEMP #2 LOW	Temp #2 is below low alarm setting	Check fluid temperature and RTD #2 Check alarm settings for Output #2
S92 TEMP #2 LOW	Temp #2 is below low alarm setting	Check fluid temperature and RTD #2 Check alarm settings for Output #3
S93 TEMP #2 LOW	Temp #2 is below low alarm setting	Check fluid temperature and RTD #2 Check alarm settings for Aux Output #1

Code	Description	Correction
S94 TEMP #2 LOW	Temp #2 is below low alarm setting	Check fluid temperature and RTD #2 Check alarm settings for Aux Output #2
S95 TEMP #2 HIGH	Temp #2 is above high alarm setting	Check fluid temperature and RTD #2 Check alarm settings for Output #1
S96 TEMP #2 HIGH	Temp #2 is above high alarm setting	Check fluid temperature and RTD #2 Check alarm settings for Output #2
S97 TEMP #2 HIGH	Temp #2 is above high alarm setting	Check fluid temperature and RTD #2 Check alarm settings for Output #3
S98 TEMP #2 HIGH	Temp #2 is above high alarm setting	Check fluid temperature and RTD #2 Check alarm settings for Aux Output #1
S99 TEMP #2 HIGH	Temp #2 is above high alarm setting	Check fluid temperature and RTD #2 Check alarm settings for Aux Output #2

Informational Events Codes

Information events are only displayed in the ALARM HISTORY and not on the Home Screen

Code	Description
I01 POWER ON	Power on or rebooted
I11 ZERO	Meter zeroed
I12 FACTORY CALIBRATION	Calibration changed from Field to Factory
I13 FIELD CALIBRATION	Calibration changed from Factory to Field
I21 FIRMWARE CHANGED	Firmware updated
I31 FLOW TOTAL RESET	Flow total reset to zero
I41 NO SD CARD	MicroSD card not installed

11.6 Symptoms

Symptom: Transmitter does not power up.	
Possible Causes	No power or inadequate power
	Blown fuse (AC Model only)
	Display ribbon cable not seated properly
Recommended Action	Measure voltage at the power terminals and check that the voltage matches the labels by the power terminals
	Check the fuse near the power terminals If fuse is blown, verify the voltage and polarity is correct and reset the fuse
	Inspect ribbon cable connections LED's on power board will light up with no LCD display
	Replace the transmitter if the above actions do not resolve the issue
Symptom: Flow reading appears to be incorrect.	
Possible Causes	Incorrect positioning of transducers
	Poor contact between transducers and pipe
	Poor placement of transducers
	Low signal strength
	Process loop issues
	Incorrect pipe settings
	Meter not calibrated
	Display not set up correctly
Recommended Action	Refer to the Transducer Mounting Configuration section for details on proper installation
	At the transducer:
	Verify that the spacing of the transducers is set correctly On most transducers, a scribe mark on the side of the transducers indicates the point of measurement—NOT from the end points of the transducers
	Verify that the transducers are aligned correctly For Z-Mount, verify the transducers are 180° From each other
	Make sure there is a good contact between the transducers and pipe and a thin coat of acoustic coupling is applied For integral mount, check for over-tightening of the transducers
	Process loop and general location:
	Make sure the transducers are on the sides of the pipe and NOT on the top of the pipe
	Check that the transducers are NOT located at the highest point in the loop where air may accumulate
	Check that the transducers are NOT on a downward flowing pipe unless adequate downstream head pressure is present to overcome partial filling or cavitation
	Check that the transducers have adequate straight pipe upstream and downstream
	Check process loop for entrained air or particulates which will impact the flow readings
	Pipes may develop scale, product build-up or corrosion over time As a result, the effective wall thickness may be different than a new pipe and wall thickness or liner parameters may need to be adjusted
	At the transmitter:
	Verify that pipe parameters match the installation

Symptom: Unstable flow.	
Possible Causes	Installation issues
	Flow instability
	Transducer mounting is loose
	Transducers are moved
	Incorrect flow settings
Recommended Action	Check process loop for variations of entrained air which will impact the flow
	Check for pump induced flow instability
	Check that the transducers are secure and are in area where the transducers will not be inadvertently bumped or disturbed
	Check low flow cutoff, minimum flow or maximum flow settings
Symptom: Flow readout is opposite of the flow direction.	
Possible Causes	Integral mount transmitter is mounted in reverse flow direction so display is properly oriented
	Up and down transducers wiring is reversed
	Flow direction parameter is reversed
Recommended Action	Change the transducer flow direction parameter
	Rewire the up and down transducers to the transmitter
Symptoms: Current, frequency or pulse outputs do not match the readings.	
Possible Causes	Incorrect parameter settings
	Wiring or control system configuration issues
Recommended Action	Verify that the parameters for the output are set properly

12. Replacement Procedures

WARNING

Disconnect power before opening the enclosure

Tools Required

- A Phillips #2 screwdriver
- A flat blade screwdriver
- Tweezers for electronics
- A workbench that prevents ESD damage to the electronics

CAUTION

Contains parts and assemblies susceptible to damage by electrostatic discharge (esd). Before picking up an esd-sensitive electronic component, discharge yourself by touching a grounded bare metal surface or approved anti-static mat.




Observe precautions for handling electrostatic-sensitive devices.

12.1 Replacing an AC Module

1. Turn off the power.
2. Open the enclosure.
3. Unplug the DC power wire connector from the terminal block on the main board.
4. Remove (2) M3 pan head phillips screws that secure the cover over the AC power terminal block.
5. Unplug the wire connector from the terminal block on the AC module.
6. Remove the remaining (4) M3 pan head phillips screws and lock washers that secure the AC module to the enclosure base.
7. Remove the AC module.

Installation is in the reverse order.

Fig. 51 Replacing an AC module




12.2 Replacing the Communication or Dry Contact Board

1. Turn off the power.
2. Open the enclosure.
3. Disconnect the wires from the communication board.
4. Remove (2) M3 pan head phillips screws that secure the cover over the communication board.
5. Remove the cover.
6. Remove the remaining (2) M3 pan head phillips screws that secure the communications board.
7. Lift the communications board straight out to unplug from the main board.

Installation is in reverse order, noting the following. To install a new communications board, align the pins with the header on the main board and gently press straight down. Do not misalign the pins. Do not use excessive force.

Fig. 52
Replacing the Communication or Dry Contact Board



12.3 Replacing the Main Board

1. Turn off the power.
2. Open the enclosure.
3. Remove the terminal blocks from the header on the main board.
4. If a communications board is present, remove it.
5. Remove the (4) M4 pan head phillips screws that secure the main board and shield.
6. Lift the shield off the main board.
7. Gently pull the main board straight out to disengage it from the display header and remove it from the enclosure lid.

Installation is in reverse order, noting the following. To install a new main board, align the pins on the display header with the socket on the main board and gently press straight down. Be careful not to misalign the pins. Do not use excessive force.




Fig. 53 Replacing the Communication or Dry Contact Board

12.4 Firmware Update

Firmware can be updated using SoloCUE Flow Device Manager software. Parameter and calibration settings will not be overwritten unless there is a conflict with the new parameters. Back up the device configuration prior to updating the firmware. See "UTM20 Firmware Update" (available at www.badgermeter.com) for more information.

13. Specifications

13.1 System

Liquid Types	Most clean liquids or liquids containing small amounts of suspended solids or gas bubbles	
Flow Accuracy	Medium and Large Pipes (RZ, NZ, WZ, HZ, LZ, YZ, JZ, KZ)	$\pm 0.5\% \pm 0.0049 \text{ ft/s}$ (0.015 m/s)
	Small Pipes (CA-CT, UZ)	1" (25 mm) and larger = $\pm 1\% \pm 0.03 \text{ ft/s}$ (0.009 m/s) 3/4" (20 mm) and smaller = $\pm 1\%$ of full scale
Repeatability	0.2% above 1.5 ft/s	
Velocity	Medium and Large Pipes	Up to 40 ft/s, depending on pipe and fluid
	Small Pipes	Up to 20 ft/s, depending on pipe and fluid
Straight Run Requirements	10 diameters upstream, 5 diameters downstream from single elbow	
Certification and Compliance	<p>General Safety (all models): cCSAus, CE, Pollution Degree 2, CE compliance to Low Voltage Directive, 2014/35/EU</p> <p>U.S./Canada Hazardous Location transmitter and transducers: Transmitter and transducers (certification option B): cCSAus Class I Division 2 Groups ABCD T4 Requires flexible conduit Not available with UZ, HZ or JZ and KZ (Easy Rail) transducers, Auxiliary Dry Contact card or units with AquaCUE/BEACON endpoints</p> <p>Transmitter (certification option R): cCSAus Ex ec ic nC IIC T4 Gc; Ex tc IIIB T100 °C Dc; Class I, Zone 2, AEx ec ic nC IIC T4 Gc; Zone 22, AEx tc IIIB T100 °C Dc; Class II, Division 2, Groups FG; Class III Not available with Auxiliary Dry Contact card or units with AquaCUE/BEACON endpoints</p> <p>Transducers LZ, NZ and RZ (certification option R): cCSAus Ex ec IIC T6 Gc; Ex tc IIIB T60 °C Dc; Class I, Zone 2, AEx ec IIC T6 Gc; Zone 22, AEx tc IIIB T60 °C Dc; Class II, Division 2, Groups FG; Class III Requires flexible conduit Not available with CA-CT, UZ, HZ or JZ and KZ (Easy Rail) transducers</p> <p>ATEX Hazardous Location: Transmitter (certification option V): II 3 G D Ex ec ic nC IIC T4 Gc; Ex tc IIIB T100 °C Dc; Tamb: -25 to 60 °C JZ (DTTJ), KZ (DTTK), LZ (DTTL), NZ (DTTN) and RZ (DTTR) Transducers: II 3 G D Ex ec IIC T6 Gc; Ex tc IIIB T60 °C Dc; Tamb: -25 to 60 °C Not available with UZ, CA to CT, or HZ transducers; flexible conduit, Auxiliary Dry Contact card or AquaCUE/BEACON endpoints</p> <p>IECEx Hazardous Location: Transmitter (certification option V): Ex ec nC ic IIC T4 Gc; Ex tc IIIC T100 °C Dc; Tamb: -25 °C to 60 °C JZ, KZ, LZ, NZ and RZ Transducers: Ex ec IIC T6 Gc; Ex tc IIIB T60 °C Dc; Tamb: -25 to 60 °C Not available with UZ, CA to CT, or HZ transducers; flexible conduit, Auxiliary Dry Contact card or AquaCUE/BEACON endpoints</p>	

13.2 Transmitter

Power Options	24V DC/AC	9 to 28V DC @ 8 W max or 20 to 26 AC 47 to 63 Hz @ 0.5 A max , 2 Amp slow-blow fuse, not field replaceable
	Mains AC	85 to 264V AC 47 to 63 Hz @ 24VA max 1 Amp slow-blow fuse, manually field replaceable Over-Voltage Rating Category II (CAT II)
Display	Options	Display with keypad or no display/keypad
	Keypad	4-button navigation, keypad with tactile feedback; polyester film
	Display	128 × 64 pixel LED backlit graphical display; adjustable brightness and timeout; polycarbonate window
	Flow rate/total	8-digit
Enclosure	NEMA Type 4X, IP67	
Construction	Aluminum construction; painted; wall, panel or pipe mounting; stainless steel fasteners and mounting hardware; EPDM gasket	
	Conduit Holes	(4) ½" NPT, M20 × 1.5 or 1/2 BSPP; cable glands available for NPT and M20
Environmental Ratings	Pollution Degree	2
	Altitude Restriction	Up to 2000 m (6561 ft)
	Ambient Temperature Range	-4 to 140 °F (-20 to 60 °C)
	Storage Temperature Range	-40 to 176 °F (-40 to 80 °C)
	Humidity	0 to 85%, non-condensing
Configuration	Via optional keypad or SoloCUE configuration software; SoloCUE available on DVD or download	
Units (Field-Selectable)	Velocity	feet/second, meters/second
	Volumetric total	US Gallons, Million Gallons, Imperial Gallons, Million Imperial Gallons, Acre-Feet, Liters, Hectoliters, Cubic Meters, Cubic Feet, Oil Barrels (42 gallons), Fluid Barrels (31.5 gallons), Imperial Fluid Barrels (36 imperial gallons), Pounds (Kilograms) and custom units
	Flow rate	Acre Feet/Day, Liters/Second, Liters/Minute, Liters/Hour, Cubic Meters/Second, Cubic Meters/Minute, Cubic Meters/Hour, Cubic Feet/Minute, Cubic Feet/Minute, Cubic Feet/Hour, Gallons/Second, Gallons/Minute, Gallons/Hour, Million Gallons/Day, Imperial Gallons/Second, Imperial Gallons/Minute, Imperial Gallons/Hour, Million Imperial Gallons/Day, Oil Barrels/Day, Fluid Barrels/Day, Imperial Fluid Barrels/Day and custom units
	Energy total (energy meters)	British Thermal Unit (Btu), Thousand Btu, Millions Btu, Kilocalories, Mega calories, Kilowatt-hour, Megawatt hour, Kilojoules, Mega joules, Ton-hour (Refrigeration)
	Heat/cooling rate (energy meters)	Btu/hour, Thousand Btu/hour, Millions Btu/hour, Ton (Refrigeration), Watts, Kilowatts, Megawatts, Kilojoules/hour, Mega joules/hour, Kilocalories/hour, Mega calories/hour
	Temperature (energy meters)	Fahrenheit, Celsius, Kelvin

UTM20 Series Ultrasonic Transit-time Flowmeters

		Flow Meter	Energy Meter
Inputs and Outputs	0/4 to 20 mA output	One 16-bit, isolated, max 800 Ohms, internal or external power	Two 16-bit, isolated, max 800 Ohms, internal or external power
	Digital input	One 5 to 30V DC, isolated, externally or internally sourced, reset totalizer or alarm output	
	Digital output	Two selectable pulse, alarm, flow direction, sink isolated open collector, 5 to 30V DC, max 50 mA externally or internally sourced, leakage current 1uA max	Three selectable pulse, frequency, alarm, flow direction, isolated open collector, 5 to 30V DC, externally or internally sourced, leakage current 1uA max
		Frequency output: 50% duty cycle, 63 to 10k Hz maximum frequency	
		Pulse (totalizer) output: 5 kHz max output, open collector, pulse width 5 to 500 ms programmable	
		Optional: Two dry contact output for alarm or flow direction 30V DC max , 5A max (Ethernet not available with this option)	
Ports	RTD (energy only)	None	Two 2-wire, 3-wire or 4-wire Pt100/Pt1000 RTD 12-bit inputs; Range of -40 to 200 °C; Clamp-on resistor kits available
	Programming	USB 2.0 mini B connector for connection to a device with SoloCUE configuration software	
	EIA-485	Modbus RTU command set or BACnet MS/TP; Baud rates 9600, 14400, 19200, 38400, 57600, 76800, 115k; terminating resistor selectable	
	Ethernet	Optional 10/100 Base T RJ45, communication via Modbus TCP/IP or BACnet/IP	
Data Logging	AquaCUE/BEACON	Connectivity to AquaCUE/BEACON endpoint (LTE cellular)	
	Number of points	Up to 8 parameters per record Selectable 1 second to 1 day Transfer logs via memory card	
	Real Time Clock	Backed up with a super capacitor, minimum of 32 days of data retention without power; Requires no servicing	
Alarms	MicroSD card slot	8 GB card, included with transmitter	
		Records 150 previous alarms, warnings or errors	
Languages		English, French, German, Italian, Spanish	
Security		Four levels: Read-only, Operator, Service and Admin; 6-digit passcode number; selectable auto logout	

UTM20 Series Ultrasonic Transit-time Flowmeters

13.3 Transducers

Model	Construction	Cable Length Max.	Pipe/Tubing Sizes ¹	Flow Rate Max. GPM (LPM)	Pipe/Tubing Materials
CA-CT⁵ fixed small pipe	CPVC, Ultem®, Nylon cord grip, PVC cable jacket; -40 to 194 °F	100 ft	0 5 to 2"	190	See ²
UZ adjustable small pipe	CPVC, Ultem, and anodized aluminum track system; Nickel-plated brass connector with Teflon insulation; PVC cable jacket, -40 to 194 °F (-40 to 90 °C)	100 ft (30 m)	0 5 to 2" (12 to 50 mm)	190 (720)	
NZ (IP67) standard pipe	PVC, Ultem®, Nylon cord grip, PVC cable jacket; -40 to 194 °F (-40 to 90 °C)	300 ft (90 m)	2 5 to 12" (DN65 to DN300)	4000 (15,000)	
RZ (IP54) standard pipe	PBT glass filled, Ultem®, Nylon cord grip; PVC cable jacket; -40 to 250 °F (-40 to 121 °C)	300 ft (90 m)	2 5 to 12" (DN65 to DN300)	4000 (15,000)	
JZ, KZ (IP54) standard pipe, integrated rail	PBT glass filled, Ultem, Nylon cord grip; PVC cable jacket; -40 to 250 °F (-40 to 121 °C)	300 ft (90 m)	2 5 to 6 in (DN65 to DN150) 2 5 to 12" (DN65 to DN300)	4000 (15,000)	
WZ (IP68) standard pipe, submersible	CPVC, Ultem, Nylon cord grip; Polyethylene cable jacket; -40 to 194 °F (-40 to 90 °C)	300 ft (90 m)	2 5 to 12" (DN65 to DN300)	4000 (15,000)	
HZ high temperature	PTFE, Vespel, Nickel-plated brass cord grip; FEP cable jacket; -40 to 350 °F (-40 to 176 °C)	300 ft (90 m)	2 5 to 12" (DN65 to DN300)	4000 (15,000)	
LZ (IP67) large pipe	CPVC, Ultem, Nylon cord grip PVC cable jacket; -40 to 194 °F (-40 to 90 °C)	300 ft (90 m)	8 to 48 in (DN200 to DN1200) ^{3, 4}	33,000 (125,000)	
YZ (IP68) large pipe, submersible	CPVC, Ultem, Nylon cord grip; Polyethylene cable jacket; -40 to 194 °F (-40 to 90 °C)	300 ft (90 m)	8 to 48 in (DN200 to DN1200) ^{3, 4}	33,000 (125,000)	

¹ Recommendations based on unlined, new pipes with water Recommended pipe or tubing sizes vary with pipe conditions and fluid

² PVC, CPVC, HDPE, PTFE, PDVF, stainless steel, ductile iron, aluminum, brass naval, carbon steel copper

³ Large pipe transducers are recommended for 8 to 12" pipes if normal velocity is expected to be greater than 12 ft/s (3 6 m/s)

⁴ Consult factory for larger pipe sizes

⁵ Not for metric pipes

13.4 RTD Kits

Part Number	Description	Installation	RTD Type	Construction	Temperature Range
76290	RTD pair; 15 ft (4.5 m) cable	Pipe clamp, surface mount, IP54	Pt 1000, Class A $\pm (0.15 + 0.002 \times t)$ with t as temperature °C	Aluminum body, silicone cable jacket	-58 to 356 °F (-50 to 180 °C)
76291	RTD pair; 50 ft (15 m) cable				
76292	RTD pair; 100 ft (30 m) cable				

13.5 SoloCUE Flow Device Manager Software

The flow meter may be programmed through the keypad or with SoloCUE software. If the meter is ordered without a display/ keypad, the flow meter must be programmed with SoloCUE software. The software is used to configure, calibrate and communicate with UTM20 meters with English, French, German, Italian and Spanish menus. Additionally, it has numerous troubleshooting tools to make diagnosing and correcting installation problems easier.

SoloCUE	Used to configure, calibrate and troubleshoot flow meters and control valves; Software is compatible with Windows 7, 8, 10	
USB Cable	RC820648	USB 2.0 mini B connector to A connector, shielded

14. Part Number Construction

14.1 UTM20 Flow Meters for Pipes 2". and Smaller

Model	UTM20 Ultrasonic Clamp-On Meter	DQ
Certification	General Area US/Canada, CE	G
Transducer Type ¹	½" ANSI Pipe	CA
	¾" ANSI Pipe	CB
	1" ANSI Pipe	CC
	1¼" ANSI Pipe	CD
	1½" ANSI Pipe	CE
	2" ANSI Pipe	CF
	½" Copper Tube	CG
	¾" Copper Tube	CH
	1" Copper Tube	CT
	1¼" Copper Tube	CJ
	1½" Copper Tube	CK
	2" Copper Tube	CL
	Small pipe, universal, DTTSU (not available with conduit)	UZ
Transmitter Type	110/220V AC Remote Mounted	R
	24V DC/AC Remote Mounted	B
Display	Display and Keypad	S
	No Display/Keypad	W
Remote Cable Length	15 feet (4.5 m)	AC
	30 feet (9 m)	AF
	50 feet (15 m)	AK
	75 feet (23 m)	AR
	100 feet (30 m)	BW
Conduit Type and Length (Conduit length is less than or equal to cable length)	None	WW
	5 feet (1.5 m)	AA
	15 feet (4.5 m)	AC
	30 feet (9 m)	AF
	50 feet (15 m)	AK
	75 feet (23 m)	AR
	100 feet (30 m)	BW

Hardware	½" NPT Threads, Poly cable glands	S
	½" NPT Threads, Nickel Plated Brass cable glands	T
	½" NPT Threads, no cable glands	N
	M20 Threads, Poly cable glands	C
	M20 Threads, Nickel Plated Brass cable glands	D
	M20 Threads, no cable glands	A
Endpoint Wiring Method	None	XX
Communication/Output	Standard Output (Modbus RTU or BACnet MS/TP field selectable)	S
	Standard Output plus Modbus TCP Ethernet	T
	Standard Output plus BACnet/IP Ethernet	V
	Standard Output plus Modbus TCP EthernetTStandard Output plus Aux Output	9
Units of Measure Totalizer/Flow Rate	Gallons/gallons per minute (field selectable, additional options available)	G
Testing & Tagging	Factory Calibrated	F
	Factory Calibrated/Stainless Steel Tag	S

¹ Stainless steel tube ½" to 2". options are available.

Part number sequence

DQ	-	G	-	-	-	-	-	-	XX	-	-	-
----	---	---	---	---	---	---	---	---	----	---	---	---

14.2 UTM20 Flow Meters for Pipes 2" and Smaller for Class I, Div 2 Hazardous Locations

Model	UTM20 Ultrasonic Clamp-On Meter	DQ
Certification	Hazardous Location, Class I, Division 2	B
Transducer Type 1	½" ANSI Pipe	CA
	¾" ANSI Pipe	CB
	1" ANSI Pipe	CC
	1¼" ANSI Pipe	CD
	1½" ANSI Pipe	CE
	2" ANSI Pipe	CF
	½" Copper Tube	CG
	¾" Copper Tube	CH
	1" Copper Tube	CT
	1¼" Copper Tube	CJ
	1½" Copper Tube	CK
	2" Copper Tube	CL
Transmitter Type	110/220V AC Remote Mounted	R
	24 VDC/AC Remote Mounted	B
Display	Display and Keypad	S
	No Display/Keypad	W
Remote Cable/Conduit Length 2	15 feet (4.5 m)	AC
	30 feet (9 m)	AF
	50 feet (15 m)	AK
	75 feet (23 m)	AR
	100 feet (30 m)	BW
Hardware	½" NPT Threads, Poly cable glands	S
	½" NPT Threads, Nickel Plated Brass cable glands	T
	½" NPT Threads, no cable glands	N
	M20 Threads, Poly cable glands	C
	M20 Threads, Nickel Plated Brass cable glands	D
	M20 Threads, no cable glands	A
Endpoint Wiring Method	None	XX

Communication/Output	Standard Output (Modbus RTU or BACnet MS/TP field selectable)	S
	Standard Output plus Modbus TCP Ethernet	T
	Standard Output plus BACnet/IP Ethernet	V
Units of Measure Totalizer/Flow Rate	Gallons/gallons per minute (field selectable, additional options available)	G
Testing & Tagging	Factory Calibrated	F
	Factory Calibrated/Stainless Steel Tag	S

¹Stainless steel tube ½" to 2". options are available.

²For hazardous location units, Remote Cable and Conduit Length codes must match

Part number sequence

DQ	-	B	-	-	-	-	-	-	XX	-	-	-
----	---	---	---	---	---	---	---	---	----	---	---	---

14.3 UTM20 Flow Meters for Pipes 2.5 in. and Larger

Model	UTM20 Ultrasonic Clamp-On Meter	DQ
Certification	General Area US/Canada, CE	G
Transducer Type	Medium pipe, DTTR, 2.5 in. (65 mm) or larger	RZ
	Medium pipe, submersible DTTN, 2.5 in. (65 mm) or larger 1	WZ
	2.5 to 6" (6"5 to 150 mm) Easy Rail (not available with conduit)	JZ
	2.5 to 12" (65 to 300 mm) Easy Rail (not available with conduit)	KZ
	Medium pipe, high temperature (not available with conduit)	HZ
	Large pipe, DTTL, 8 in. (200 mm) or larger	LZ
	Large pipe, submersible DTTL, 8 in. (200 mm) or larger 1	YZ
Transmitter Type	110/220V AC Remote Mounted	R
	24 VDC/AC Remote Mounted	B
Display	Display and Keypad	S
	No Display/Keypad	W
Remote Cable Length	15 feet (4.5 m)	AC
	30 feet (9 m)	AF
	50 feet (15 m)	AK
	75 feet (23 m)	AR
	100 feet (30 m)	BW
	150 feet (46 m)	BK
	200 feet (61 m)	DW
	250 feet (76 m)	DK
	300 feet (90 m)	EW
	350 feet (107 m) (DTTL "LZ" and "YZ" only)	EK
	400 feet (122 m) (DTTL "LZ" and "YZ" only)	FW
	450 feet (137) (DTTL "LZ" and "YZ" only)	FK
	500 feet (152 m) (DTTL "LZ" and "YZ" only)	GW
	550 feet (168) (DTTL "LZ" and "YZ" only)	GK
	600 feet (183 m) (DTTL "LZ" and "YZ" only)	HW

Conduit Type and Length (Conduit length is less than or equal to cable length)	None	WW
	5 feet (1.5 m)	AA
	15 feet (4.5 m)	AC
	30 feet (9 m)	AF
	50 feet (15 m)	AK
	75 feet (23 m)	AR
	100 feet (30 m)	BW
	150 feet (46 m)	BK
	200 feet (61 m)	DW
	250 feet (76 m)	DK
	300 feet (90 m)	EW
Hardware	½" NPT Threads, Poly cable glands	S
	½" NPT Threads, Nickel Plated Brass cable glands	T
	½" NPT Threads, no cable glands	N
	M20 Threads, Poly cable glands	C
	M20 Threads, Nickel Plated Brass cable glands	D
	M20 Threads, no cable glands	A
Endpoint Wiring Method	None	XX
Communication/Output	Standard Output (Modbus RTU or BACnet MS/TP field selectable)	S
	Standard Output plus Modbus TCP Ethernet	T
	Standard Output plus BACnet/IP Ethernet	V
	Standard Output plus Aux Output	9
Units of Measure Totalizer/Flow Rate	Gallons/gallons per minute (field selectable, additional options available)	G
Testing & Tagging	Factory Calibrated	F
	Factory Calibrated/Stainless Steel Tag	S

¹ Stainless steel tube ½" to 2". options are available.

² For hazardous location units, Remote Cable and Conduit Length codes must match

Part number sequence

DQ	G	-	-	-	-	-	-	XX	-	-	-
----	---	---	---	---	---	---	---	----	---	---	---

14.4 UTM20 Flow Meters for Pipes 2.5 in. and Larger for Class I, Div 2 Hazardous Locations

Model	UTM20 Ultrasonic Clamp-On Meter	DQ
Certification	Hazardous Location, Class I, Division 2	BR
Transducer Type	Medium pipe, DTTR, 2.5 in. (65 mm) or larger	RZ
	Medium pipe, submersible DTTN, 2.5 in. (65 mm) or larger 1	WZ
	Large pipe, DTTL, 8 in. (200 mm) or larger	LZ
	Large pipe, submersible DTTL, 8 in. (200 mm) or larger 1	YZ
Transmitter Type	110/220V AC Remote Mounted	R
	24 VDC/AC Remote Mounted	B
Display	Standard	S
	No Display/Keypad	W
Remote Cable/Conduit Length	15 feet (4.5 m)	AC
	30 feet (9 m)	AF
	50 feet (15 m)	AK
	75 feet (23 m)	AR
	100 feet (30 m)	BW
	150 feet (46 m)	BK
	200 feet (61 m)	DW
	250 feet (76 m)	DK
	300 feet (90 m)	EW
Hardware	½" NPT Threads, Poly cable glands	S
	½" NPT Threads, Nickel Plated Brass cable glands	T
	½" NPT Threads, no cable glands	N
	M20 Threads, Poly cable glands	C
	M20 Threads, Nickel Plated Brass cable glands	D
	M20 Threads, no cable glands	A
Endpoint Wiring Method	None	XX

Communication/Output	Standard Output (Modbus RTU or BACnet MS/TP field selectable)	S
	Standard Output plus Modbus TCP Ethernet	T
	Standard Output plus BACnet/IP Ethernet	V
Units of Measure Totalizer/Flow Rate	Gallons/gallons per minute (field selectable, additional options available)	G
Testing & Tagging	Factory Calibrated	F
	Factory Calibrated/Stainless Steel Tag	S

¹Stainless steel tube ½" to 2". options are available.

²For hazardous location units, Remote Cable and Conduit Length codes must match

Part number sequence

DQ	-	-	-	-	-	XX	-	-	-
----	---	---	---	---	---	----	---	---	---

14.5 UTM20 Flow Meters for Pipes Larger than 2". for ATEX/EICEx Hazardous Locations

Model	UTM20 Ultrasonic Clamp-On Meter	DQ
Certification	Hazardous Location, ATEX, IECEx	V
Transducer Type	Medium pipe, DTTR, 2.5 in. (65 mm) or larger	RZ
	Medium pipe, submersible DTTN, 2.5 in. (65 mm) or larger 1	WZ
	2.5 to 6" (65 to 150 mm) Easy Rail (not available with conduit)	JZ
	2.5 to 12" (65 to 300 mm) Easy Rail (not available with conduit)	KZ
	Large pipe, DTTL, 8 in. (200 mm) or larger	LZ
	Large pipe, submersible DTTL, 8 in. (200 mm) or larger 1	YZ
Transmitter Type	110/220V AC Remote Mounted	R
	24 VDC/AC Remote Mounted	B
Display	Display and Keypad	S
	No Display/Keypad	W
Remote Cable Length	15 feet (4.5 m)	AC
	30 feet (9 m)	AF
	50 feet (15 m)	AK
	75 feet (23 m)	AR
	100 feet (30 m)	BW
	150 feet (46 m)	BK
	200 feet (61 m)	DW
	250 feet (76 m)	DK
Conduit Type and Length (Conduit length is less than or equal to cable length)	None	WW
Hardware	½" NPT Threads, Poly cable glands	S
	½" NPT Threads, Nickel Plated Brass cable glands	T
	½" NPT Threads, no cable glands	N
	M20 Threads, Poly cable glands	C
	M20 Threads, Nickel Plated Brass cable glands	D
	M20 Threads, no cable glands	A
Endpoint Wiring Method	None	XX
Communication/Output	Standard Output (Modbus RTU or BACnet MS/TP field selectable)	S
	Standard Output plus Modbus TCP Ethernet	T
	Standard Output plus BACnet/IP Ethernet	V

Units of Measure Totalizer/Flow Rate	Gallons/gallons per minute (field selectable, additional options available)	G
	Factory Calibrated	F
Testing & Tagging	Factory Calibrated/Stainless Steel Tag	S

¹ Submersible transducer cables use two conduit openings.**Note:** Check for availability.

Part number sequence

DQ	-	-	-	-	-	-	XX	-	-	-
----	---	---	---	---	---	---	----	---	---	---

14.6 UTM20 Energy Meters for Pipes 2". and Smaller

Model	UTM20 Ultrasonic Clamp-On Meter	DR
Certification	General Area US/Canada, CE	G
Transducer Type 1	½" ANSI Pipe	CA
	¾" ANSI Pipe	CB
	1" ANSI Pipe	CC
	1¼" ANSI Pipe	CD
	1½" ANSI Pipe	CE
	2" ANSI Pipe	CF
	½" Copper Tube	CG
	¾" Copper Tube	CH
	1" Copper Tube	CT
	1¼" Copper Tube	CJ
	1½" Copper Tube	CK
	2" Copper Tube	CL
	Small pipe, universal, DTTSU (not available with conduit)	UZ
Transmitter Type	110/220V AC Remote Mounted	R
	24 VDC/AC Remote Mounted	B
Display	Display and Keypad	S
	No Display/Keypad	W
Remote Cable Length	15 feet (4.5 m)	AC
	30 feet (9 m)	AF
	50 feet (15 m)	AK
	75 feet (23 m)	AR
	100 feet (30 m)	BW
Conduit Type and Length (Conduit length is less than or equal to cable length)	None	WW
	5 feet (1.5 m)	AA
	15 feet (4.5 m)	AC
	30 feet (9 m)	AF
	50 feet (15 m)	AK
	75 feet (23 m)	AR
	100 feet (30 m)	BW
RTD Type	Surface, Commercial	C
	None (user provided)	X

RTD Length	15 feet	AC
	50 feet	AK
	100 feet	BW
	None (user provided)	WW
Hardware	½" NPT Threads, Poly cable glands	S
	½" NPT Threads, Nickel Plated Brass cable glands	T
	½" NPT Threads, no cable glands	N
Endpoint Wiring Method	None	XX
Communication/Output	Standard Output (Modbus RTU or BACnet MS/TP field selectable)	S
	Standard Output plus Modbus TCP Ethernet	T
	Standard Output plus BACnet/IP Ethernet	V
	Standard Output plus Auxiliary Dry Contact Output	9
Units of Measure Totalizer/Flow Rate	Gallons/gallons per minute (field selectable, additional options available)	G
Units of Measure Energy Totalizer/Rate	Kilowatt-hour/Watt (field selectable, additional options available)	R
Testing & Tagging	Factory Calibrated	F
	Factory Calibrated/Stainless Steel Tag	S

¹ Stainless steel tube ½" to 2". options are available.

Part number sequence

DR	G	-	-	-	-	-			-	XX	-	-	-	-
-----------	----------	---	---	---	---	---	--	--	---	-----------	---	---	---	---

14.7 UTM20 Energy Meters for Pipes 2.5 in. and Larger

Model	UTM20 Ultrasonic Clamp-On Meter	DR
Certification	General Area US/Canada, CE	G
Transducer Type	Medium pipe, DTTR, 2.5 in. (65 mm) or larger	RZ
	Medium pipe, submersible DTTN, 2.5 in. (65 mm) or larger 1	WZ
	2.5 to 6" (65 to 150 mm) Easy Rail (not available with conduit)	JZ
	2.5 to 12" (65 to 300 mm) Easy Rail (not available with conduit)	KZ
	Medium pipe, high temperature (not available with conduit)	HZ
	Large pipe, DTTL, 8 in. (200 mm) or larger	LZ
	Large pipe, submersible DTTL, 8 in. (200 mm) or larger 1	YZ
Transmitter Type	110/220V AC Remote Mounted	R
	24 VDC/AC Remote Mounted	B
Display	Standard	S
	No Display/Keypad	W
Remote Cable Length 2	15 feet (4.5 m)	AC
	30 feet (9 m)	AF
	50 feet (15 m)	AK
	75 feet (23 m)	AR
	100 feet (30 m)	BW
	150 feet (46 m)	BK
	200 feet (61 m)	DW
	250 feet (76 m)	DK
	300 feet (90 m)	EW
Conduit Type and Length (Conduit length is less than or equal to cable length)	None	WW
	5 feet (1.5 m)	AA
	15 feet (4.5 m)	AC
	30 feet (9 m)	AF
	50 feet (15 m)	AK
	75 feet (23 m)	AR
	100 feet (30 m)	BW
	150 feet (46 m)	BK
	200 feet (61 m)	DW
	250 feet (76 m)	DK
	300 feet (90 m)	EW

RTD Type	Surface, Commercial	C
	None (user provided)	X
RTD Length	15 feet (4.5 m)	AC
	50 feet (15 m)	AK
	100 feet (30 m)	BW
	None (user provided)	WW
Hardware	½" NPT Threads, Poly cable glands	S
	½" NPT Threads, Nickel Plated Brass cable glands	T
	½" NPT Threads, no cable glands	N
	M20 Threads, Poly cable glands	C
	M20 Threads, Nickel Plated Brass cable glands	D
	M20 Threads, no cable glands	A
Endpoint Wiring Method	None	XX
Communication/Output	Standard Output (Modbus RTU or BACnet MS/TP field selectable)	S
	Standard Output plus Modbus TCP Ethernet	T
	Standard Output plus Aux Output	9
Units of Measure Totalizer/Flow Rate	Gallons/gallons per minute (field selectable, additional options available)	G
Units of Measure Energy Totalizer/Rate	Kilowatt-hour/Kilowatt (field selectable, additional options available)	R
Testing & Tagging	Factory Calibrated	F
	Factory Calibrated/Stainless Steel Tag	S

¹ Contact factory for DTTL cable lengths longer than 300 ft.

² Submersible transducer cables use two conduit openings.

Part number sequence

DR	G	-	-	-	-	-	-	-	XX	-	-	-	-
-----------	----------	---	---	---	---	---	---	---	-----------	---	---	---	---

15. North American Pipe Schedules

Table 8: Cast iron pipe, standard classes, 3 to 10 inch

Size in.	Class in.	A	B	C	D	E	F	G	H
3	OD	3.80	3.96	3.96	3.96				
	Wall	0.39	0.42	0.45	0.48				
	ID	3.02	3.12	3.06	3.00				
4	OD	4.80	5.00	5.00	5.00				
	Wall	0.42	0.45	0.48	0.52				
	ID	3.96	4.10	4.04	3.96				
6	OD	6.90	7.10	7.10	7.10	7.22	7.22	7.38	7.38
	Wall	0.44	0.48	0.51	0.55	0.58	0.61	0.65	0.69
	ID	6.02	6.14	6.08	6.00	6.06	6.00	6.08	6.00
8	OD	9.05	9.05	9.30	9.30	9.42	9.42	9.60	9.60
	Wall	0.46	0.51	0.56	0.60	0.66	0.66	0.75	0.80
	ID	8.13	8.03	8.18	8.10	8.10	8.10	8.10	8.00
10	OD	11.10	11.10	11.40	11.40	11.60	11.60	11.84	11.84
	Wall	0.50	0.57	0.62	0.68	0.74	0.80	0.86	0.92
	ID	10.10	9.96	10.16	10.04	10.12	10.00	10.12	10.00

Table 9: Steel, stainless steel, PVC pipe, standard classes

NPS	OD	SCH 60		X STG.		SCH 80		SCH 100		SCH 120/140		SCH 180	
in.	in.	ID in.	Wall in.	ID in.	Wall in.	ID in.	Wall in.	ID in.	Wall in.	ID in.	Wall in.	ID in.	Wall in.
1	1.315			0.957	0.179	0.957	0.179					0.815	0.250
1.25	1.660			1.278	0.191	1.278	0.191					1.160	0.250
1.5	1.900			1.500	0.200	1.500	0.200					1.338	0.281
2	2.375			1.939	0.218	1.939	0.218					1.687	0.344
2.5	2.875			2.323	0.276	2.323	0.276					2.125	0.375
3	3.500			2.900	0.300	2.900	0.300					2.624	0.438
3.5	4.000			3.364	0.318	3.364	0.318						
4	4.500			3.826	0.337	3.826	0.337					3.624	0.438
5	5.563			4.813	0.375	4.813	0.375					4.563	0.500
6	6.625			5.761	0.432	5.761	0.432					5.501	0.562
8	8.625	7.813	0.406	7.625	0.500	7.625	0.500	7.437	0.594	7.178	0.719	6.183	1.221
10	10.75	9.750	0.500	9.75	0.500	9.562	0.594	9.312	0.719	9.062	0.844	8.500	1.125

Table 10: Steel, stainless steel, PVC pipe, standard classes (continued)

NPS	OD	SCH 5		SCH 10 (Lt Wall)		SCH 20		SCH 30		STD		SCH 40	
in.	in.	ID in.	Wall in.	ID in.	Wall in.	ID in.	Wall in.	ID in.	Wall in.	ID in.	Wall in.	ID in.	Wall in.
1	1.315	1.185	0.065	1.097	0.109	-	-	-	-	1.049	—	1.049	0.133
1.25	1.660	1.53	0.065	1.442	0.109					1.380		1.380	0.140
1.5	1.900	1.77	0.065	1.682	0.109					1.610		1.610	0.145
2	2.375	2.245	0.065	2.157	0.109					2.067		2.067	0.154
2.5	2.875	2.709	0.083	2.635	0.120					2.469		2.469	0.203
3	3.500	3.334	0.083	3.260	0.120					3.068		3.068	0.216
3.5	4.000	3.834	0.083	3.760	0.120					3.548		3.548	0.226
4	4.500	4.334	0.083	4.260	0.120					4.026	0.237	4.026	0.237
5	5.563	5.345	0.109	5.295	0.134					5.047	0.258	5.047	0.258
6	6.625	6.407	0.109	6.357	0.134					6.065	0.280	6.065	0.280
8	8.625	8.407	0.109	8.329	0.148	8.125	0.250	8.071	0.277	7.981	0.322	7.981	0.322
10	10.75	10.482	0.134	10.42	0.165	10.25	0.250	10.13	0.310	10.02	0.365	10.02	0.365

Table 11: Copper tubing, copper and brass pipe, aluminum

Nominal Diameter in.		Copper Tubing in.			Copper & Brass Pipe in.	Alum. in.
		Type				
		K	L	M		
0 5	OD	0.625	0.625	0.625	0.840	-
	Wall	0.049	0.040	0.028	0.108	
	ID	0.527	0.545	0.569	0.625	
0 6250	OD	0.750	0.750	0.750	-	
	Wall	0.049	0.042	0.030		
	ID	0.652	0.666	0.690		
0 75	OD	0.875	0.875	0.875	1.050	
	Wall	0.065	0.045	0.032	0.114	
	ID	0.745	0.785	0.811	0.822	
1	OD	1.125	1.125	1.125	1.315	
	Wall	0.065	0.050	0.035	0.127	
	ID	0.995	1.025	1.055	1.062	
1 25	OD	1.375	1.375	1.375	1.660	
	Wall	0.065	0.055	0.042	0.146	
	ID	1.245	1.265	1.291	1.368	
1 5	OD	1.625	1.625	1.625	1.900	
	Wall	0.072	0.060	0.049	0.150	
	ID	1.481	1.505	1.527	1.600	
2	OD	2.125	2.125	2.125	2.375	
	Wall	0.083	0.070	0.058	0.157	
	ID	1.959	1.985	2.009	2.062	
2 5	OD	2.625	2.625	2.625	2.875	2.500
	Wall	0.095	0.080	0.065	0.188	0.050
	ID	2.435	2.465	2.495	2.500	2.400
3	OD	3.125	3.125	3.125	3.500	3.000
	Wall	0.109	0.090	0.072	0.219	0.050
	ID	2.907	2.945	2.981	3.062	2.900

Table 11: Copper tubing, copper and brass pipe, aluminum (continued)

Nominal Diameter in.		Copper Tubing in.			Copper & Brass Pipe in.	Alum. in.
		Type				
		K	L	M		
3-1/2	OD	3.625	3.625	3.625	4.000	-
	Wall	0.120	0.100	0.083	0.250	
	ID	3.385	3.425	3.459	3.500	
4	OD	4.125	4.125	4.125	4.500	4.000
	Wall	0.134	0.110	0.095	0.095	0.250
	ID	3.857	3.905	3.935	3.935	4.000
4-1/2	OD	-				5.000
	Wall					0.250
	ID					4.500
5	OD	5.125	5.125	5.125	5.563	5.000
	Wall	0.160	0.125	0.109	0.250	0.063
	ID	4.805	4.875	4.907	5.063	4.874
6	OD	6.125	6.125	6.125	6.625	6.000
	Wall	0.192	0.140	0.122	0.250	0.063
	ID	5.741	5.845	5.881	6.125	5.874
7	OD	-			7.625	7.000
	Wall				0.282	0.078
	ID				7.062	6.844
8	OD	8.125	8.125	8.125	8.625	8.000
	Wall	0.271	0.200	0.170	0.313	0.094
	ID	7.583	7.725	7.785	8.000	7.812
10	OD	10.125	10.125	10.125	10.000	-
	Wall	0.338	0.250	0.212	0.094	
	ID	9.449	9.625	9.701	9.812	

