spirax sarco

3C.500-E

Issue 4.1 - 2016

# RV type Flash Vessels

### **Description**

The energetic efficiency of a steam plant or of one of it sections can be easily increased and optimised simply recovering the flash

steam produced during the discharge of the condensate.

It is for this reason that every modern steam plant must be equipped with one or more recovery sections for the flash steam.

Steam traps discharge the condensate from a pressurized system to an other having a lower pressure; during the changeover, due to an unavoidable physical low, part of the high temperature condensate is reverted to steam that have exactly the same characteristics of the steam produced by boilers. From here the convenience and the logical consequence of arranging the recovery and the use of the flash steam by means of flash systems, including flash vessels and related accessories.

The system will amortize the whole cost of the equipment in a very short time, producing afterwards an economical recovery by a free of cost energy saving.

#### Standards

The RV flash vessels, standard construction or specifically engineered on project, are designed and constructed according to the requirements of the European Pressure Equipment Directive 2014/68/EU.

#### Certification

The RV flash vessels are available with material certification to EN 10204 3.1.

Note: All certification / inspection requirements must be stated at the time of order placement.



**Fig. 1** - Plant section for the flash steam recovery by means of RV flash vessel and related accessories: steam traps, strainers, sight glasses, pressure control, safety valve, air vent, pressure gauge, stop valves.

#### Technical features

| Models                  | RV 6 - RV 8 - RV 12 - RV 15 - RV S on   | RV 6 - RV 8 - RV 12 - RV 15 - RV S on design                                      |  |  |  |  |  |  |
|-------------------------|---|---|--|--|--|--|--|--|
| Fluids                  | Steam - Condensate                      | Steam - Condensate  |  |  |  |  |  |  |
| Materials               | Quality carbon steel sheet - Fabricated | Quality carbon steel sheet - Fabricated execution - External heat resistant paint |  |  |  |  |  |  |
| Execution               | 25 bar g @ 250°C                        | 25 bar g @ 250°C  |  |  |  |  |  |  |
| Cold hydraulic test     | 37,5 bar g                              | 37,5 bar g  |  |  |  |  |  |  |
| Plant connections       | Flanged EN 1092 PN 40                   | Flanged EN 1092 PN 40   |  |  |  |  |  |  |
| Accessories connections | Screwed gas ISO 7/1 Rp                  | Screwed gas ISO 7/1 Rp  |  |  |  |  |  |  |
|                         | Type RV 6                               | Category 2  |  |  |  |  |  |  |
| C € Mark                | Type RV 8                               | Category 2  |  |  |  |  |  |  |
| Category                | Type RV 12                              | Category 3  |  |  |  |  |  |  |
| Gas and Liquid Group 2  | Type RV 15                              | Category 3  |  |  |  |  |  |  |
|                         | Type RV S                               | To be defined   |  |  |  |  |  |  |

#### How to size

Use the chart below to select the appropriate size flash vessel. It is necessary to know the pressure on the condensate at the steam traps discharge from the high pressure section of the plant or the boiler pressure in the case of blowdown heat recovery, the flash steam pressure (desired or already existing) and the condensate or blowdown flowrate.

See the two sizing examples indicated on the graph below.

## Example 1 (solid lines):

A boiler plant operating at 12 bar g has a TDS control blowdown flowrate of 2500 kg/h (3 boilers at 833 kg/h each).

The flash steam from the blowdown is to be added to the low pressure steam system operating at 1 bar g.

- 1. From boiler pressure move horizontally to flash steam pressure A
- 2. Drop vertically to blowdown flowrate in kg/h B

- Follow curve to right-hand scale and across to same flash pressure - C
- Move upwards to flash vessel size. Select flash vessels in this case an RV 8 is required.

#### Example 2 (dotted lines):

A plant operating on steam at 11 bar g condenses 4000 kg/h of steam. Flash is to be recovered at  $0.5\,\mathrm{bar}$  g:


- From pressure on steam traps move horizontally to flash steam pressure - A1
- 2. Drop vertically to condensate flowrate in kg/h B1
- Follow curve to right hand scale and across to same flash pressure
   C1
- Move upwards to flash vessels size. Select flash vessel in this case an RV 12 is required.


# Safety Information, Installation and Maintenance

For full details see the Installation and Maintenance Instructions supplied with the product.

The pressure equipments are engineered taking into consideration no corrosion extra thickness. To evaluate the full integrity of the construction it will be advisable to follow the recommendations in the Installation and Maintenance Instructions manual.

Flash steam pressure bar





# Dimensions in mm and weights in kg (approximate)

| Туре  | Α  | В    | С   | D   | E<br>(DN) | F<br>(DN) | G<br>(DN) | Н    | I   | L   | Weight |
|-------|--|------|-----|-----|-----------|-----------|-----------|------|-----|-----|--------|
| RV 6  | 168  | 1137 | 510 | 343 | 65        | 40        | 50        | 1/2" | 184 | 120 | 40     |
| RV 8  | 219  | 1151 | 515 | 350 | 80        | 50        | 80        | 1/2" | 210 | 120 | 65     |
| RV 12 | 323  | 1219 | 562 | 397 | 100       | 50        | 80        | 1/2" | 262 | 120 | 90     |
| RV 15 | 408  | 1354 | 630 | 425 | 150       | 50        | 125       | 1/2" | 307 | 120 | 112    |
| RV S  | To be defined according to specific projects |      |     |     |           |           |           |      |     |     |        |