


EP6/PP6 Mounting Kit Assembly


HARDWARE IDENTIFICATION						
A	BRACKET					
C	LEVER 20-30	EY1 / PY1 ONLY				
D	LEVER 50-80	EY2 / PY2 ONLY				
Н	LOCATOR 20-30	EY1 / PY1 ONLY				
K	LOCATOR 50-70	EY2 / PY2 ONLY				
M	PIN					
P	SPRING					
Q	SPACER	PY1 / PY2 ONLY				
R	U-BOLT	UBC ONLY				
S	M8 CAP HEAD SCREW					
T	M8 HEX HEAD SCREW					
U	M8 SPRING WASHER					
V	M8 PLAIN WASHER					
W	M8 NUT					
X	M6 CAP HEAD SCREW					
Y	M5 NUT					
Z	NUT, SPRING WASHER AND SCREW SUPPLIED WITH EP6 / PP6 POSITIONER					

ACTUATOR COUPLING



	HARDWARE IDENTIFICA	TION					
В	BRACKET						
E	LEVER 10-40	UY3 ONLY					
F	LEVER 30-70	UY1 ONLY					
G	LEVER 60-100	UY2 / UY4 ONLY					
J	LOCATOR 65-70-75	UY2 ONLY					
L	LOCATOR - SLOTTED	UY1 / UY3 / UY4					
N	PIN						
P	SPRING						
R	U-BOLT	UBC ONLY					
S	M8 CAP HEAD SCREW						
T	M8 HEX HEAD SCREW						
U	M8 SPRING WASHER						
V	M8 PLAIN WASHER						
W	M8 NUT						
X	M6 CAP HEAD SCREW						
Υ	M5 NUT						
Z	NUT, SPRING WASHER AND SCREW SUPPLIED WITH EP6 / PP6 POSITIONER						

Z	Z NUT, SPRING WASHER AND SCREW SUPPLIED WITH EP6 / PP6 POSITIONER											
→												
		C SERIES		QL		SPIRA-TROL						
VALVE >				DN15- DN100		DN125- DN200	DN15- DN100		DN125- DN300			
	PN1600	A~R	C~R									
ACTUATOR	PN3000			D~L	A~L		D~L	A~L				
	PN4000			D~L	A~L		D~L	A~L				
	PN5000			D~L	A~L		D~L	A~L				
	PN6000			D~L	A~L		D~L	A~L				
	PN9100			D~L	A~L		D~L	A~L				
	PN9200			D~L	A~L		D~L	A~L				
	PN9300			D~L	A~L		D~L	A~L		 <*		
	PN9400					B~R			E~R			
	TN2200					B~R			E~R			
	TN2300					B~R			E~R			
	TN2400					B~R			E~R			
STROKE mm		38	50	20	30	50	20	30	70			
										•		



*>