



# spirax sarco®

## PN1000 and PN2000 Actuator Spares

PN1000



PN2000



### Spare parts

The spare parts available are detailed below. No other parts are supplied as spares.

#### Available spares

<b>Stem seal kit</b>	Spindle 'O' ring and 'V' ring and diaphragm plate 'O' ring	<b>B, C, D</b>
<b>Diaphragm kit</b>	Diaphragm	<b>A</b>
<b>Spring kit</b>	Set of spring(s)	<b>E</b>
<b>Linkage kit</b>	Connector, valve spindle adapter, lock plate, fixing screws and travel indicator	<b>F, G, H, I, J</b>

### How to order spares

Always order spares by using the description given in the column headed 'Available spares' and state the actuator type.

**Example for PN1000:** 1 Stem seal kit for a PN1520A2 pneumatic actuator.

**Example for PN2000:** 1 Stem seal kit for a PN2520A2 pneumatic actuator.