

Manual Loading Station Type 354 Installation and Maintenance Instructions

INSTALLATION

Type 354 manual loading stations are provided with one pillar (11) complete with an auxiliary fixing plate (12) and one screw (18) for simple panel mounting (see part list on the back of sheet).

After installation on panel, pneumatic piping must be provided by utilizing air connections (1/4" NPT female) fitted on the back of station and identified by following letters:

E, air supply; U, output signal.

It is strongly recommended to check for perfect airtightness of connections and fittings on the signal pneumatic line, with water soap solution or special spray compounds.

Air supply must be filtered, clean, dry and oil free, at 20 psig (1.4 bar) pressure; maximum 35 psig (2.4 bar).


MAINTENANCE

Type 354 loading stations do not require special maintenance.


Replacement of mamometer (17) is accomplished by unscrewing two screws (8) which fix manometer holding plate (16) and unscrewing manometer itself.


In case there is abnormal operation of pressure regulator due to air leakage with output signl constantly low, replace diaphragm assembly (5) as follows:

- rotate counterclockwise adjusting knob (14) up to its stop;
- loosen the four screws (1);
- disassemble plate (4) and plate (2) from base (13) without damaging connection (10);
- separate plate (2) from plate (4), remove diaphragm assembly (5) and replace it with a new one;
- reassemble now unit making sure that springs (3) and (6) are correctly positioned in their seats and that side holes of plate (4), of plate (2) and of diaphragm assembly (5) are correctly aligned with each other.




Panel cut-out





PART LIST



RECOMMENDED SPARE PARTS

Description	Part list	Ordering code
Diaphragm and O-rings assembly	Part 5 - 9 - 15	3.837.4750.151
Manometer set	Part 15 - 17	3.837.4750.154

REPAIR

Please contact our nearest Branch Office or Agent, or directly Spirax-Sarco S.r.l. Via Pasubio, 8 - Cernusco sul Naviglio (MI) - ITALY - Tel.: +39 02 92 11 95 11 - Fax: +39 02 924 03 21

LOSS OF GUARANTEE

Total or partial disregard of above instructions involves loss of any right to guarantee.

Spirax-Sarco S.r.l. - Via per Cinisello, 18 - 20054 Nova Milanese (MI) - Tel.: +39 0362 49 17.1 - Fax: +39 0362 49 17 307