spirax /sarco LCV1 Bronze

TI-P029-01 CTLS Issue 10

## **Description**

The LCV1 is a bronze lift check valve which is installed in horizontal lines to prevent reverse flow.

#### Standards

This product fully complies with the requirements of the EU Pressure Equipment Directive/UK Pressure Equipment (Safety) Regulations.

Lift Check Valve

#### Certification


This product is available with certification to EN 10204 2.2.

Note: All certification/inspection requirements must be stated at the time of order placement.

## Sizes and pipe connections


1/2", 3/4", 1", 11/4", 11/2" and 2". Screwed BSP or NPT

## **Materials**



No.	Part	Material	
1	Body	Bronze	EN 1982 CC491K
2	Cone	Brass	BS 2874 CZ 114
3	Сар	Brass	EN 12165 CW617N
4 (Not illustrated)	Spring	Stainless steel	BS 2056 302 S26

# Pressure/temperature limits



The product **must not** be used in this region.

Body	design conditions	PN16
РМА	Maximum allowable pressure	16 bar g @ 180 °C
TMA	Maximum allowable temperature	250 °C @ 8 bar g
Minim	um allowable temperature	-29 °C
РМО	Maximum operating pressure for saturated steam service	14 bar g
ТМО	Maximum operating temperature	250 °C @ 8 bar g
	um operating temperature For lower operating temperatures consult Spirax Sarco.	0 °C
Design	ned for a maximum cold hydraulic test pressure of	28 bar g

## Kv values

Size	1/2"	3/4"	1"	11/4"	11/2"	2"
Kv	1.9	4.3	8.5	11.9	18.8	30.8


For conversion: Cv (UK) = Kv x 0.963 Cv (US) = Kv x 1.156


# Opening pressures in mbar

Without springs			→ Flow pressures				
Size	1/2"	3/4"	1"	11/4"	11/2	2"	
<b>→</b>	6.2	7.4	6.5	7.1	7.1	6.9	

With springs fitted the opening pressure is the same as the spring strength.

## Dimensions/weights (approximate) in mm and kg





Size	Α	В	С	D	Weight
1/2"	52	46	18	36	0.2
3/4"	71	58	20	41	0.5
1"	86	71	28	56	0.8
11/4"	108	71	28	56	0.8
11/2"	106	91	36	71	1.9
2"	131	104	43	86	2.7

## Safety information, installation and maintenance

For full details see the Installation and Maintenance Instructions (IM-P029-06) supplied with the product.

## Installation note:

Always install the LCV1 horizontally with the flow in the direction indicated on the body.

#### Disposal

This product is recyclable. No ecological hazard is anticipated with the disposal of this product, providing due care is taken.

# **Spare parts**

There are no spare parts available for this product.

#### How to order

Example: 1 off Spirax Sarco 11/4" LCV1 lift check valve having screwed BSP connections.